

BEKO

COLOUR TELEVISIONS

IDTV
28C723IDW

Operating Instructions

CONTENTS

General information	2
Special features of your integrated digital television.....	2
Receiving digital stations.....	2
Safety Instructions	3
Special features	4
Electrical connections	5
Connection/Preparation	6
Connecting the aerial and the mains cable.....	6
Inserting batteries into the remote control.....	6
Control unit	7
Front panel/External connections.....	7
External connections table.....	8
Remote control.....	8
Television operation	9
Basic functions.....	9
Settings	10
Searching for television stations.....	10
Tuning digital television stations.....	10
Automatic search.....	10
Manual search.....	11
Resetting the receiver.....	11
Installation.....	12
Access control.....	13
Special features for digital stations.....	14
TV guide.....	16
Tuning analogue television stations.....	16
Autoprogramming.....	16
Tuning channels using the search.....	17
Fine tuning analogue television stations.....	17
Tuning the analogue television channels by entering the channel numbers.....	18
Moving to digital setup menu.....	18
Special features for analogue stations.....	18
Sound settings	20-21
Picture settings	22
Special features	23-24
Teletext mode	25
Fastext, Toptext (Model Dependant).....	25-26
Connecting external equipment	27
Connecting a video recorder.....	27-28
Connecting a DVD player.....	29
Connecting a decoder.....	30
Connecting TV with video and satellite/digital receiver.....	31
Troubleshooting	32
Technical specifications table	33
Guarantee	34
Service	35

Special features of your integrated digital television

This television can receive and process all analogue and all digital stations. This television set has an integrated digital and analogue receiver.

The digital receiver unit converts the signals from digital stations to provide outstanding audio and picture quality.

The TV guide (only for digital stations) tells you of any schedule changes at short notice, and provides an overview of all the stations' schedules for the next few days.

If the broadcaster provides it, you can call up detailed information on each programme at the touch of a button.

This television has a very comprehensive, user-friendly menu system.

2

Receiving digital stations

You need a digital outdoor or indoor aerial (passive or active indoor aerial with its own power supply) to receive digital stations.

Unlike analogue broadcasting, not every station has its own transmission frequency. Instead, several stations are grouped into what are known as bouquets on a regional or national level.


You can find the current transmission information on teletext from various broadcasters, or look in a TV guide or on the Internet.

Safety is Important

Your safety and the safety of others is important. Please, therefore, ensure you read the Safety instructions **before** you operate this television.

Safety instructions

! Read all the safety instructions before first use of your TV.



- Position the television so that direct light does not fall on the screen. Excessive light will cause a washed out effect.



- Position the power supply lead and other leads so that they are not likely to be walked on or pinched by things placed on or against them.



- Do not use the appliance in humid or damp conditions. Do not allow the appliance to get wet, i.e. dripping or splashing, as this may be dangerous. Do not place water filled objects, such as vases and flower pots on top of the appliance.



- Make sure that no naked flame sources, such as lighted candles, are placed on top of the appliance.
- Do not place the television near heat sources such as radiators, ovens, stoves, etc.



- Do not use the television near any apparatus that produces a magnetic field such as HI-FI speakers or electric motors otherwise colourpurity may be affected.



- The heat built up in the set escapes through ventilation holes, so do not cover the set by drapes, clothes etc. that may block air circulation. Do not place the television on carpet or soft furnishings.
- NEVER let children push anything into the holes or slots on the case.



- Clean the TV Screen using a slightly damp cloth or chamois leather. Never use abrasive cleaning agents like liquid or aerosol cleaners.
- Remove the mains plug from the socket outlet while cleaning.



- If you wish to place the television on a shelf or in a wall unit always ensure there is a minimum air gap of 8 cm around the top, sides and rear of the television, to assist ventilation.



- Your TV set is designed to operate with mains voltages 230V AC; 50Hz. Do not connect your TV set to power sources other than the mains supply.

- To fully disconnect the TV, the mains plug is used as a disconnecting device and therefore shall be readily accessible.

Television

Thank you for buying this television which is designed to give you many years of satisfactory service.

You may already be familiar with using a television but do please take time to read these instructions. They are designed to familiarise you with the unit's many new features and to ensure you get the very best out of your purchase.

Special features

4

- Automatic tuning system with country selection
- 899 Digital, 100 Analog programme memory
- Available for cable channels (A decoder maybe required)
- Manual fine tuning for analogue channels
- S-Video connection (Model dependant)
- Audio/Video PHONO sockets (Model dependant)
- Back audio out (Model dependant)
- CI slot (Model dependant)
- Component input via PHONO (Model dependant)
- Component input via scart (Model dependant)
- SPDIF coaxial output (Model dependant)
- Stereo headphone socket (Model dependant)
- 2 Scart Socket: Video cassette recorder, satellite receiver, video disc player,DVD, TV games or a home computer can be connected to this AV socket with an appropriate connecting cable.
- Third scart socket (Model dependant)
- Stereo sound system (Nicam) (Model dependant)
- Spatial sound effect
- Equalizer sound setup
- Automatic Volume Leveling
- Virtual Dolby Surround (Model dependant)
- Subwoofer (Model dependant)
- Picture adjustment using one button (Smart control)
- Sound adjustment using one button (Smart control)
- User friendly on screen display system
- Infrared remote control
- Multilanguage menu system
- On timer
- Off timer
- Child lock-Adult lock
- Return to the last channel viewed (SWAP)
- Alarm timer (Model dependant)
- 4:3, 16:9, Zoom, Letterbox, Subtitle, Panaroma (optional), picture formats (for Widescreen TV sets)
- Naming the channels
- Teletext reception
- Digital teletext
- Auto recognition of the broadcasting format (4:3, 16-9 or Letterbox) via WSS feature
- Digital Colour Transition Improvement (DCTI).
- Digital Comb Filter (DCF)
- Digital Luminance Transition Improvement (DLTI)
- Dynamic Digital Video Adaption (Model dependant)
- TILT function (Model dependant)
- MHEG-5
- Favorite channel listing
- DVB subtitling
- OAD (Over air download)

Electrical connections

1. SECTION: INSTALLATION AND PRECAUTIONS

ELECTRICAL CONNECTIONS

For your own safety read the following instructions carefully before attempting to connect this unit to the mains supply.

For your convenience a mains plug with a fuse has been fitted to this appliance. For your safety please observe the following information.

The moulded plug on this appliance incorporates a 5A fuse. Should the fuse need to be replaced an ASTA approved BS 1362 fuse of the same rating must be used. Do not forget to refit the fuse cover. In the event of losing the fuse cover the plug must not be used until a replacement fuse cover which must be the same colour as that visible on the pin face of the plug has been fitted. Fuse covers are available from any good electrical store.

If the fitted moulded plug is not suitable for your socket, then the plug should be cut off and an appropriate plug fitted.

IMPORTANT! FITTING A DIFFERENT PLUG.

If the mains plug is cut off from the mains cable rewire the replacement plug in accordance with these instructions.

IMPORTANT

The wires in this mains lead are coloured in accordance with the following code:

Blue - Neutral

Brown - Live

As the colours in the mains lead may not correspond with the coloured markings identifying the terminals in your plug proceed as follows:

The wire coloured BLUE must be connected to the terminal marked with the letter N or coloured BLACK.


The wire coloured BROWN must be connected to the terminal marked with the letter L or coloured RED.

Do not make any connection to the terminal marked E or $\frac{1}{\perp}$ OR COLOURED GREEN, GREEN /YELLOW.

The television receiver must be protected by a 5A fuse if a fused plug is fitted.

For any other plug fit a 5A fuse at the distribution board.

5



13 A PLUG

Caution: - Under no circumstances should the discarded plug be inserted into a mains socket. To prevent shock hazard carefully dispose of the discarded plug into your dustbin, do not leave the plug lying around where children might see it.

CONNECTION/PREPARATION


In the box

Inside this package you should have:

Television, Remote control, User guide, AAA batteries x 2

Read these instructions before use.

Connecting the aerial and the mains cable



Plug the cable of the outdoor or indoor aerial (passive or active indoor aerial with its own power supply) into the aerial socket »T« of the television set.

Please note:

When connecting an indoor aerial, you may have to try it out at different positions until you get the best reception.

Connect the TV mains plug into your domestic mains socket outlet. (230V 50Hz A.C.)

Please note:


Only plug the TV into the mains socket after you have connected the external equipment and the aerial.

Inserting batteries into the remote control

Open the battery compartment by removing the lid.

Insert the batteries (Mignon type, for example UM-3 or AAA, 2x1,5V). Observe the polarity (marked on the base of the battery compartment).

Close the battery compartment.



Note:


If the television no longer reacts properly to remote control commands, the batteries may be flat. Be sure to remove used batteries. The manufacturer accepts no liability for damage resulting from used batteries.

Environmental note

Batteries, including those which contain no heavy metal, may not be disposed of with household waste. Please dispose of used batteries in an environmentally sound manner. Find out about the legal regulations which apply in your area.

Control Unit

Front Panel



General



ON/OFF switch



Stand by (Model dependant)



Stand by indicator

External Connections: (Front or side)



Right audio PHONO (Red)


Left audio PHONO/Mono PHONO (White)

Video PHONO (Yellow)

S-Video connection

Headphone socket

(Model Dependant)




It is used for external subwoofer in 33" televisions

You may wish to connect an audio amplifier or any similar devices to audio out. The output is always the current channel you are watching.



Aerial socket

External connections: (Rear)



AV1 scart



AV2 scart



AV3 scart (Model dependant)



Coaxial output (Model dependant)

CI slot (Model dependant)

This common interface (C.I) slot works with an external module, and for use with top up TV conditional access module and smart card.

Please note

- See the external connections table on next page for available connections depending the size and model of your TV set.
- Do not use Video PHONO and S-Video connections at the same time, otherwise they will effect the picture each other.

External connections table

Picture tube size/type	28" 16:9	29" 4:3
AV1 Scart	STD.	STD.
AV2 Scart	STD.	STD.
AV3 Scart	X	X
Headphone socket	X	X
Audio/Video PHONO	X	X
S-Video socket	X	X
Back Audio Out	X	X
Coaxial Out	X	X
CI Slot	X	X


STD : Standard

X : Model Dependant

Please note:

The Audio/Video PHONO, S-Video and Headphone socket can be placed on the front panel or on the right-hand side of the cabinet depending to the model of your TV.

Remote control



TELEVISION OPERATIONS



Basic functions

Switching on and off

Switch on the television by pressing the »⏻« button on the television set. The device switches to standby mode, and the stand-by indicator will illuminate.

Switch the television on with any »**Numeric button**« or »PR+«, »PR-«.

Press the »⏻« button to switch the television to standby mode.

Completely switch the television off by pressing »⏻« on the television set. This saves electricity.

Selecting channels

Enter single-digit or multi-digit preset channel numbers by pressing »1 ... 0« on the remote control.

– Channels with no stations assigned are ignored.

Press »PR+«, »PR-« to move up and down channels.

Selecting AV channel positions

Use »AV« to select AV channels directly.

Adjusting the volume

Adjust the volume with »VOL-« or »VOL+«.

Muting

Use »⏻« to switch the sound off (mute) and to switch it on again.

9

Selecting stations from lists

You can select stations from various lists (e.g. all stations, favourites).

Press »LIST FAV« to open the station list. The station list »All programmes« appears.

Press »⏪«, »⏩« to select the station and press »OK« to call it up.

– You can switch between the station list and your favourites by pressing »LIST FAV«.

Press »EXIT« to finish the settings.

Picture settings

Select the desired picture setting from »USER«, »SOFT«, »NATURAL« or »RICH« with »SUB«.

– You can alter the »User« picture setting, see the "PICTURE SETTINGS" chapter on page 19.

Sound settings

Press »UPDATE« to select the audio setting »USER«, »MUSIC«, »SPORTS«, »CINEMA« or »SPEECH«.

– You can alter the »USER« audio setting – see the "EQUALIZER" chapter on page 18.

Swap function

Allows you to swap between the program you are watching and the last selected program. i.e. If you were watching Program 1 and change to Program 11, press the »SWAP DOUB« button to go back to Program 1. Press it again to return to Program 11.

PR 01 → SWAP DOUB PR 11 → SWAP DOUB PR 01

SETTINGS

Searching for television stations

The television is equipped with an automatic station search system. You can start the search and can then sort the television stations into your order of preference. There are 899 preset positions for digital stations and 100 for analogue stations, to which you can assign television stations from the aerial or from the cable connection (analogue programmes).

Switch on the television with **»⓪«** on the television set, then press **»PR+«, »PR-«** on the remote control or the TV, or by using any numeric button on the remote control.



– The **»LANGUAGE«** menu appears when the television is first switched on.

Hint:

If the **»LANGUAGE«** menu does not appear on the screen, follow the instructions on pages 10 and 16 to retune all television channels using the automatic search.

Select language with **»^«, »v«** and press **»OK«** to confirm.



The country menu will now appear. Using **»^«, »v«** select the appropriate country in which the television will be used. Press **»OK«** to confirm selection. Search and storing of analogue channels will begin.


Digital channels will be searched. The search is finished when the message DONE appears. Press **»●«** (Green) to quit the station search.

Press **»EXIT«** to finish the settings.

Tuning digital television stations

Select a program between 1 and 899.

Automatic search



Press **»MENU«** to open the **»MAIN MENU«** menu.
– The **»MAIN MENU«** menu appears.



Select **»DIGITAL SETUP«** with **»^«, »v«** and press **»OK«** to confirm.

– The **»DVB MENU«** appears.

Select **»AUTOMATIC SEARCH«** with **»^«, »v«** and press **»OK«** to confirm.


– The »CHANNEL SEARCH - DIGITAL« menu appears and the search begins. The automatic search may last several minutes depending on the number of television channels received. The search is finished when the message »DONE« appears.


– At the end of the search, new TV or radio stations are automatically added to the end of the station list.




Press »« or »« (Green) to quit the station search. The »DVB MENU« appears.




Press »« to finish the setting.

Manual search



Press »« to open the »MAIN MENU« menu.
– The »MAIN MENU« menu appears.


Select »DIGITAL SETUP« with »«, »« and press »« to confirm.
– The »DVB MENU« appears.


Select »MANUAL SEARCH« using »«, »« and press »« to confirm. – The »MANUAL SEARCH« menu appears.

Press »« or »« to select the channel number and press »« to confirm.
The search begins.

– The search is finished when the message »DONE« appears.


– At the end of the search, new TV or radio stations are automatically added to the end of the station list.


Press »« or »« (Green) to quit the station search. The »DVB MENU« appears.




Press »« to finish the setting.

Resetting the TV

This function enables you to delete the station lists and all custom settings.



Press »« to open the »MAIN MENU« menu.
– The »MAIN MENU« menu appears.

Select »DIGITAL SETUP« with »«, »« and press »« to confirm.
– The »DVB MENU« appears.

Select »RESET RECEIVER« with »«, »« and press »« to confirm.

Use »0« – »9« to enter the password 1234 and confirm with »●« (Green).
 – The »DVB MENU« appears.

Select »AUTOMATIC SEARCH« with »^«, »v« and press »OK« to confirm.
 – The »CHANNEL SEARCH - DIGITAL« menu appears and the search begins. The automatic search may last several minutes depending on the number of television channels received.
 – The search is finished when the message »DONE« appears.

Press »^{BACK}B« or »●« (Green) to quit the station search. The »DVB MENU« appears.

Press »^{EXIT}« to finish the setting.


Installation

Selecting the audio language

You can set a preferred language for all digital channels. This function activates only if the SERVICE PREFERENCE is selected as "SUBTITLE".

In some areas you may be able to select a preferred audio language if it is available in the transmission. You can select from english, gaelic or welsh. If not available english will be automatically selected as the default language.

12



Press »^{MENU}« to open the »MAIN MENU«.
 – The »MAIN MENU« appears.

Select »DIGITAL SETUP« with »^«, »v« and press »OK« to confirm.
 – The »DVB MENU« appears.

Select »INSTALLATION« by pressing »^«, »v« and press »OK« to confirm.
 – The »INSTALLATION« menu appears.


Select the »AUDIO« line with »^«, »v«. Press »<« or »>« to select the language. Press »^{EXIT}« to finish the setting.

Note: Scene-descriptions may be available for some programmes. You can skip between different audio modes by pressing »^{LANG}MIX«.

Selecting the subtitle language

You can select the preferred subtitle language for digital channels. This function activates only if the SERVICE PREFERENCE is selected as "SUBTITLE".

In some areas you may be able to select a preferred subtitle language if it is available in the transmission. You can select from english, gaelic or welsh. To activate subtitle press subtitle (SUBT) button on remote control. If program does not have a subtitle in selected language, no subtitle is displayed even if subtitle display is activated by subtitle button on remote control.



Press »^{MENU}« to open the »MAIN MENU«.
 – The »MAIN MENU« appears.

Select »DIGITAL SETUP« with »^«, »v« and press »OK« to confirm.
 – The »DVB MENU« appears.


Select »INSTALLATION« by pressing »^«, »v« and press »OK« to confirm.
 – The »INSTALLATION« menu appears.

Select »SUBTITLE« with »^«, »v«. Press »<« or »>« to select the language. Press »^{EXIT}« to finish the setting.

Note: Subtitle mode may be selected as on or off via »^{SUBT}P100« button. If is not working, check with »^{SUBT}« that the preset position is on.

Service Preference

You can select the service preference as »DATA SERVICE« or »SUBTITLE« when data service is selected, MHEG (Interactive text) is available if transmission programme has this data. if data service is not selected this function will not operate even if transmission programme, is carrying this data. When subtitles is selected subtitles are displayed in the preferred language selected, if not selected subtitle (SUBT) button on remote control will not work.



MENU
Press »« to open the »MAIN MENU«.

– The »MAIN MENU« appears.

Select »DIGITAL SETUP« with », »« and press »« to confirm.

– The »DVB MENU« appears.

Select »INSTALLATION« by pressing », »« and press »« to confirm.

– The »INSTALLATION« menu appears.


Select »SERVICE PREFERE.« with », »«. Press »« or »« to make the preference.

Press »« to finish the setting.

Data Service

You can select the language for the data service.

In some areas you may be able to select a preferred language for the data service if it is available in the transmission. Therefore the MHEG (Interactive text) data can be displayed in either english, gaelic or welsh. If not available english will be automatically selected as the default language.



MENU
Press »« to open the »MAIN MENU«.

– The »MAIN MENU« appears.

Select »DIGITAL SETUP« with », »« and press »« to confirm.

– The »DVB MENU« appears.

Select »INSTALLATION« by pressing », »« and press »« to confirm.

– The »INSTALLATION« menu appears.

Select »DATA SERVICE« with », »«. Press »« or »« to select the language.

Press »« to finish the setting.

Access control (optional)

You can use the DVB card menu via »ACCESS CONTROL«. After inserting the card to CI slot (Model dependant);

In this menu you can access information on the module and smart card.



MENU
Press »« to open the »MAIN MENU« menu.


– The »MAIN MENU« menu appears.


Select »DIGITAL SETUP« with », »« and press »« to confirm.




– The »DVB MENU« appears.

Select »ACCESS CONTROL« with », »« and press »« to confirm the card.

Signal information



Press  to open the »MAIN MENU« menu.
– The »MAIN MENU« menu appears.


Select »DIGITAL SETUP« with ,  and press  to confirm.
– The »DVB MENU« appears.

Select »SIGNAL INFORMATION« with ,  and press  to confirm.

Notes:

The lower section of the menu shows the signal properties. The further the bar for »Quality« and »Signal Strength« extends to the right, the better the reception signal.


The signal level not only depends on the settings of your receiver unit, but also on the channel which is currently active. Remember this when aligning your aerial using the signal level display.
Other items in this menu are for service information.


Press  to quit the menu.




14


Special features for digital stations

You can block channel positions (adult lock) and create favourite lists.



Press  to open the »MAIN MENU«.
– The »MAIN MENU« appears.

Select »PROGRAM TABLE« with ,  and press  to confirm.



– The menu »EDIT CHANNELS - TV« appears.

Adult lock (block channel positions)


You can block channels which are unsuitable for children.

Select the desired television channel with ,  and confirm with  on the program table.

Select »Adult Lock« with ,  and activate it with  or .

Press  (green) to confirm the setting. The blocked TV station is marked with a key.

Creating a list of favourites



Press **MENU** to open the »MAIN MENU«. The »MAIN MENU« appears.

Select »PROGRAM TABLE« with **UP**, **DOWN** and press **OK** to confirm.

– The menu »EDIT CHANNELS - TV« appears.

You can select your favourite stations and save them in up to four lists.


Select the station with **UP**, **DOWN** and press **1** – **4** to enter it into lists of favourites 1 – 4.

– To remove, press the corresponding number button again.

– You can enter the selected station in more than one favourite list.

Press **EXIT** to finish the settings.

Displaying television and radio channel lists.



Press **MENU** to open the »MAIN MENU«. – The »MAIN MENU« appears.

Select »PROGRAM TABLE« with **UP**, **DOWN** and press **OK** to confirm.

You can skip between favourite channel lists, radio list (if available) and program table by pressing **GREEN** (green).

Radio channels, may be available with digital broadcast. You can skip between radio and television channel list by pressing **RED** (red). Television channels are not display in radio mode.

Selecting and moving channel functions operate similarly to television mode.

Note:

Favourite lists are available if favourite channels are selected.

Moving channels (Favourite channels only)

You can change the order of the preset digital channels in favourite channel list.



Press **MENU** to open the »MAIN MENU«. – The »MAIN MENU« appears.

Select »PROGRAM TABLE« with **UP**, **DOWN** and press **OK** to confirm.

– The menu »EDIT CHANNELS - TV« appears. (If you wish to move radio channels press **RED**). Now press **GREEN** (Green) twice. The yellow “MOVE” option will now appear in the menu.

Select the channel you wish to move with **UP**, **DOWN**. Press **YELLOW** (yellow) to move the channel.

Now, the channel is selected. Choose the new position for the selected channel and press **YELLOW** (yellow) again to confirm. Press **EXIT** to finish the setting.

Note:

The channel is moved to the previous position of the selected one.

TV guide

The electronic TV guide offers an overview of all programmes that will be broadcast in the next week (only for digital stations).





Press »GUIDE« to view the station information.

– Information about the current and following programme appears.

Please note:

Not all stations supply a detailed TV guide.

Many broadcasters supply the daily programme but no detailed descriptions. Some broadcasters do not supply any information.

Scroll through the station information with »«, »«. Select the next programme with »« or »«. Press »EXIT« to quit the TV guide.

16

Tuning analogue television stations

When digital channels are present, the analogue television channels will be assigned to channel positions 900-999 during automatic search and when no digital channels are present the analogue channels will be assigned to channel positions 1-100.

Autoprograming







Use »0« – »9« to select station position 900.


Press »MENU« to open the »MAIN MENU«.



– The »MAIN MENU« appears.

Select »SETUP« with »«, »« and confirm with »OK«.





– The »SETUP« menu appears.

Select »PROGRAM NO« with »«, »« and using »« or »« enter the channel numbers from the point they should be saved.



Select »AUTOPROGRAM« with »«, »« and confirm with »OK«.

– The »COUNTRY SELECTION« menu appears.

Select the country using »«, »« »« or »« and confirm with »OK«.

– The automatic search may last a few minutes, depending on the number of television channels received.

Note:

You can interrupt the search by pressing »EXIT«.

Tuning channels using the search



Use »0« – »9« to select station position 900.

Press »MENU« to open the »MAIN MENU«.
– The »MAIN MENU« appears.

Select »SETUP« with »^«, »v« and confirm with »OK«.
– The »SETUP« menu appears.



Select »Program No« with »^«, »v« and set the preset channel with »<« or »>«.

Select »Search« with »^«, »v« and start the search with »<« or »>«.


– If a strong station signal is received, the search is interrupted and the picture appears. Repeat the search until the channel you want appears on the screen.

Select »STORE« with »^«, »v« and confirm with »OK«. The »STORED« message appears.

Press »EXIT« to finish the setting.

Fine tuning analogue television stations

The television automatically tunes itself to the best possible reception. You may need to carry out manual fine tuning in areas where there is poor reception.



Press »MENU« to open the »MAIN MENU«.
– The »MAIN MENU« appears.


Select »SETUP« with »^«, »v« and confirm with »OK«. The »SETUP« menu appears.

Select »FINE TUNE« with »^«, »v« and set it with »<« or »>«.

Select »STORE« with »^«, »v« and confirm with »OK«. The »STORED« message appears.

Press »EXIT« to finish the setting.

Tuning the analogue television channels by entering the channel numbers



Use »0« – »9« to select station position 900.

Press »MENU« to open the »MAIN MENU«.

– The »MAIN MENU« appears.

Select »SETUP« with »UP«, »DOWN« and confirm with »OK«.

Select »PROGRAM NO« with »UP«, »DOWN« and set the channel with »LEFT« or »RIGHT«.

Select »Channel« with »UP«, »DOWN« and confirm with »OK«. Press »OK« to choose between »S« (cable channel) and »C« (terrestrial channel). Press »LEFT« or »RIGHT« to switch up and down channels or use »1...0« to enter the channel number directly.

Select »STORE« with »UP«, »DOWN« and confirm with »OK«.

Press »EXIT« to finish the setting.

18

Moving to digital setup menu



Press »MENU« to open the »MAIN MENU«.

– The »MAIN MENU« appears.

Select »SETUP« with »UP«, »DOWN« and confirm with »OK«.


Select »DIGITAL SETUP« with »UP«, »DOWN«.

The »DVB MENU« with appears.

Special features for analogue stations

You can delete stations that have been stored more than once during the automatic search. You can also store stations in a different preset position, change or enter the name of a stations as well as skip channels.

Deleting stations



Press »MENU« to open the »MAIN MENU«.

– The »MAIN MENU« appears.

Select »PROGRAM TABLE« with »UP«, »DOWN« and press »OK« to confirm.

– The »PROGRAM TABLE« menu appears.

Select the channel you wish to delete with »UP«, »DOWN«.


Press »OK« (blue) to prepare the channel for deletion and press »OK« to delete.


Sorting television analog stations

In the »PROGRAM TABLE« menu, select the station to be moved by pressing »UP«, »DOWN«. Highlight the channel with »OK«.

Select a new station with »UP«, »DOWN« and then press »OK« to confirm. All of the stations that follow move up one position.


Sound settings



Press  to open the »MAIN MENU«.
– The »MAIN MENU« appears.

Select »SOUND« with ,  and confirm with .

– The »SOUND« menu appears.




Volume

The standard volume is set here. This is the volume of the television after switching on.

Select »VOLUME« with ,  and adjust the setting with  or .

Balance

Select »BALANCE« with ,  and adjust the setting with  or .



Sound type

If the device receives two channel programmes, e.g. a film with the original sound on sound channel B (display: »Dual II «) and the dubbed version on sound channel A (display: »Dual I«), you can select the sound channel you desire.

If the device receives stereo or Nicam programmes, it switches automatically to stereo sound (display: »Stereo«). You can switch the sound to »Mono« if the stereo reception quality is poor.

Select »SOUND TYPE« with ,  and adjust the setting with  or .

Sound mode

You can select NORMAL, SPATIAL or DOLBY VIRTUAL (optional) with  or .

SPATIAL sound is an ‘expanded stereo’. It gives the impression that the two speakers in the TV are further apart than they really are.

DOLBY VIRTUAL is based on Dolby Pro Logic decoding for production of the Left, Right, Centre and Virtual Surround Sound channels using two loudspeakers.

Manufactured under license from Dolby Laboratories. “Dolby”, “Pro Logic” and the double-D symbol are trademarks of Dolby Laboratories.

Please Note

To get the surround effects in Dolby Virtual mode, you must apply a Dolby Surround encoded input to the TV. You can’t adjust the AVL and EQUALIZER in DOLBY VIRTUAL mode.

Automatic volume levelling





The television channels broadcast at different volumes. The automatic volume levelling (AVL) function means the volume is kept the same when you switch between channels.

Select »AVL« with »«, »« and then select »On« with »« or »«.

Dynamic bass (Model dependant)



You can amplify the bass-effect using this setting.





Select »DYNAMIC BASS« with »«, »« and then select »ON« with »« or »«.

Subwoofer (Model dependant)

A sub woofer speaker can be fitted within the TV case as an option depending to the model. For 33" (84cm) TV sets there is an external subwoofer (optional) to be fixed as shown below.







Select Sound menu and press »« button to access subwoofer. Press the »« button to switch the Subwoofer on or off.


Please Note




If you move the loudspeaker switch, on the rear of the TV, to the external position, the internal speakers in the TV will be switched off but the Subwoofer will remain on if switched on.




Equalizer






The equalizer offers you four preset sound settings (Music, Sports, Cinema and Speech) and one which you can create yourself (User). Select »EQUALIZER« by pressing »«, »« and use »« or »« buttons to change the equalizer mode.

For changing user settings;




Select »EQUALIZER« by pressing »«, »« and press »« to confirm.
– The »EQUALIZER« menu appears.

Select the »User« audio setting using »«, »« and press »« to confirm.
– The »0.1« frequency band is activated.

Set the value using »«, »« and select the next frequency band by pressing »« or »«. Press »« to save the setting.

Press »« to finish the settings.

Picture settings



Press to open the »MAIN MENU«.

- The »MAIN MENU« appears.

Select »PICTURE« with , and confirm with .

- The »PICTURE« menu appears.


Select »BRIGHTNESS«, »CONTRAST«, »COLOUR« or »SHARPNESS« with , and adjust them with , . Press to finish the settings.

Note:

After a short while the »PICTURE« menu reappears. The settings are saved as the »USER« picture default setting.

22

Setting the picture features



You can set the noise suppression of the picture. You can set the noise suppression to one of three settings: »NORMAL«, »WARM« and »COOL«.

Press to open the »MAIN MENU«.

- The »MAIN MENU« appears.

Select »PICTURE« with , and confirm with .

- The »PICTURE« menu appears.

Select »COLOUR TEMPERATURE« with , and set the desired value with , . Press to finish the settings.

CTI (Colour Transient Improvement):

You can improve the colour transitions in the picture by selecting ON or OFF.

DDVa (Model dependant) (Dynamic Digital Video Adaption):

You can increase the picture sharpness by selecting DDVa as ON.


IMPORTANT NOTE: Your TV has Digital Comb Filter, DLTI (Digital Luminance Transient Improvement) features to improve picture quality. These features are set ON and they can not be changed by the end user.

TILT (Model dependant):

Because of the structure of the picture tubes, your picture can be lost on the corners of the screen depending on the position of your TV, north-south-east-west.

To clear this effect, you can adjust the TILT setting and prevent the picture loss (Model dependant).

SPECIAL FEATURES



Press »^{MENU} « to open the »MAIN MENU«.
– The »MAIN MENU« appears.

Select »FEATURES« with »[^]«, »^v« and confirm with »^{OK}«.
– The »FEATURES« menu appears.

Changing the menu language

You can change the language of the OSD menu.




Select »LANGUAGE« with »[^]«, »^v« and confirm with »^{OK}«.
– The »LANGUAGE« menu appears.

Select the language with »[^]«, »^v« or »[<]«, »[>]« and press »^{OK}« to confirm.

Press »^{EXIT} « to finish the setting.

23

Entering the switch-on and off times



A switch-on and off timer can be set in the »Date&Time settings menu«. After this time has elapsed, the television switches to standby mode or switches on from standby mode. You can enter the channel with which the television should switch on in »Program«.

Select »DATE & TIME SETTINGS« with »[^]«, »^v« and confirm with »^{OK}«.

Select »DATE«, »CLOCK«, »ON TIME«, »OFF TIME«, »ALARM TIME« or »PROGRAM NO« with »[^]«, »^v«.

Enter the switch-on or off time and the channel with »1...0«.
Press »^{EXIT} « to finish the setting.

Date: Use the numeric buttons to set the real date.

Clock: Use the numeric buttons to set the real time.

On Time: Use the numeric buttons to set the time that you want your TV to be turned on (TV should be on stand-by mode).

Off Time: Use the numeric buttons to set the time that you want your TV to be turned off (Stand-by mode).

Alarm Time (Model dependant): Use the numeric buttons to set the alarm time that you want your TV to alarm.

Program No: Use the numeric buttons to set the programme number that will be shown when you set the **On Time**.

Picture format

This allows you to select the picture size on corresponding to the screen type of your TV: Available formats for widescreen TV sets are 16:9, 4:3, Zoom, Letterbox, Subtitle and Panaroma. Available formats of 4:3 TV sets are 4:3 and 16:9.

The formats of the broadcasts (4:3 or 16:9) you watch by means of aerial input are chosen automatically. (4:3, 16:9 and Letterbox for 16:9 TV) This feature is active if the channel you are watching sends WSS (Wide Screen Signalling) information.


Note: The feature mentioned above is relevant for TV sets having teletext.

Widescreen TV sets:


16:9, this is the screen format of widescreen TV sets (28" SF/PF, 32" SF/PF). The TV will automatically switch to this format if it detects 16:9 format from the SCART inputs.

24

16:9




4:3




4:3, conventional TV picture format.

Zoom



Zoom, an enlarged 4:3 format retaining the same aspect ratio.



LetterBox



L Box (Letter box), Useful for watching video, some film formats and Pal-Plus format.

4:3 Sets:

4:3, is the screen format of 28", 29" and 33" TV sets But you can change the picture format to 16:9 to able to watch the inputs in 16:9 format, i.e. some broadcasts and DVD's.



16:9

Press the »^{REV}« button to page through the different picture formats and select the one you want. The selected format will appear on the lower center of the screen for a short while.

Once you have switched the TV off the picture format will revert to the stored setting.

TELETEXT MODE

Teletext is an information system that displays text on your TV screen. Using the teletext control buttons you can view pages of information that are listed in the teletext index.


Please Note

No on screen display is available in text mode. The contrast, brightness and colour cannot be changed but the volume control is still available.


To enter Text mode

Please Note

Make sure the TV channel you are watching transmits teletext.

Press the »« button. The text page will appear, normally the index page.


To exit Text mode


Press the »« button. The TV will return to the channel you were watching.


To select a page of text

Find the number of the page in the index and enter it using the »1...0« buttons. The number of the page will appear in the top left hand corner of the screen.


The page counter will search for your page. When it finds it, the page will be displayed.

To move to the next page of text press the »« button.

To move to the previous page press the »« button.

To return to the index page press the »P100« button.

TV/text mix

To view a page of text whilst watching a TV programme press the »« button. The text will be superimposed over the TV programme.

Press the »« button again to return to the text page.

Page search whilst watching TV

In Text mode press the Update button. The TV will return to TV mode with the text page number in the top left hand corner of the screen.

Enter the page number you want using the »1...0« buttons.

The top line of the text page will appear whilst the text searches for your page. When the page is found the number will remain in the top left hand corner of the screen.

Press the »« button to view your selected page of text.

Double height text

If you have difficulty reading the text on the TV you can double the height of the text.

Press the »« button. The top half of the page will be displayed in double height text.

Press the »« button again.



The bottom half of the page will be displayed in double height text.


Press the »« button again to return to the full page.

TELETEXT MODE

Page hold


If the page of text you have selected contains sub pages, these sub pages will automatically be displayed in order with a delay to allow you to read the page.

To stop the move to the next sub page press the »  « button. STOP will appear in the  top left hand corner.


To continue moving through the sub pages press the »  « button again.

To select a sub page

If the page of text you are viewing contains sub pages, the number of the sub page you are on and the total number of sub pages is displayed on the right of the screen i.e. 1/7.

To select a sub page press the »  « button. The page number and subpage number will display at the bottom of the screen.


Enter the number of the sub page, using the » **1...0** « buttons in the format 0001 for sub page 1.


The teletext will search for the sub page. This may take some time. To return to the TV whilst the teletext is searching press the »  « button.

When the page number is found it will appear in the top left hand corner of the screen.

Press the »  « button again to view the text page.

To reveal information

Press the »  « button to reveal concealed information (quiz answers etc.).

Press the »  « button again to conceal the information again.

Fastext

At the bottom of the teletext screen is a row of subject headings in red, green yellow and blue.

The remote control has a row of coloured buttons corresponding to the row of coloured subjects on the screen. Pressing one of the coloured buttons will take you directly to the page corresponding to the subject heading.

Toptext (Model Dependant)

At the bottom of the teletext screen is a row of subject headings in yellow and blue. Pressing yellow or blue buttons on the remote control, selects the related Subject. Next page can be selected by pressing the red button and previous page can be selected by pressing the green button.


Note: Fastext and Toptext features are not available in every program.

Connecting external equipment

Headphones (Model Dependant)

The headphones must have an impedance of between 8 and 32 ohms and have a 3.5 mm stereo jack plug.

Plug the headphone jack into the headphone socket of the TV.


To activate headphone sound, press the mute “” button on the remote control (a mute symbol will appear on the screen) and adjust headphone volume by using the **VOL+** on **VOL-** buttons on the remote control or front panel of the television.

Connecting a video recorder

① Via SCART

Make sure the TV and video recorder are both switched off.

Plug one end of the SCART lead (not supplied) into the back of the video recorder and the other end into one of the SCART sockets on the back of the TV. Switch on the video recorder and the TV.

Press the »« button on the remote control to select AV1, AV2 or AV3 (Model dependant) to correspond with SCART socket you are using on the back of the TV.

Please note:


You can connect a RGB external equipment via Scart 1. It is necessary to you use full Scart cable for this purpose.

Select the video outputs of external device by using its menu to RGB if it's available.

② Via PHONO lead (Not supplied)

Make sure the TV and video recorder are both switched off.

Plug one end of the PHONO lead into the video and audio out sockets on the back of the video recorder and plug the other end into the video and audio in sockets of the TV. If the sound is in mono use the Audio Input L. In the SOUND menu select MONO.

Press the »« button repetitively and select the AV3 mode for two scart models or select AV4 mode for three scart models.

③ Via aerial socket

Make sure the TV and video recorder are both switched off.

Unplug the aerial lead from the TV and plug it into the aerial socket on the video recorder (if fitted). Plug a coaxial plug into the RF out socket on the rear of the video recorder and plug the other end into the aerial socket of the TV. Switch on the video recorder and the TV. If your video recorder has a test signal, switch it on. (Refer to the video recorder user guide). See 'Tuning the TV' and carry out the tuning procedure for the video recorder test signal. Select a programme number 0 or between 55 and 99.


④ S-Video Player

If you have an S-Video player you can connect it to SCART socket 2 via an adaptor from scart to S-Video/PHONO audio (not supplied). Press the »^{AV}« button three times to select AV2S (available for two scart models).

⑤ Via PHONO lead and S-Video socket

You can also connect it through the S-Video socket of the TV (Model dependant). Plug the S-Video plug into the S-Video socket and the audio leads into the audio sockets. Press the »^{AV}« button repetitively to select AV3S for two scart models or AV4S for three scart models.

28



Connecting a DVD player

① Via SCART


Make sure the TV and DVD player are both switched off. Plug one end of the SCART lead (not supplied) into the back of the DVD player and the other end into one of the SCART sockets on the back of the TV. Switch on the DVD and the TV. Press the » **AV** « button on the remote control to select AV1, AV2 or AV3 (Model dependant) to correspond with SCART socket you are using on the back of the TV.

② Via PHONO lead (Model Dependant)

Make sure the TV and DVD player are both switched off. Plug one end of the PHONO lead into the video and audio out sockets on the back of the DVD player and plug the other end into the video and audio in sockets of the TV. Press the » **AV** « button repetitively and select the AV3 mode for two scart models or select AV4 mode for three scart models.

③ Via PHONO lead and S-Video socket

You can also connect it through the S-Video socket of the TV (optional). Plug the S-Video plug into the S-Video socket and the audio leads into the audio sockets. Press the » **AV** « button repetitively to select AV3S for two scart models or AV4S for three scart models.



Connecting a decoder

① Via SCART

Make sure the TV and decoder are both switched off. Plug one end of the SCART lead (not supplied) into the back of the decoder and the other end into the SCART1 on the back of the TV. Switch on the decoder and the TV. Press the » **AV** « button on the remote control to select AV1.

② Via PHONO lead (Model Dependant)

Make sure the TV and decoder are both switched off. Plug one end of the PHONO lead into the video and audio out sockets on the back of the decoder and plug the other end into the video and audio in sockets on the TV.

AV




Press the » **AV** « button repetitively and select the AV3 mode for two scart models or select AV4 mode for three scart models.


30

Please Note


You can record from one external piece of equipment to another via the TV by connecting the playback to SCART 1 and the recorder to SCART 2 or SCART 3 and selecting AV1. You cannot watch the TV.

You can connect NTSC supported equipment to the TV via the SCART sockets and adjusting the colour via the PICTURE menu.


Select TINT by using »  « button and use the adjust the colour to »  « or »  « buttons.




Connecting TV with video and satellite/digital receiver



Connecting TV with camcorder



Connecting TV games and computer



Troubleshooting

Symptom	Possible cause	Solution
Screen lit, but no station	Aerial cable	Is the aerial cable connected?
	No television station programmed	Start the station search
Poor picture contrast	Picture settings incorrectly set	Adjust the brightness, contrast or colour setting
	Problem at station	Test with another channel
Interference	Interference from other devices	Change the position of the device
Ghosts, reflection	Channel setting	Automatic or manual channel setting/fine tuning
	Aerial	Have aerial cable or system checked
No colour	Colour intensity at minimum	Turn up the colour
	TV standard setting (if setting option is available)	Select the correct colour standard
	Problem at station	Test with another channel
Inappropriate colour, colour spots	Strong magnetic field due, for example, to loudspeakers	Move the loudspeakers away from the television. If colour spots remain, switch off the television set at the mains and switch on again after 10 minutes
Picture but no sound	Volume set to minimum	Turn up or switch on the volume
	Problem at station	Test with another channel
Teletext missing or faulty	Television station (has no teletext) or aerial system	Test another channel for fine tuning and ghosts
	Station signal too weak	Check the aerial system
Remote control does not work	No optical connection	Point the remote control at the television set
	Remote control batteries	Check the batteries, change if necessary
	Operating condition undefined	Switch off the television with the main power button for approximately 2 minutes
Some channels are not present when using PR+ or PR- buttons.	Parental lock has been activated	Switch off the parental lock
No Text on Digital Channels	Station is not transmitting text information	Check another channel
	Incorrect setting in installation menu	Enter the main menu followed by digital setup option and select installation. Set service preference to "data service"
No Subtitles	Station is not transmitting subtitle information	Check another channel
	Incorrect setting in installation menu	Enter the main menu followed by digital setup option and select installation. Set service preference to "subtitles"
	Subtitles features is not activated	Press subtitle button (SUBT) on remote control to turn on subtitles
Spinning egg timer logo seen on screen when switching television on in digital mode	Normal operation. During this short period the digital board is being initialised	This is not a fault

Technical specifications table

Picture tube size/type	28" 16:9	29" 4:3
Screen size	70 cm	72 cm
Visible screen size	66 cm	68 cm
Sound Output (%10 THD)	2x10 W	2x10 W
Power consumption	100 W	105 W
Stand by Power consumption	4 W	4 W
Subwoofer	X	X
Dolby Virtual	X	X

X : Model Dependant
16:9: Widescreen TV
4:3 : Conventional TV

Please note:

Using a subwoofer (Model dependant) causes 20 W extra power consumption and supplies maximum 20 W extra sound output.

General technical specifications

Power Supply

AC: 230Va.c 50Hz

Number of preset programmes 100 analog 899 digital

RF Aerial input 75 ohm (unbalanced)

Speaker impedance 8 ohm

Audio output Stereo/NICAM (Model dependant)

Batteries 2x AAA

Receiving channels VHF (Band I Channels 2-4)

..... VHF (Band III Channels 5-12)

..... UHF (Channels 21-69)

..... Cable TV (S1-S20/S21-S41)


Receiving broadcast system..... PAL BG

PAL SECAM BG

PAL SECAM BG DK/DK´

PAL SECAM BG LL´

PAL I



Environmental note

This product has been made from high-quality parts and materials which can be re-used and recycled. Therefore, do not throw the product away with normal household waste at the end of its life. Take it to a collection point for devices. This is indicated by this symbol on the product, in the operating manual and on the packaging.

Please find out about collection points operated by your local authority.
 Help protect the environment by recycling used products.



Guarantee - Television

Your new television is guaranteed against the cost of breakdown repairs for twelve months from the date of the original purchase. (* see note below for small screen sets)

What is covered?

- All repairs necessary as a result of faulty materials, defective components or manufacturing defect.
- The cost of all functional replacement parts, excluding remote control batteries
- The labour costs of a Beko approved repairer to carry out the repair.
- (*) For TV's with screen sizes of 21 inches or less (measured diagonally corner to corner) you may be offered a replacement instead of repair under guarantee. Your dealer will advise you.

What is not covered?

- Transit or delivery damage
- Accidental damage
- Misuse, or abuse.
- Cabinet or appearance parts, including knobs and flaps
- Remote control batteries.
- Repairs or replacements required as a result of unauthorised repairs or inexperienced installation that fails to meet the requirements contained in the user instruction book.
- Repairs or replacements to product installed or used on commercial or non-household premises.

Important notes.

- The product is guaranteed for domestic household use only.
- The guarantee will be void if the product is installed or used in commercial or non-household premises.
- The product must be correctly installed and operated in accordance with the instructions contained within the Operating Instructions Booklet provided with the product
- The guarantee is given only within the boundaries of the United Kingdom and the Republic of Ireland.
- The guarantee is not transferable if the product is resold.
- Beko Plc disclaims any liability for incidental or consequential damages.
- The guarantee does not in anyway diminish your statutory or legal rights.

Beko House, Caxton Way, Watford, Herts, WD18 8UF, Tel: 0870 241 0128



HOW TO OBTAIN SERVICE

Congratulations on your choice of a Beko colour television. Your new television has been designed and manufactured to the highest quality standards to give you many years of use. To get the best out of it, please take a few moments to read the instruction book.

Your television is supplied with a full 12 months guarantee, covering parts and labour. Should you require service under guarantee, simply call the number below (**see note for small screen sets)

0870 241 0128

Our service receptionist will ask you for your product model number, your retailer's name, and the date of purchase when you call. It will assist you if you complete the box at the bottom of this page when you take delivery of your television so that the information is readily available should you need it. If it is necessary for an engineer to visit your home he will normally be there within 48hrs of receipt of your call (excluding Bank Holidays) or at your earliest convenience.

Before telephoning for service please check the trouble shooting guide in the instruction book as often minor problems are easily identified and resolved by following the instructions contained therein. Service visits where there is no fault with the product could incur a charge even though the product is under guarantee.

Service is also available on the above number after the guarantee period has expired. The cost of any repairs outside of the guarantee period is payable to the engineer at the time of visit .

Please complete the box below for ease of reference later.

Model Number	Serial Number
Date of Purchase	Place of Purchase
Please keep your purchase receipt. The engineer will need to see it should you require service under the 12-month Guarantee.	

***** Special Note:**

In home repair service is not available on models with a screen size of 21" or under. You should contact your retailer for advice and assistance on these models.

ADW.801