











2 × 12



| | | |
|--|--|--|
| (D) Montageanweisung | 1 - 27 Arbeitsfolge | 220/230 V~ 3,2/3,4 kW |
| (CH) Montageanweisung | BZ 9 (S) Instr. Nr. CH G 51 1 - 27 Arbeitsfolge | 380/400 V 2 N~ 3,2/3,4 kW 220/230 V~ 3,2/3,4/2,0/2,1 kW |
| (GB) Assembly Instructions | 1 - 27 Procedure | 240 V~ 13 A 2,9 kW |
| (F) Instructions de montage | 1 - 27 Ordre des Opérations | 220/230 V~ 3,2/3,4 kW |
| (I) Istruzioni per il montaggio | 1 - 27 Sequenza di lavoro | 220 V~ 2,5 kW |
| (NL) Montage-Voorschriften | 1 - 27 Volgorde van werken | 220/230 V~ 3,2/3,4 kW |
| (DK) Monteringsvejledning | 1 - 27 Arbejdsrække- følge | 380/400 V 2 N~ 3,2/3,4 kW 220/230 V~ 3,2/3,4/2,0/2,1 kW |
| (P) Instruções de montagem | 1 - 27 Sequência das operações | 220/230 V~ 3,2/3,4 kW |
| (E) Instrucciones de montaje | 1 - 27 Operaciones a realizar | 220/230 V~ 3,2/3,4 kW |
| (S) Monteringsanvisning | 1 - 27 Arbetsgång | 220/230 V~ 10 A 2,0/2,1 kW |
| (N) Montasjeveiledning | 1 - 27 Rekkefølge for montering | 220/230 V~ 10 A 2,0/2,1 kW |
| (SF) Assennus ohjeet | 1 - 27 Työnkulku | 220/230 V~ 10 A 2,0/2,1 kW |
| (GR) Οδηγία συναρμογής | 1 - 27 Ρυθμός λειτουργίας | 220/230 V~ 3,2/3,4 kW |
| (TR) Yerleştirme talimatı | 1 - 27 Kurulum sırası | 220/230 V~ 3,2/3,4 kW |
| طريقة التركيب (عربي) | 1 - 27 دورة التشغيل | 220/230 V~ 3,2/3,4 kW |







1739 986 060 (6812)

37x0005

