explore beyond limits™

Acer Electronic Projection Screen

User's Manual

Electronic Projection Screen_A4.indd 1 2014/5/22 下午4:01

Acer Electronic Projection Screen
User Guide

1. The Control Box has one control cord and one power cord. Connect control cord to the right side position (hole) of top screen bar (# illustration A). Then, connect to power cord (# illustration B) to a suitable power supply. Press "DOWN" button on Control Box to make the screen in downward direction (# illustration C) and press "STOP" button to stop at any position you want.

2. To store the screen, press "UP" button on Control Box to make the screen in upward direction (# illustration D).

Note 1: The screen can be operated by either Control Box or remote control, and just press the UP/DOWN/STOP button to adjust the screen directly.

Note 2: The screen can be installed by either wall mounted or ceiling mounted.