





Step 1

Masonry Walls or Cement Walls

Drill a hole at the marked position with an electric drill and drilling bit.

Step 2

Stud Walls

Step 3

Step 4

Step 5

Step 6

Step 7

Step 8

Step 9

Step 10

Step 11

Step 12

Wall Mount Tilt Angle

Projector Tilt Angle

Horizontal Lateral move

Knob B Yellow

Knob C Black