

## **Systemerweiterung für den SCENIC E, SCENIC N, SCENIC P, SCENIC W**

Wie Sie das Wireless LAN-Modul einbauen, ist in der Betriebsanleitung Ihres Systems beschrieben. Diese Betriebsanleitung finden Sie als PDF-Datei auf der mitgelieferten CD "User Documentation" oder "Drivers & Utilities". Hinweise zur Wireless-LAN-Software finden Sie ebenfalls auf der CD.

### **Einbauhinweise für den SCENIC E**

Bauen Sie das Wireless LAN-Modul anstelle des Diskettenlaufwerks ein. Gehen Sie vor, wie im Kapitel "Diskettenlaufwerk tauschen" beschrieben. Stecken Sie die USB-Leitung auf dem Mainboard.

## **System extensions for the SCENIC E, SCENIC N, SCENIC P, SCENIC W**

How to install the wireless LAN module is described in the Operating Manual of your system. The Operating Manual is provided as PDF file on the "User Documentation" or "Drivers & Utilities" CD. Information on the wireless LAN software can also be found on the CD.

### **Installation information for the SCENIC E**

Install the wireless LAN module instead of the floppy disk drive. Proceed as described in the chapter "Replacing the floppy disk drive". Connect the USB cable to the mainboard.

## **Extension système pour les SCENIC E, SCENIC N, SCENIC P, SCENIC W**

Le montage du module Wireless LAN est décrit dans le manuel d'utilisation de votre système. Vous trouverez le manuel d'utilisation au format PDF sur le CD "User Documentation" ou "Drivers & Utilities". Vous trouverez également sur le CD des informations sur le logiciel Wireless LAN.

### **Instructions de montage pour le SCENIC E**

Montez le module Wireless LAN à la place du lecteur de disquettes. Procédez comme décrit au chapitre "Remplacer le lecteur de disquette". Branchez le câble USB sur la carte mère.

## CE marking



### CE marking for devices with radio component

This equipment complies with the requirements of Directive 1999/5/EC of the European Parliament and Commission from 9 March, 1999 governing Radio and Telecommunications Equipment and mutual recognition of conformity.

This equipment can be used in the following countries:

Belgium	Denmark	Germany	Estonia
Finland	France	Greece	UK
Ireland	Iceland	Italy	Latvia
Liechtenstein	Lithuania	Luxemburg	Malta
Netherlands	Norway	Austria	Poland
Portugal	Sweden	Switzerland	Slovakia
Slovenia	Spain	Cyprus	Hungary
Czech Republic			

Contact the corresponding government office of the respective country for current information on possible operating restrictions. If your country is not included in the list, then please contact the corresponding supervisory authority as to whether the use of this product is permitted in your country.



You will find the Declaration of Conformity for this device as a PDF file in the "Wireless LAN" manual on the "User Documentation" CD or in the Internet under <http://manuals.fujitsu-siemens.com>.



A26361-F3108-Z170-1-6319