

Warranty Service

This warranty gives you specific legal rights and you may also have other rights that vary from state to state. Some states do not allow the exclusion limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so that the above limitations and exclusions may not apply to you.

For questions or comments, please write:

Remington Products Company, L.L.C. 50 Commerce Drive Trumbull, CT 06611-5403 Attn: Customer Service

Remington Products (Canada) Inc. 61 Amber Street Markham, Ontario Canada L3R 3J7 Attn: Consumer Affairs

U.S. Warranty Service

In the United States, service is provided by our Company-owned Service Centers and over 300 Authorized Service Dealers. For the address of your nearest authorized Service Dealer, please consult the Yellow Pages under "Shaver-Electric-Repair". If you wish, you may mail the product, postpaid, to Remington Products Company, L.L.C., 60 Main Street, Bridgeport, CT 06604, Attention: Service Department.

International Warranty Service

Service under the Remington warranty can be obtained outside the United States by Remington-authorized Distributors and Service Dealers. Please consult your local telephone directory for the nearest location.

Questions or Comments: Please call 800-736-4648 in the U.S. or 888-277-6333 in Canada.



Visit us at www.remington-products.com

Remington and Precision are trademarks of Remington Corporation, L.L.C. in the U.S. Remington is a trademark of Remington Corporation, L.L.C. in Canada. © 2002 R.P.C., L.L.C. Job #G02-025 9/02 Part No. 13757

NE-1 - US Patent D457,984; Canadian Patent 94,170. NE-3 - US Patent D455,229; Canadian Patent 94,169. NE-4 - US Patent D455,863; Canadian Patent 94,168.

Remington Products Company, L.L.C. 60 Main Street Bridgeport, CT 06604

Remington Products (Canada) Inc. 61 Amber Street Markham, Ontario L3R 3J7

MADE IN CHINA

Performance Guarantee

Remington® Money-Back Offer

You have just bought one of the finest trimmers available today. If for any reason, within 30 days of the purchase of your Remington Precision Trimmer, you are not satisfied and would like a refund, just return your product, together with the sales receipt to the retailer from whom you purchased it. Remington will reimburse all retailers who accept the product within 30 days of purchase. If you have any questions regarding the money back guarantee, please call 1-800-736-4648 in the United States or 888-277-6333 in Canada.

Full Two-Year Warranty

Remington warrants that your product, except as noted below, is, on date of purchase, free from defect in material and workmanship. Remington will correct any such defect without charge if you return the complete product either in person or by mail, postage paid, to a Remington company-owned Service Center or Authorized Service Dealer within two years after the date of purchase with original receipt.

Do not return this product to the retailer from whom the product was purchased.

This warranty does not cover damage by accident, misuse, abuse, or by affixing an unauthorized accessory or alteration to the product, or by connection of the product and adapter to any but the specific current and voltage indicated the instruction booklet, or by any other conditions beyond our control.

No responsibility, obligation, or liability is assumed for the installation or maintenance of this product. Warranty service must be performed by a Remington Company-owned Service Center or Authorized Service Dealer and damage or loss of any kind resulting from servicing by any other person is not covered under warranty. Enclosed is a listing of Company-owned Service Centers. Authorized Service Dealers may be found in the yellow pages of your directory. If you wish, you may mail the product postpaid to Remington Products Company, L.L.C., 60 Main St., Bridgeport, CT 06604 Attention: Service Department or Remington Products (Canada) Inc, 61 Amber Street, Markham, Ontario, L3R 3J7.

REMINGTON SHALL NOT BE RESPONSIBLE FOR ANY INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES. IN ADDITION THIS WARRANTY DOES NOT COVER THE TRIMMER BLADES.

All implied warranties including but not limited to implied warranties of fitness and merchantability, are limited in duration to two years from date of original purchase.

Use & Care Guide

REMINGTON

precision Nose & Ear Trimmers



NE-1 Linear



NE-3 Rotary Washable/Bendable



NE-4 Washable Linear

Model NE-1, NE-3, NE-4

IMPORTANT SAFETY INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USING.

WARNING

To reduce the risk of burns, fire, electric shock, or injury to persons:

- Do not use this appliance with a damaged or broken cutting unit, as injury may occur.
- Close supervision is necessary when this appliance is used by, on, or near children or invalids.
- This trimmer is designed for household use only. Do not use attachments not recommended or authorized by Remington Products Company, L.L.C.
- Always store your trimmer in a moisture-free environment. Do not store trimmer in temperatures exceeding 130°F/54°C.
- Always remember to turn on the trimmer before you insert it into your nose or ear to avoid painfully snagging hairs.
- Never insert the trimmer more than 1/4" (6mm) into nose or ear. Foreign objects should not come into contact with the ear drum.

SAVE THESE INSTRUCTIONS

Your New Trimmer

TO INSERT BATTERIES

- Rotate the battery compartment cap approximately one quarter turn then pull off (Figure 2).
- Insert one "AA" ALKALINE battery. Label on inside of battery compartment shows proper direction to insert battery in the unit.
- Place cap back on unit in same position as removed and rotate clockwise until the cap snaps into place, and markings align.




Figure 2

Use of any batteries other than alkaline will negatively affect the unit's operating performance. Batteries should not be left in the unit, if the unit is not in use for long periods. To prevent battery corrosion the unit should be kept in a dry environment. Dead batteries should be removed immediately and disposed of properly. Do not use batteries that have been recharged with this unit. The lower voltage in recharged batteries impairs the performance of the cutting unit.

The upper body of Model NE-3 can flex for added comfort in use. With the switch facing you, tilt the top half forward or backward as desired up to 30° in either direction.

Cleaning and Maintenance

Maintaining Your Trimmer

Your Remington® Wet/Dry Nose & Ear Trimmer is designed to give you years of comfortable use. To ensure that you get optimal performance from your trimmer, follow these maintenance tips:

- Clean your trimmer between uses.
- Lubricate the trimmer lightly every six months.

Cleaning Your Trimmer (All Models)

- After each use, brush or blow accumulated hair from the cutting unit.

Rinsing your Trimmer (NE-3 & 4 models only)

- After use, rinse the cutter head under the faucet with cool or warm water. It is not necessary to remove the cutting head. Do not use hot water.
- If the trimmer needs additional cleaning, the cutting head can be removed by rotating it approx. 1/8" turn and pulling it off. Blow out accumulated hair or rinse more thoroughly under running water.
- Shake excess water from the cutter head, making sure that all parts are held together.
- Replace the cutter in the same position as it was removed, rotating it clockwise 1/8 turn to lock it into place.
- After rinsing, apply a drop or two of mineral oil or baby oil to the top of the cutter head between two teeth. Too much oil applied may spray. Be sure to point the trimmer down and away from you and turn it on to spread the oil evenly and expel any excess.