

D Montageanweisung
 F Instructions d'installation
 I Istruzioni di montaggio
 NL Installatievoorschrift
 DK Installasjonsinstruktus
 N Installationsinstruktioner
 FIN Asennusohje
 S Installation instruktioner
 E Instrucciones de montaje

43191680-005 Auxiliary Switches

INSTALLATION INSTRUCTIONS

00A

00B

- ML6420A3007
- ML6420A3015
- ML6420A3023
- ML6420A3031
- ML6420A3072
- ML6425A3006
- ML6425A3014
- ML6425B3005
- ML6425B3021
- ML7420A3006
- ML7420A3014
- ML7420A3071
- ML7420G1004
- ML7420G1012
- ML7420G1020
- ML7425A3005
- ML7425B3004

1

2

3

4

Manufactured for and on behalf of the Environmental and Combustion Controls Division of Honeywell Technologies Sarl, Ecublens, Route du Bois 37, Switzerland by its Authorized Representative:

Automation and Control Solutions

Honeywell GmbH
Böblinger Straße 17
D-71101 Schönaich / Germany
Phone: (49) 7031 637 - 01
Fax: (49) 7031 637 - 493
<http://europe.hbc.honeywell.com>

Subject to change without notice. Printed in Germany

MU1B-0348GE51 R0206A

DIN EN ISO
9001/14001