

DR300

Einbau-Anleitung • Installation Instructions
Instructions de montage • Istruzioni di montaggio

E1


Bauteile • Components • Pièces • Componenti

①= Pilotventil
Pilot valve
Vanne pilote
Valvola pilota


②= Filtereinsatz
Filter insert
Garniture de filtration
Inserto filtro

③= Absperr-Kugelhahn
Manual ball valve
Clapet à bille
Valvola di intercettazione a sfera

④= Regulierventil
Control valve
Valve de régulation
Valvola di regolazione

**E2**


Einbau • Installation • Installation • Installazione



E3


Inbetriebnahme • Commissioning • Mise en service

Messa in servizio



E4

Schließgeschwindigkeit einstellen • Closure pace adjustment • Réglage de la vitesse de fermeture Regolazione della velocità di chiusura



Schließgeschwindigkeit verkleinern
Reduce closure pace
Réduire la vitesse de fermeture
Riduzione della velocità di chiusura

Schließgeschwindigkeit vergrößern
Faster closure pace
Augmenter la vitesse de fermeture
Aumento della velocità di chiusura

Automation and Control Solutions

Honeywell GmbH

Hardhofweg

74821 Mosbach

Phone: (49) 6261 810

Fax: (49) 6261 81309

www.honeywell.com

Manufactured for and on behalf of the Environmental and Combustion Controls Division of Honeywell Technologies Sàrl, Rolle, Z.A. La Pièce 16, Switzerland by its Authorised Representative Honeywell GmbH

MU1H-1028GE23 R0909
Subject to change without notice
© 2009 Honeywell GmbH

Honeywell