


QUICK START GUIDE

AirPlay function allows you to stream music wirelessly from an iOS device, such as iPhone or iPod touch to the speakers of SC-AP01. To use the AirPlay function, SC-AP01 must join the same wireless network as the iOS device through the wireless network router (access point).



Setting up SC-AP01

Set up SC-AP01 by following the method that suits you best.

Is your wireless network router WPS compatible?

Yes

- Supports WPS*1 (Push Button Configuration)

*1 : WPS : Wi-Fi Protected Setup™

I don't know

- Doesn't support WPS
- METHOD 1 didn't work*2

*2 : Turn SC-AP01 off before proceeding to METHOD 2.

METHOD 1

1 Turn on SC-AP01 and then activate the WPS push button setup mode.

Press and hold for 2 sec.

(Lights red) (Blinks blue) (Lights blue)

2 Press the WPS button on the wireless network router to establish the connection.

Router's manual

(Blinks blue rapidly) 2 min. (Max) (Lights blue)

Setup finished

*3 : The marking may differ.

METHOD 2 The following explanations are based on an iPhone.

Connect your iOS device to SC-AP01

Step 1

1 Turn on SC-AP01 and then activate the network setup mode.

Press and hold both buttons for 2 sec.

(Lights red) (Blinks purple)

2 Connect your iOS device to SC-AP01's setup network.

Enter your home wireless network details

Step 2

1 Display SC-AP01's network setting page.

Address bar: Type in "192.168.1.12" Go Search wireless network

2 Select your home wireless network (SSID).

Preparation Before proceeding, check your home wireless network name (SSID) and password.

Router Router's manual

SSID: XXXXXXXXXXXX Password: XXXXXXXXXXXX

Network name (SSID) Done

3 Enter your home wireless network password.

Password Type in the password Done

Complete the settings

Step 3

1 Apply your home wireless network details to establish the connection.

JOIN OK

The settings have been applied. Confirm the indications on the device.

(Blinks blue rapidly) 2 min. (Max) (Lights blue)

Setup finished

On devices other than an iPhone, close the tab/window before closing the Internet browser.

Using AirPlay

The following explanations are based on an iPhone.

Preparation

- Make sure SC-AP01 is turned on.

Step 1

1 Connect your iOS device to your home wireless network.

Settings Wi-Fi Turn on

Choose a Network... Your home wireless network name (SSID)*4

*4 : You may be prompted for the password. Enter the password of your home wireless network.

2 Select "Panasonic AP01" from the AirPlay icon and start play.

Music AirPlay icon Panasonic AP01 Play starts. (with a slight delay)

FAQ

I have a new iOS device (iPhone/iPod touch/iPad), do I need to reset SC-AP01?
No, you only have to connect the new iOS device to the same home wireless network. (Refer to "Using AirPlay")

My wireless network router is WPS push button compatible but SC-AP01 does not light blue with "METHOD 1".
The security setting may be set to WEP. Try using "METHOD 2".

Can I change the display name for SC-AP01 (e.g., AP01_Bedroom)?
Yes, refer to the Owner's Manual "Advanced network settings", under "Network settings".

If you have any questions, contact:

U.S.A. and Puerto Rico: 1-800-211-PANA (7262)
Mon-Fri: 9 am - 9 pm (EST) Lunes-Viernes
Sat-Sun: 10 am - 7 pm (EST) Sabado-Domingo
<http://www.panasonic.com/help>

Canada:
Telephone: 1-800-561-5505
E-mail link: "Support -> contact us -> email" on www.panasonic.ca