


hp **Wireless Mouse x3300**
 无线鼠标 x3300
 無線滑鼠 x3300
 Quick Setup



1

Please download and install software from <http://www.hp.com/support>

Software zum Herunterladen und Installieren finden Sie auf <http://www.hp.com/support>

Descargue e instale el software en: <http://www.hp.com/support>

Veuillez télécharger puis installer le logiciel à partir de <http://www.hp.com/support>

Scaricare e installare il software dal sito Internet: <http://www.hp.com/support>

Download en installeer software via <http://www.hp.com/support>

Baixe e instale o software em <http://www.hp.com/support>

<http://www.hp.com/jp/support/>からソフトウェアをダウンロードおよびインストールしてください

<http://www.hp.com/support/>에서 소프트웨어를 다운로드하고 설치하십시오.


請至 <http://www.hp.com/support/> 下載並安裝軟件

請自 <http://www.hp.com/support/> 下載並安裝軟體


Lütfen yazılımı <http://www.hp.com/support/> adresinden indirin ve yükleyin

Загрузите и установите программное обеспечение с веб-страницы <http://www.hp.com/support/>


2 A



B





3




707965-B21

4



A



B

