


LEGENDA LEGEND LEGENDE LEGENDE		
B <sub>1,2</sub>	SELETTORE ZYKLUSWAHLSCHALTER	SELECTEUR SELECTOR
L <sub>1</sub>	SPIA MACCHINA IN TENSIONE MACHINE LIVE WARNING LAMP	MASCHINE UNTER SPANNUNG-LAMPE LAMPE APPAREIL SOUS TENSION
L <sub>2</sub>	SPIA MACCHINA IN FUNZIONE MACHINE ON WARNING LAMP	MASCHINE IN BETRIEB-LAMPE LAMPE MACHINE EN FONCTION
MO	MORSETTIERA MAIN TERMINAL BOARD	KLEMMENBRETT BOITE DE CONNEXION
R <sub>1,2</sub>	RESISTENZA HEIZKOERPER	RESISTANCE HEATER
T <sub>1,2</sub>	TERMOSTATO THERMOSTAT	THERMOSTAT THERMOSTAT
TS <sub>1,2</sub>	TERMOSTATO SICUREZZA SICHERHEITSTHERMOSTAT	THERMOSTAT DE SECURITE SAFETY THERMOSTAT
		01 - 12 - 08
286402 286405 288402 288405 286602 288602 286603		



COLLEGARE IL CAVO DI ALIMENTAZIONE AD UN SEZIONATORE A PARETE - RELIER LE CABLE D'ALIMENTATION A UN INTERRUPTEUR MURAL - CONNECT THE POWER-SUPPLY CABLE WITH A WALL DISCONNECTOR - BAUSEITS IST EIN HAUPTSCHALTER ZU INSTALLIEREN