

The CC450 combines flexibility and power to capture amazing images or videos in bold colors. It offers 14.2 MP high resolution pictures along with 720p HD video recording. The CC450 is powered by two AA batteries, giving you the convenience of using photo lithium, alkaline, or standard rechargeable battery types. With the improved comfortable compact design and easy-to-navigate user interface, the CC450 makes picture taking easy and fun, giving you everything you need to capture life-like quality images to share with family and friends.



High definition images with outstanding clarity

The CC450 offers you 14.2 MP high resolution and 720p HD video recording to capture videos or images in outstanding quality. With 4X Optical Zoom, the CC450 lets you magnify and capture sharp images when taking pictures from a distance. The CC450 offers you everything you need to capture life-like images to share with family and friends.

New easy-to-navigate user interface

The new user interface features modern 3D icons and greater color contrast for improved visibility when navigating menu selections in bright light. Additionally, when choosing scene modes, two images are shown as examples of what a picture would look like in comparison to using the auto mode.

Smile detection

With smile detection, the camera will search for a smile and automatically take the picture when the subject is smiling. This feature is especially helpful when trying to capture pictures of young children.

Blink detection

When using the blink detection feature, the camera alerts you if a subject is blinking when the picture is taken. The camera will then prompt you to either keep or delete the picture.

Over 30 scene modes

With over 30 scene modes, you can easily ensure the best shot is captured in different shooting situations. Pick the mode that best matches your activity or use the intelligent scene mode to let the camera detect the conditions and select the best mode for you.

The CC450 also features two new scene modes for you to create fun special effects: LOMO and Fisheye. When using LOMO, the camera will create a halo effect around your picture, and capture the people and objects in an artistic, over-saturated color. Using the Fisheye scene mode, the camera will create a circular fish-eye appearance.

Package contents

- HP CC450 digital camera
- Wrist strap
- 0.8 meter USB cable
- 2 x AA batteries
- Quick start guide
- Software install and electronic user manual CD-ROM
- Warranty document



SPECIFICATIONS

| LCD Display | 2.7" screen |
|--------------------------------|---|
| Sensor Type | 1/2.3" CCD |
| Total Pixels | 14.5 MP (4412 × 3282) |
| Effective Pixels | 14.2 MP (4352 × 3264) |
| Zoom | 4X optical zoom, 5X digital zoom |
| Still Image Format | JPEG/EXIF 2.2 |
| ISO Sensitivity | Auto, 100, 200, 400, 800, 1600 , 3200 <3M, 16:9 <2M>, VGA>, 6400 <3M, 16:9 <2M>, VGA> |
| Video Format | AVI (Motion JPEG) |
| Storage Media | SD/SDHC (Up to 32GB) Note: Class 6 or greater speed SDHC cards are required for 720p HD video |
| Minimum System Requirements | Microsoft Windows XP/Vista/7 Pentium III 1GHz processor or equivalent 512 MB RAM or greater 300 MB available hard disk space for software installation |
| Power | 2 x AA batteries |
| Dimensions | 94.7 x 61.1 x 27.5 mm (3.72 x 2.40 x 10.8 in) |
| Weight | 0.11 kg (0.25 lb) (without battery) |
| Warranty | One year limited hardware warranty from date of purchase |

Questions about the HP Digital Camera? Look us up online at http://www.hp.com