



At the heart of the image

DIGITAL PHOTO STORAGE VIEWER
COOLWALKER
MSV-01

COOLWALKER — Your 30GB portable photo storage album!



Compact and lightweight (only 350 grams) — stores approx. 30 gigabytes of digital files.

View your digital snaps anywhere with the 2.5-inch color LCD. Or connect COOLWALKER to a TV and wow family & friends with your photos on the big screen.

COOLWALKER allows image storage in JPEG, TIFF and NEF formats. Data upload can be done via USB 2.0 and COOLWALKER is equipped with a data card slot.

Packed with features yet easy to carry, simple to use.

Store up to 10,000* digital photos on the high-quality 30GB hard disk.

*Calculated for 6-megapixel images stored in JPEG FINE format.

Lets you store and immediately view your photos on the high-quality 2.5-inch TFT color monitor.

Transfer photos direct from COOLWALKER to a CF card or to a computer via USB 2.0.

Note: SD card compatible with CF card type adapter.

Operation is intuitive thanks to the simple user interface.



Compatible with JPEG, TIFF and other major image file formats — including NEF file.

A slideshow feature and remote control add up to fun for the whole family when COOLWALKER is connected to your TV.

PictBridge compatible — outputs directly to a printer.

Light (approx. 350g) and compact (approx. 81 x 130 x 35mm), so you can take COOLWALKER everywhere.



MSV-01 Specifications

Model name	Nikon Digital Photo Storage Viewer MSV-01
Storage	2.5" internal hard disk drive with 30GB capacity (approx. 0.1 GB is used for system)
Compatible memory cards	CompactFlash memory card (Type I/II), Microdrive supported
Monitor	2.5" TFT color LCD; 490 (H) x 240 (V) dots; brightness adjustable (15 levels)
Menu languages	English, French, German, Spanish
Compatible file formats for display and playback	Standard formats compliant with DCF (Design rule for Camera File system): JPEG, TIFF, RAW (NEF) *1, QuickTime Motion JPEG, Wave Format Audio File (WAV)*2. Supports file formats recorded by Nikon digital cameras.
Image display	Thumbnail; One-frame; Zoom (still JPEG images only): x2, x4, x8; Slideshow; Movie; Histogram display; Shooting information; Search by date
Video output	NTSC/PAL selectable
Interface	USB 2.0 •As a mass storage device: recognized as a computer's external HDD or CF card reader •PictBridge: connects via USB cable to a PictBridge printer
Terminals	CompactFlash™ card slot (Type II) x 1, USB (miniplug) x 1, AV output x 1, DC input x 1

Power	•Interchangeable EN-EL6 rechargeable Li-ion battery (2000mAh) •AC adapter (supplied)
Max. continuous playback time	Approx. 1.5 hours when using the battery pack, fully charged, at room temperature (20°C)
Dimensions (WHD)	Approx. 81 x 130 x 35mm
Weight	Approx. 350g (including battery)
System requirements	•Interface: built-in USB ports (Note: this product may not function as expected when connected via a USB hub.) •Compatible operating systems: Windows XP Home Edition/Professional, Windows 2000 Professional, Windows Millennium Edition (Me), Windows 98 Second Edition (SE) *3; Mac OS 9.1-9.2, Mac OS X (version 10.1.2 or later). Compatible with any of the above operating systems preinstalled.
DPOF	Supports DPOF for DCF-compliant images stored on a CF memory card.
Supplied accessories	USB cable, AV cable, Rechargeable battery EN-EL6 (installed), AC adapter, Remote control unit, Soft case, Software CD-ROM, Instruction manual, Warranty

*1 RAW images recorded with specific Nikon Digital cameras (D1x, D1h, D100, D70, D2h, COOLPIX with RAW support).

Software updates may provide support for images taken with other Nikon digital cameras.

*2 Only sound files attached to images using digital cameras. Connection with audio-video equipment with AV input and audio output is required for playing audio.

*3 CD-ROM drive is required for COOLWALKER MSV-01 driver installation (Windows 98 SE only).

Apple, the Apple logo, Macintosh®, Mac OS, Power Macintosh, PowerBook, and Quick Time® are registered trademarks of Apple Computer, Inc. Finder, Power Mac, iMac, and iBook are trademarks of Apple Computer, Inc. Microsoft® and Windows® are registered trademarks of Microsoft Corporation. Internet is a trademark of Digital Equipment Corporation. CompactFlash™ is a trademark of SanDisk Corporation. The SD logo is a trademark of the SD Card Association. PictBridge is a trademark. All other trade names mentioned in this manual or other documentation provided with your Nikon product are trademarks of their respective holders.

Specifications and equipment are subject to change without any notice or obligation on the part of the manufacturer.

©2004 NIKON CORPORATION



WARNING TO ENSURE CORRECT USAGE, READ MANUALS CAREFULLY BEFORE USING YOUR EQUIPMENT. SOME DOCUMENTATION IS SUPPLIED ON CD-ROM ONLY.



NIKON CORPORATION

Fuji Bldg., 2-3, Marunouchi 3-chome, Chiyoda-ku,
Tokyo 100-8331, Japan

<http://nikonimaging.com/>