

Connecting a VCR to MONITOR OUT Jacks

(except for KV-1405GE/1415GE/1415AS/2115GE/1487B1)

KV-1405GE/1415GE/1415AS/2115GE/1487B1

- The A/B and TV/VIDEO buttons on the Remote Commander are not effective for the KV-1415GE/1415AS/2115GE.
- The KV-1405GE/1415GE/1415AS/2115GE do not have VIDEO IN and MONITOR OUT jacks. Use an antenna cable to connect a VCR.


(* except for KV-1405GE/1415GE/1415AS/2115GE/1487B1)

Model KV -	1405GE, 1415GE, 1485GE, 1485GET, 1605GE, 1685GE, 1685GET, 1985GE, 1985GET, 2115GE, 2185GE, 2185GET, R14P1, P21P1, 1487B1	1415AS, 2185AS	R21S1	2185AST
Low VHF band	E2~E4	0~5, 5A 1~3	0~5, 5A	1~3
High VHF band	E5~E12	6~11 4~10	6~11	4~10
UHF	E21~E69	28~69	28~69	—
CATV	S01~S03 S1~S20 S1~S41 (for KV-1487B1 only)			

VIDEO INPUT jacks: phono jacks (except for KV-1405GE/1415GE/1415AS/2115GE)

MONITOR OUT jacks: phono jacks (except for KV-1405GE/1415GE/1415AS/2115GE/1487B1)

Model KV -	1405, 1415, 1485, 1487B1	1605, 1685	1985	2115, 2185	R14	R21
Audio output	3W				5W	
Picture tube Approx. cm (inches)	37 (14) (Approx. 34 cm picture measured diagonally)	41 (16) (Approx. 37 cm picture measured diagonally)	49 (19) (Approx. 46 cm picture measured diagonally)	54 (21) (Approx. 51 cm picture measured diagonally)	37 (14) (Approx. 34 cm picture measured diagonally)	54 (21) (Approx. 51 cm picture measured diagonally)
Dimensions (w/h/d, mm)	364×344×405	397×375.5×426	474×429×473	520×462.5×486	422×349.5×406	564×459.5×472
Mass (kg)	11	14.5	19	24	12	24



KV-1405

1415

1485

1487

1605

1685

1985

2115

2185

R14

R21

GE, GET, AS, AST, P1, S1, B1

Rear (Except for KV-1405GE/1415GE/1415AS/1487B1/1605GE/2115GE)

Front (Except for KV-1405GE/1415GE/1415AS/1605GE/2115GE)