

Code List

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
A.R. Systems	0001,0002,0711						
AB			0812				
ABC				0452			
Accent		0711					
ACE	0713						
Adel sound		0756					
Admiral	0032,0033,0041,0155 1013						
Adyson	0004,0724,0730						
Aegir			0514				
Afreey						0688	
Agashi	0033,0159,0730						
Aiko	0039,0707,0711,0730						
Aim	0711						
Aiostay	0009,0019,0033						
Aiwa	0261	0755,0757 0758,0760			0581	0626,3029	
Akai	0004,0005,0010,0019 0023,0026,0031,0033 0039,0054,0074,0087 0105,0139,0159,0168 0169,0175,0262,0707 0711,0730,0731,0745 1011,1015,1023,1025	0269,0270 0271,0309 0310,0356 0357,0757					
Aki	0004,0005						
Akiba	0711,0731,0742						
Akito	0711						
Akura	0026,0033,0039,0159 0170,0711,0731,0738 0740,1015						
Aaron	0730						
Alba	0019,0039,0088,0159 0169,0262,0705,0730 0731,0738,0744	0755,0757 0760	0407,0426,0521			0680	
Albiral	0000,0001,0019,0026 0096,0146,0175,1015						
Aldes			0511,0514				
Alfa Gold			0810,0811				
Alhori	0004						
Allorgan	0004,0015,0078						
Allsar	0711	0759					
Allsat			0386,0424,0499 0512				
Allsonic			0511				
AlphaStar			0499,0826				
Amstar			0847				

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Amstrad	0006,0033,0039,0175 0262,0711,0731,0740 1013,1015	0755	0371,0372,0408 0409,0476,0488 0497,0506,0816 2014,2026				
Amstrong			0506				
Amway	0026						
Anam	0711						
Anex	0026						
Anglo	1015						
Anitech	0004,0024,0026,0033 0037,0096,0163,0175 0711,0724,1015	0759					
Anitsch		0311					
Ankaro			0373,0511				
Anntron			0426				
Ansonic	0026,0033,0145,0170 0711,1015	0756					
Antecno	0039						
Antron			0521				
APEX						0672	
Apollo			0402,0426				
Arcon			0372,0373,0476				
Arianet						3034	
Arion			2003				
Aristona	0711						
Armstrong			0499				
Arthur Martin	0739						
Art-tech	0159,0163,0175						
ASA	0007,0009,0013,0026 0032,0041,0094,0105 0155,0161,0221,1012	0282 0758					
ASAT			0499				
Asberg	0026,0024,0096,0159 0169,0711						
Asiagiant				0501			
Asora	0033						
Aston			0498				
Astra	0033		0372,0409,0488 0506,0520				
Astro	0001,0019,0026,0096		0502,0514,0521				
ASTRX			0840,0842,0843 0846				
Asuka	0019,0037,0039,0731	0755 0758					
Atlantic	0711,0730						
ATLE					0579		
ATLM						0627,0671	
Atoro	0033						
Auchan	0005,0739						
Audiosonic	0160,0711,0731						

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Audiostar	0033,0039						
Audioton	0004,0033,0037,0168		0386,0512,0521				
Aura			0430,0487				
Aurora	0004,0168,0221						
Ausind	0008,0045						
Autovox	0004,0007,0012,0014 0015,0078,0079,0104 0151,0153						
AVA	0175						
AWA	0026,0027,0033,0159 0160,0168,0175,0189 0220,0706,0708,0709 0714,0730,0740,1007	0758					
Axxion	0026,0033,0262						
Baihua	0039						
Baird	0031,0162,0737	0271 0273 0755					
Bang & Olufsen	0026,0155						
Barcom	0103,0155,0724		0373				
Basic Line	0005,0026,0039,0163 0711,0731						
Baur	0005,0010,0015,0026 0027,0033,0047,0052 0054,0074,0126,0127 0159,0711,1020,1051						
Bazin	0004						
BBK Speaker						3001,3002 3003,3004 3005,3006 3007,3008 3009	
BEKO	0026,0142,0159,0170 0226,0254,0711,0719 0722,1021						
Bekoteknik	0170						
Benjamin			0468				
Bentley						3021	
Beon	0711						
BEST	0741		0373,0453,0511				
Bestar	0170,0711,1046						
Biazet	0175						
Bifonic	0004,0033						
Bigsat			2013				
Big Stone	0033,1015						
Blaupunkt	0010,0017,0018,0020 0054,0111,0231,0232 0233,0234,0235,0236 0241,1005	0272 0274 0275 0312 0369			0568		0569(VHS)

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Blausonic	0004						
BlueSky	0711,0719,0731,0738 0742,0744,1046	0757 0758 0760					
BlueStar	0005,0019						
Boca			0497,0506				
Bondstec	0151						
Bosch Bauer	0037,0232,0236,0722 1024,1025						
Boston	0155						
BPL	0026,0160,0162,0163 0711						
Brain			0373				
Brandt	0000,0001,0004,0019 0037,0045,0047,0067 0070,0077,0100,0103 0117,0159,0224,0711 0722,0733,0735,0744 0746,1024,1025,1026 1027,1029,1036,1044		0372				
Braun	0096						
Brignton	0001,0004,0175						
Brinkmann	0711	0760					
Brionvega	0026,0104,0155,0164 0165,0197,0200,0201 0257,0711,1013	0276 0283					
Bristol	0155						
Britannia	0004,0730						
Broksonic	0026,0033						
Brother	1015						
Bruns	0158						
BSkyB			0880,0881				
BSR	0006,0016,0019,0021 0088						
BTC	0731						
Bush (UK)	0019,0022,0023,0047 0097,0262,0711,0731 0738,0744	0281 0755 0757 0760	0402			0680,0685 0689	
Cabletime	0246,0247,0251						0524,0525 0526(CTV)
Cambridge			0371,0375				
CANAL+			0804				
Canton	0039						
Capsonic	1015						
Carad	0711,0717						
Caravell						0622	
Carena	0711,0742						
Cascade	0711						
Casio	0711	0755					

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Catha	0711						
CBM	0024						
CCE	0711						
Celint	0101						
Centurion	0711						
Century	0145,0146,0155						
CGE	0019,0023,0024,0033 0145,0151,0159,0169 0170,0175,0231,0235 1005	0270 0277 0755					
CGM	0026,0033,0039,0093 0163,0170,0254,0262 1015	0291					
Chaparral	0216		0216,0374,0410				
Ciate	0155						
Cie	0006,0033,0039,0159 0168						
Cimline	0731						
Cineultra						0689	
Citycom			0507				
Clarivox	0000,0001,0009,0019 0045,0155,0166,0167 0175,1000,1015,1029 1047						
Clatronic	0004,0019,0024,0026 0033,0037,0039,0096 0145,0146,0159,0163 0169,0170,0262,0705 0711,0731,1015						
Clayton	0019						
CNT			0514				
CODIAM	0138						
Colorlux	0155						
Colormatt	0155						
Colotron	0155						
Combitech		0757					
Concorde	0033						
Comet	0175						
CommLink			0511				
Comsat			0821,2014				
Comtec			0511				
Condor	0024,0026,0033,0037 0096,0159,0169,0170 0175,0197,0711,0730 1015		0520				
CONIC	0724					0673	
Contec	0004,0016,0033,0044 0730						
Continental Edison	0733,0744						

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Conrad			0520				
Cosat			0512				
Cosmel	0026,0033,0175,1000						
Crosley	0024,0025,0057,0145 0155,0231,1005						
Crown	0019,0024,0026,0033 0039,0096,0142,0159 0169,0170,0254,0705 0711,0741,0744,1009	0759	0506				
Cosmos	0159						
Crystal	0026						
CS Electronics	0004,0039,0151,0730 0731						
CTC Clatronic	0096						
Curtis	0088,0175						
Cybertron	0731						
Cyfra+			0804,0841				
Cymatic	0000,0004,0019						
Daewoo	0004,0033,0039,0159 0168,0172,0175,0209 0711,0730,0731	0757				0660,3013	
Dainichi	0004,0730,0731						
Dansai	0707,0711,0724,0730 1015	0281					
Dansette	0740						
Datcom			2005				
Dawa	0026,0711						
Daytron	0711						
DCS						0642	
Decca (UK)	0002,0004,0026,0028 0031,0258,0711	0278 0755 0760					
Degraaf	0047						
Demacolor	0024						
Denca						0665	
Deitron	0711						
Denon					0547		0564(TUNE) 0566(DECK)
Denver	0033,0175					0689	
Denzel						0684	
Desay						0625	
Desmet	0002,0005,0019,0026 0033,0037,0155,0159 0711						
Diamant	0711	0758					
Diamond						0683	
Digiline	0711						
Digital			2006				
Dinasty	0033						
Disistrat			0424				

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Disk Express			0373				
Distrisat			0499				
Dixi	0033,0156,0711						
DK-Digital							0677
DNT			0409,0424,0428 0430,0487,0499				
Domoh	0026						
Domus	0026						
Donatec			0373				
Doric	0041						
Drake			0376,0445,0446 0447,0495				
Dreambox			2030				
Drean	0711						
DSE (Digitor)	0026,0027,0033						
DSR			2003				
Dual	0004,0005,0011,0015 0019,0023,0026,0033 0052,0159,0255,0258 0711,0737,1013,1020	0273 0279 0755				0684	
Dual-Tec	0004,0011,0019,0029						
Dumont	0009,0013,0024,0155 0169,0221,1012,1032	0755					
Dunai	0019						
Dux	0159,0711						
D-Vision	0026						
Dynasat			0491,0492				
Dynatron	0711						
Eastern				0508 0509 0510			
Echostar			0377,0378,0379 0386,0409,0411 0412,0457,0458 0461,0462,0486 0800,0821,0827 0862,0883,2008				
Edan Line	0026						
EH.Galaxy			0858				
Einhell			0497,0506,0511				
EISAT			0822				
Elbe	0000,0001,0004,0019 0026,0044,0171,0197 0711,0717,0731,1013	0313					
Electrosat			0870				
Electrovenda	0026						
Elekta	0033,0163,0175,1015		0514				
Elektron	0019						
Elektronica	0004,0026						
Elektronika	1009						

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Elektrontech	0033						
Elektronska IND	0000,0019						
Elemis	0175						
ELG	0711						
Elan	0004						
Elbit	0026,0159						
Elin	0005,0011,0013,0033 0047,0087,0175,0221 0711,0730,0745						
Eltax	1015					3023	
Elyxio						3000	
Elite	0037,0039,0108,0711 0731,1005						
Elman	0000,0005,0019,0029 1032						
Elta	0019,0033,0097,0163 0730,1015		0386,0426,0499 0512				
Emanon			0426				
Emerson	0004,0009,0019,0024 0026,0037,0045,0096 0146,0155,0170,0172 0175,0262,0711,1012 1015	0286					
EMME ESSE			0463,0464,0465				
Encore						0688	
Engel	0019						
Enzer						0684	
Erres	0711						
ESC	0159,0711						
Estel	0019						
Etron	0005,0033,0711						
Eurocom	0019						
Eurofeel	0004						
Euroman	0004,0159,0175,0711 0730,0741,1009						
Europa	0711		0499				
Europhon	0000,0004,0019,0029 0030,0146,0711,1003 1032						
Eurosat			0386,0506				
Eurosky			0421,0497,0506 0520				
Euro Space			0850				
Eurostar	0057,0221		0465,0513,0520 0872				
Everest	0175						
Exator			0426,0521				
Expert	0005,0739,1047						
Exquisit	0711						

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Fagor	0019,0711		0512				
Family Life	0711						
Fenner	0026,0033,0163,0168 0175,0193,0240						
Ferguson	0733,0735,0746	0755	2003			0679	
Fidelis	0004,0026,0033						
Fidelity (UK)	0003,0004,0015,0033 0034,0229,0262,0711 0724,0730	0755	0371,0372				
Filmnet	0202,0248,1046		0424				
Filsai	0004,0033						
Finlandia	0019,0047,0722,0745 1012	0755					
Finlux	0002,0004,0007,0008 0009,0013,0019,0024 0025,0026,0029,0031 0035,0045,0057,0087 0094,0096,0101,0105 0151,0159,0161,0169 0175,0197,0221,0711 1011,1012,1032	0278 0755	0414,0415				
Firstline	0001,0004,0005,0015 0019,0023,0026,0031 0033,0037,0145,0168 0175,0711,0730,0738 1046	0758 0760					
Fisher	0004,0013,0015,0025 0036,0044,0057,0074 0120,0155,0167,0170 0255,1020	0280 0314 0315 0316			0529,0546		
Flint	0159,0711,0731,0742						
F.M.			0386				
Force			0836				
Formenti Phoenix	0000,0003,0004,0005 0006,0008,0019,0024 0025,0026,0033,0037 0038,0045,0057,0155 0159,0175,0730,1005 1015,1032						
Fortec Star			0458,0808,0809 0846,0850,0851 0852,0853,0854 0856,0857,0859 0866,0867,0876 0878,0879				
Fortess	0155						
Fraba	0026,0159,0711						
Fracarro			0380,0381				
Francarro			0426				
FranceTelecom	0266						
Freecom			0426				
Freesat			0426				

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Frontech	0006,0033,0097,0145 0151,0172,0724,1015						
Friac	0711,0741						
Frontech	0004,0151	0759					
FTE			0386,0399				
Fuba			0373,0408,0413 0426				
Fujitect	0026						
Fujitsu	0004,0011,0039,0078 0096,0163,0724	0755					
Funai	0016,0033,0160,0740 1015,1022	0359 0755					
Funtach			0823,0824				
Galaxis	0009,0024,0026,0096 0145,0159,0169,0170 0711	0755	0386,0511,0512				
Galaxys			0873				
Galeria	0033						
GBC	0000,0002,0004,0019 0025,0026,0031,0033 0039,0040,0041,0042 0044,0057,0163,0168 0172,0175,0262,0731	0281					
GE	0735						
Geant Casino	0005,0739						
Geber	0005						
GEC (UK)	0002,0004,0005,0024 0026,0031,0041,0042 0082,0711	0278					
Geloso	0000,0004,0019,0025 0032,0033,0039,0041 0057,0149,0150,0168	0281					
General	0733,0743	0358					
General Corporation	0004,0044,0078						
General Technic	0033	0760					
Genexxa	0711,0731,0740						
Giucar Record			0382,0416				
GMG	0033,0169,1015						
GMI			0506	0515 0519			
Goldhand	0004,0033,0730						
Goldstar	0003,0004,0011,0018 0019,0026,0033,0043 0080,0097,0145,0151 0153,0172,0175,0252 0700,0701,0711,0724 0730,1013,1015	0282 0755 0758				0633,0682	

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Goodmans	0004,0019,0033,0039 0044,0119,0159,0168 0175,0262,0707,0711 0722,0735,0737,0744 1046	0301 0755 0758 0760					
Gorenje	0026,0039,0170,0173 0175,0741,1009						
GP	0004						
GPM	0033,0039,0724,0731 1015						
Gradiente	0711						
Graetz	0711						0684
Granada (UK)	0002,0004,0005,0026 0027,0041,0044,0045 0046,0047,0048,0049 0082,0105,0110,0111 0139,0159,0191,0711 0722,0735,0739,1012 1031	0272 0278 0283 0314 0369 0755 0758					
Grandin	0005,0019,0026,0037 0039,0082,0163,0705 0711,0717,0719,0731 0739,0742,1047	0755 0758	0496				
Great Wall	0253						
Gronic	0004,0019,0026,0096 0175						
Grothusen			0426				
Grundig	0003,0010,0012,0017 0018,0020,0045,0050 0051,0053,0054,0056 0094,0711,0744,1046	0272 0275 0284 0361 0369 0760	0383,0400,0402 0484			0686,3019 3035	0675,0680
GTT	0033,0169,0175						
Haitai					0548	0648	
Halifax	0730						
Hampton	0004,0730						
Hanimex		0757					
Hanseatic	0000,0004,0005,0015 0019,0025,0026,0027 0033,0037,0039,0044 0052,0055,0057,0088 0097,0159,0175,0254 0258,0711	0278 0285 0758	0372,0516				
Hantarex	0000,0026,0033,0159 0711						
Hantor	0711		0426				
Hanuri			0514				
Hapo	0039						
Happy	0039						
Harman						0690	
Harwood	0711,0740						

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Hauppaugel	0026,0711						
HCM	0004,0019,0033,0159 0711,0731,0740,1015	0759					
Heliocom			0520				
Hemmermann	0004,0015,0057						
Hebet			2007				
Hexa	0019,1029						
Higashi	0004,0005,0006,0026 0028,0033,0039,0044 0159,0175,0724,1015						
Highline	0711						
Hikona	0731						
Hinari	0033,0044,0058,0059 0060,0711,0731,0744	0281,0286 0287,0317 0360,0756 0757,0759					
Hisawa	0019,0039,0731,0739 0742	0757					
Hisonix	0033						
Hirschmann			0415				
Hitachi	0004,0005,0040,0041 0042,0044,0047,0055 0061,0062,0063,0064 0065,0066,0067,0068 0082,0087,0105,0172 0174,0175,0221,0222 0710,0711,0724,0737 1024,1026,1027	0273,0281 0285,0288 0755,0756	0483,0828,0829		0530	0684	
Hitsu	0039,0730,0742						
Hornyphone	0711						
Horyzont	0019,0175						
Hoshai	0039,0163,0731,0742						
Hotel TV	0704						
HTS			0827				
Huanyu	0730						
Hughes			0828,0829				
Humax			0505,2004,2012				
Huth			0421,0479,0506 0511,0512,0520				
HWALIN			0816				
Hygashi	0730						
Hyper	0003,0004,0019,0026 0033,0039,0151,0153 0159,0175,0193,0254 0262,0724,0730,1015						
Hypson	0001,0004,0019,0026 0033,0175,0711,0739 0742,1015	0757					
Iberia	0711						
Ibervisao	0005,0019						

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
ICE	0004,0033,0039,0145 0262,0711,0730,0731 1015						
Ices	0730,0731						
Ics	0033						
ICX International			0417				
ID Digital			2004				
IEG	0004						
Imperial	0019,0023,0024,0145 0146,0151,0159,0169 0170,0172,0231,0235 0711,1005,1015	0277,0289 0755					
Incobe	0004,0033						
Inddsit	1037						
Indiana	0711						
Info			2010				
Ingelen	0744						
Ingersoll	0033	0756					
Inkei					0541		
Inno Hit	0000,0004,0019,0023 0024,0031,0043,0060 0145,0146,0159,0175 0169,0170,0172,0235 0711,0731,1005,1015	0759					
INT	1015						
INTER (265)	0725						
Interburg	0033						
Interbuy	1015	0758					
Interfunk	0005,0026,0027,0040 0045,0046,0047,0052 0069,0070,0071,0073 0075,0082,0084,0145 0155,0159,0169,0170 0232,0234,0711,1025 1031	0278,0290					
Intertronic			0506				
Intervision	0004,0005,0019,0026 0096,0146,0159,0170 0172,0175,0711,0731 0742,0744,1015,1032	0755,0758 0760	0386,0512 0520,0523				
Intercord	1020						
Interstar			2011				
Irradio	0008,0019,0026,0033 0039,0043,0045,0060 0151,0153,0159,0175 0262,0254,0711,0724 0731,1015	0758					
Iskra	0000,0004,0019,0254 1032						
Isukai	0711,0731						
IT	0723						

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
ITC	0004,0019						
ITL	0033						
ITS	0004,0033,0039,0262 0711,0730,0731,1015						
ITT-Nokia	0005,0032,0033,0040 0041,0045,0049,0069 0070,0071,0072,0074 0076,0162,0168,0176 0177,0717,0745	0270,0273 0276,0290 0291,0292 0316	0384,0385,0418				
ITV	0026,0711	0758					
Janco	0249,0250						
JBL					0623,0624		
JEC	0707						
Jeemon			0386				
Jerrold			0454	0417			
JET-Point	0159,0175						
JMB						0686	
Johansson			0387,0512				
Johnson	0004						
JVC	0044,0077,0119,0178 0179,0262,0731,1025	0270,0273 0292,0318 0319,0320 0321,0328			0605	0664,3012 3022	
JSR			0386				
Kabel	0088						
Kaido	0097						
Kaiser	0026						
Kaisui	0004,0026,0033,0039 0163,0169,0711,0730 0731,0742,1015						
Kamp	0730						
Kansai	0111						
Karcher	0001,0004,0026,0033 0097,0159,0163,0175 0711,0717,0741,1009				0549		
Kardon						0690	
Kathrein	1046		0388,0389,0390 0419,0424,0469 0499,0507,0521				
Kawasho	0262,0730						
Kambrook	0004,0026,0175,1015						
Kamosonic	0004						
Kapsch	0005,0013,0078,0082						
Kaya	0033						
Kendo	0004,0019,0033,0088 0096,0146,0175,0197 0711,0717,1013	0758,0760					
Kennedy	0011,0025,0057,0078 0079,0146,0155,0197 1013						
Kennex	0026						

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Kenwood			0804		0527,0531 0532,0533 0534,0550 0580	0572,0630 0663	
Kimay	1015						
Kingsely	0730						
Kiss						0684,3015	
Kitt	0004,0033,1015						
Kitten	0175						
Klarmax	0000,0001,0004,0019						
Kneissel	0004,0159,0197,0711 0717	0757 0758 0760					
Koenig	0037,0057						
Kolon	0019						
Kolster	0001,0004,0019,0039 0096,0146,0172,0175 0711,1015						
KONIG	0027						
Konka	0039,0262,0711,0731						
Kontakt	0744						
Korpel	0711						
Korting	0026,0037,0155,0157 0170,0741						
Kosmos	0711						
Kotron	0740,1015						
KR			0521				
Kraking	0019						
Kronne	0004,0019						
Kuba Electronic	0015,0047,1020						
Kyoshu	0740						
Kyostar			0426,0521				
Kyoto	0004,0019						
Laem_sat			0386				
Lasat			0497,0506,0514 0520				
Lavis	0000,0001,0005,0013						
Lecson	0711,0718					0687	
Legend-V						0650	
Lemon			2021				
Lenco	0005,0013,0026,0033 0039,0097,0159,0168 0175,0183,0238,0239 0240,0711,1015,1032	0325 0355	0423,0426,0480 0481,0482		0060,0549 0594,0595 0596,0597 0598,0599 0600,0601	0689	0585,0586 0587,0588 0589,0590 0591,0592 0593
Lenoir	0004,0015,0026,0033 0163,0168,0175						
LEON			0499				
Lexus	0026,1015		0499				

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Leyco	0016,0026,0031,0163 0705,0711,1015						
LG	0026,0218,0711,0730	0755,0758				0682	
Liesenkotter	0026,0159,0232,0711						
Lifesat			0516,2022				
Lifetec	0033,0039,0168,0175 0711,0731,0738,1015	0760					
Linton	1020						
Loewe Opta	0000,0002,0013,0027 0052,0054,0081,0155 0156,0189,0213,0242 0711,1030	0272,0278 0369,0756 0758	0506				0675
Logic	0028,0185						
Logik	0028	0287,0322 0360,0756				0669	
Logix	0738						
Lorenzen			0520				
Love	0001						
Luma	0032,0041,0078,0082 0711,1013	0322					
Lumatron	0026,0711,1013						
Lux May	0711						
Luxor	0004,0005,0043,0045 0047,0055,0068,0070 0083,0084,0085,0086 0087,0105,0162,0177 0745,1011,1012	0285,0291	0384,0391 0392		0528		
M & B			0516				
M.D.C.	0175						
M Electronic	0005,0009,0013,0015 0018,0033,0105,0159 0168,0172,0175,0197 0221,0737,1011,1012 1020						
Macab			0420				
Mactech	0026,0039						
Macom			0444				
Madison	0711						
Magnadyne	0000,0015,0019,0025 0026,0029,0033,0041 0057,0147,0149,0150 0155,0169,1032						
Magnafon	0000,0003,0004,0008 0009,0015,0026,0029 0030,0033,0057,0159 0169,0730,1032						
Magnasonic	0175	0291					
Magnavox	0019,0191,0711		0477,0830 0831		0553,0576 0604	0571	
Magnum	0169						

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Manesth	0004,0005,0006,0026 0037,0088,0142,0159 0707,0711						
Manhattan	0023,0169,0711,0738		0386,0512 0514				
Manta						3011	
Marantz	0006,0026,0027,0159 0711,1020	0272,0278 0301	0424,0499				
Marech	0037						
Mark	0711,0730						
Marquant		0759					
Marshall	0033,0039						
Mascot	0145						
Maspro			0388,0393 0402,0490				
Masuda	0731						
Match	0033						
Matsui	0004,0006,0015,0019 0028,0033,0041,0088 0097,0141,0175,0182 0262,0705,0707,0711 0735,0742,0744	0287,0322 0332,0755 0756,0757 0758,0760				0683,0686	
Max			0520				
Maxell	0026,0033,0163,0724						
Maximal	0005,0058						
Maxon	0033						
Maxview						0670	
Maxwell	0000,0026,1032						
MB			0516				
Mediamarkt			0506				
Mediator	0711						
Medion	0175,0711,0738,1046	0757,0760					0677
Mega			0424,0499				
Megas	0717						
Melectronic	0255,0711,0730	0755,0758					
Melvox	0739						
Memorex	1015	0282,0314 0755,0758					
Memphis	1000						
Mercury	0711						
Metronic			0426,0496 0506,0507 0511,0514 0521				
Metz	0010,0018,0053,0054 0089,0090,0091,0155 0175,0180,0183	0272,0275 0294,0369 0370	0383				
MGA	0039						
Micormay		0760					

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
MicroTechnology			2014				
Micromaxx	0711,0738						
Micron	0004						
Microsat			0874				
Microsoft X-BOX						0620	
Migros		0755					
MINA			0494				
Minerva	0010,0018,0045,0051 0053,0744	0272,0275 0369	0383,0400,0484				
Minoka	0711,0740						
Mission					0553		
Mitsubishi	0010,0028,0033,0044 0052,0092,0119,0154 0155,0181,0182,0711	0278,0281 0293,0320 0362,0751	0489			0662	
Mitsuri General	0023						
Mivar	0000,0003,0004,0043 0093,0094,0095,0245 0259,0730,0734						
MME			0217				
M.N.E.T.			0373				
Monyka						0684	
Morgans	0711		0421,0476,0497 0499,0506,2012				
Motorola			2000				
Mosaic	0026						
MTC	0019,0027,0047,0170 0730						
Multisystem	0159						
Multitech	0000,0004,0019,0024 0026,0033,0039,0044 0057,0096,0097,0146 0163,0168,0170,0172 0175,0254,0711,0730 0738,1000,1015	0281,0325 0755,0759					
Murphy (UK)	0041,0730	0755					
Musikland	0731						
Mutek						0638	0638
NAD		0363					
Naiko	0711						
Nakimura	0711						
NEC	0028,0033,0037,0044 0168,0184,0711,0742	0273,0313 0320,0758	0422,0478,0493		0551		
Neckermann	0000,0004,0016,0018 0026,0027,0033,0037 0044,0047,0052,0054 0055,0082,0088,0097 0127,0145,0155,0159 0170,0175,0197,0199 0232,0234,0236,0711 1009,1013,1020,1046 1051	0270,0272 0273,0278 0285,0286 0369	0421				

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
N.E.I.	0019,0026,0039,0159 0166,0711,1000						
Neosat			0845				
Neotion Box			2007				
Nesco	0005,0151	0755,0757					
Netsat	0711						
Network			0394				
Neufunk	0711,0717					0684	
Neuhaus			0520				
Neusat			2013				
Newmar	0004,0019						
Newstar			2015				
New World	0731						
NewTech	0004,0026,0711,0737						
Nicamagic	0730						
Nikkai	0004,0142,0707,0711 0724,0730,0731,1013						
Nikko	0175,1000		0506				
Noblex	0033,0044,0120,0168 0711						
Noblisko	0003,0004,0008,0009 0024,0029,0045,0051 0096,0146,0730,1032	0272,0369					
NOKIA	0005,0013,0015,0019 0026,0033,0041,0045 0047,0074,0078,0082 0084,0087,0105,0159 0163,0168,0169,0170 0175,0177,0221,0720 0745,1005,1011,1012 1015		0502,0720 0807				
Nording	0024						
Nordmende	0010,0018,0026,0054 0057,0065,0067,0075 0077,0098,0099,0100 0101,0102,0103,0104 0110,0134,0159,0185 0186,0222,0711,0722 0733,0735,0737,1004 1024,1025,1026,1027 1050	0270,0273 0279,0292 0295,0296 0297,0318 0319,0321 0323,0324 0326,0327 0328,0329 0330	0426,0476 0514		0535,0549		
Norfolk	0019						
Norm n	0159						
Norton	0163						
Norway	0023,0170						
Nova	0013						
Novatronic	0026,0033,0159,0168 0711,1015						
OAK				0500			
Obritech			0426				

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Oceanic (F)	0005,0040,0047,0082 0087,0105,0106,0107 0177,0739,1011,1046 1047	0755					
Octagon			0426,0521				
Octal	0004						
Ost			0372				
Osaki	0026,0175	0758					
Okano	0033,0159,0170,0711	0759,0760	0506				
Olympic			0511				
Omega	0262						
Onceas	0004,0033,0172						
Ondiola	0037						
Onkyo					0536,0537 0613,0614 0615,0616	3027,3033	
Onwa	0039,0262,0731,1015						
Opera	0711						
Opentel			2016				
Optex			0386				
Opticum			2006,2016				
Orava	0019,0026,0033		0424				
Orbit	0711						
Orbiter	0170						
Orion	0006,0015,0016,0026 0028,0039,0057,0088 0108,0109,0159,0187 0188,0189,0711,0724 0735,0740,1001,1003 1015,1046	0286,0322 0331,0332 0333,0360 0756,0757 0760				0686,3010	
Oritron						0683	
Orline	0711,0731						
Ormond	0738						
Orson		0755					
Orsowe	0000						
Osaki	0016,0711,0731,0740 1015	0282,0755					
Osio	0043,0711						
Oso	0731						
Osume	0731						
Other Line	0000						
Otto Versand	0004,0005,0010,0015 0016,0018,0019,0025 0026,0027,0033,0037 0044,0047,0052,0054 0055,0057,0064,0074 0088,0097,0110,0111 0126,0127,0139,0151 0159,0175,0187,0191 0197,0254,0258,0262 0711,0722,1020,1046	0278,0285	0372,0516				

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Pace			0394,0395 0400,0402 0485,0804 0814,0815 2001,2019				
Pacific						0676,0677 0678,0679	
Pacl	0003,0004,0008,0045 0730						
Palcom			0396				
Palladium	0197,0711	0271,0356 0756,0758	0421,0506				
Palsat			0423				
Palsonic	0711,0740	0755					
Panama	0004,0159,1015						
Panasat			0819,0863				
Panasonic National	0001,0003,0019,0037 0040,0054,0082,0106 0110,0111,0112,0114 0155,0190,0212,0241 0711,0738,0745,1050	0274,0290 0312,0354	0473,0832		0538	0573,0574 0629,0639	0639
Panama	0711,0730						
Panavision	0711,1015						
Panavox	0057						
Panda			0520				
Panorama	0004,1015						
Panoramic	1025						
Pansat			0455				
Paragon				0806			
Pathe Cinema	0000,0001,0004,0019 0037,0730,0739,1029	0756					
Pausa	0033						
PCM	0026						
Penney		0313					
Pentax		0288					
Perdio	0711	0755					
Perfekt	0711						
Pershin	0045,0739,1029						
Philco	0019,0023,0024,0025 0026,0033,0044,0057 0145,0151,0155,0159 0169,0170,0231,0235 0711,1005						
Philex	0229						
Philharmonic	0004,0172						

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Philips	0003,0004,0011,0015 0026,0027,0044,0046 0054,0073,0113,0115 0155,0159,0175,0191 0192,0193,0194,0223 0266,0230,0242,0711 0737,1010,1013,1020 1024,1031,1033,1043 1045,1046,1048	0278,0302 0334,0335 0336,0369	0402,0424 0425,0460 0477,0499 0507,0521 0803,0830 0831,0841 2028		0552,0553 0579,0604	0559,0675	0560(EQ) 0561(PIP) 0562(TAPE) 0565(TUNE) 0567(DCC) 0675
Phoenix	0026,0057,0159,0711 0730						
Phonola	0026,0175,0730	0278,0335					
Phonotrend	0711		0511			0689	
Pilot (1621Y)		0753 (Video2)					
Pilot (1624Y)	0729 (PIP)						
Pilot (P1528Y)		0752					
Pilot (P1707Y)	0721						
Pilot (P3033)	0727						
Pilot (P3050)		0754					
Pilot (P4005)	0726						
Pilot (P567)	0728						
Pilot (P716)	0724						
Pioneer	0000,0005,0026,0027 0067,0159,0243,0711 0737,1024	0278,0320 0334,0336 0363,0364 0365	0474,0804		0545,0554 0555,0610	0571,0658	0658
Plantron	0057,0711						
Playsonic	0001,0004,0155						
Polestar	0214						
Polsat			0805,0883 2009,2017				
Poppy	0033						
Portland	0026,0168						
Powerpoint	0744						
Prandoni-Prince	0000,0008,0032,0038 0041,0045,0057,0146 1032						
Praxis	0217						
Preisner			0497,0506				
Premier			0802				
Premium X			2020				
Prima	0004,0033,0724,1015						
Primestat			0454				
Printz	0015,0026,1013						
Prinz		0755					
Profekt	0711						
Profex	0019,0023,0024,0026 0033,0097,0233	0759					
Profitronic	0041,0096,0175,0711 1032						

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Progresson	0033						
Proline	0019,0031,0187,0711 0746	0755					
Prontech	0019						
Prosat	0001		0405,0451,0479 0511,0523				
Prosonic	0026,0705,0711,0730	0755					
Protech	0026,0033,0159,0175 0254,0711,0738						
Protek			2022				
Proton					0553		
Provision	0175,0711		0514				
PSR			0858				
Ptt_telcom			2026				
PYE	0711	0320					
Pygmy	0155						
Quadra Vision	0739						
Quadral			0511,0523				
Quartz		0314					
Quelle	0004,0005,0006,0007 0008,0009,0010,0011 0013,0015,0016,0018 0019,0023,0026,0027 0028,0031,0033,0043 0044,0045,0050,0051 0052,0054,0064,0069 0074,0078,0087,0088 0094,0097,0105,0110 0120,0126,0127,0139 0151,0153,0159,0170 0175,0187,0191,0197 0199,0221,0231,0232 0233,0234,0235,0236 0258,0711,0722,0724 0738,1004,1005,1008 1009,1011,1012,1013 1015,1030,1046,1049 1050	0272 0275 0278 0286 0298 0369	0371,0372,0383 0520				
Quasar	0006,0043,0045,0724 1032						
R-Line	0711						
Radialva	0026,0711,0731	0758					
Radiola	0242,0711		0499				
Radiomarelli	0000,0015,0026,0033 0057,0155,0169,1032						
Radionette	0005,0013,0082,0221						
Radiotone	0033,0159,0175,0254 0705,0711,0740,1015				0549		
Radix			0409,0428,0430 0487				
Rainbow			0521				
Raite						0684	

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Rank (UK)	0022						
RBM (UK)	0019,0022,0041,0047 0094,0097						
RCA	0204,0210,0211,0735 0746	0349	0450,0818,0835			0602,0661 0667	
RC-AK			0456				
RE			0386				
Realistic	0013						
REC						0685	
Record	0001,0026,0169,0175 0711						
Redder	0001						
Rediffusion (UK)	0005,0041,0116,0745						
Redstar						3030	0670
Reflex	0191,0711						
REX	0011,0021,0032,0078 0079,0118	0273,0292 0319					
Revox	0026,0027,0711						
RFT	0005,0039,0155,0156 0254,1032,1046		0499,0511				
Rhapsody	0730						
Riz	0019						
RM (RM2200)			0860				
Roadstar	0019,0026,0033,0039 0159,0711,0731	0758				0685 0689	
Rosita	0033,1015						
ROTEL					0553,0582 0583		0584 (TAPE)
Rover			0523				
Rowa	0033						
Royal Lux	0033,0039,0163,0169 0175,0219,0719,0740 0741,1015	0759					
RTG.(SpaceNet)			0846				
SABA	0000,0028,0065,0067 0070,0075,0082,0084 0085,0098,0099,0100 0103,0117,0155,0185 0186,0222,0224,0722 0733,0735,0737,0745 0746,1024,1025,1026 1027,1044	0270,0273 0279,0292 0295,0318 0319,0321 0326,0337 0338	0514,0520				
SAE					0553		
Sagem	0717,0742		0805,2028				
Sainel	0019						
Saisho	0004,0006,0015,0028 0039,0088,0097,0182 0187,0244	0286,0287 0322,0332 0360,0760					
Sakai	0004						
Sakio	0033,1015						
Sakura			0397,0398				

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Salora	0004,0005,0043,0047 0048,0055,0066,0068 0069,0074,0076,0082 0086,0087,0097,0105 0162,0177,0195,0249 0250,0267,0268,0745 1011,1012	0283,0285 0314	0391,0418				
Sambers	0000,0001,0004,0006 0008,0009,0024,0029 0030,0043,0045,0724 1032						
Sampo						0688	
Samsung	0004,0006,0026,0031 0033,0043,0145,0159 0160,0163,0170,0175 0212,0215,0702,0703 0711,0716,0730,1015 1018,1019,1039,1040 1042,1052	0289	0426,0459,0475 0476,0801,0805 0877			0637 0666 3028	0666
Sandra	0000,0004,0730						
Sandor	1047						
Sansui	0711	0320,0759 0760			0603	0686	
Sanwa		0756					
Sanyo	0004,0013,0028,0031 0033,0044,0057,0074 0119,0120,0121,0122 0123,0155,0162,0167 0170,0182,0195,0205 0711,0730,1024	0291,0314 0316,0339			0539,0604 0606	0681	
SAT 100			0371,0372,0488				
Satcom			0426,2026				
Saville		0757					
Sstcom			0516,0520				
Sateco			0386,0426				
Satline			0523				
Satmaster			0476				
Satpartner			0426,0514,0521				
SBR	0711						
Schacke			0521				
Schaub Lorenz	0005,0033,0039,0168 0177	0755					
Schneider	0004,0005,0006,0011 0015,0019,0023,0025 0026,0033,0036,0038 0039,0057,0151,0159 0191,0255,0258,0262 0711,0724,0731,0737 0738,1013,1015,1020 1031,1032,1038,1041 1046	0278,0281 0289,0755 0758	0424			0679	
Schwaiger			0516				

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Scientific Atlanta			0452				
Scott	0026,0037						
Sears		0315					
Sector			0511				
Sedeia			0426				
Seemann			0506				
SEG	0004,0019,0024,0026 0033,0039,0096,0145 0146,0156,0159,0177 0711,0724,0730,0738 0744,1015	0281,0289 0759	0426,0516			0684	
Sei-Sinudyne	0006,0015,0016,0026 0039,0057,0088,0155 0187,0197,1001,1003 1013,1032,1046	0756					
Seiko	0168						
Seleco	0005,0007,0011,0019 0026,0041,0044,0058 0077,0078,0082,0101 0175,0197,0722,1013 1046	0309,0758	0426,0512				
Senday	0026						
Senta		0277					
Sentra	0005,0039,0142,0707 0731						
Serino	0717,0742						
SET			0825,0837,0838 0839				
Sharp	0044,0054,0119,0124 0196,0198,0225,0227	0301,0302 0341,0758			0531,0550 0566	0628 3010	
Sherwood					0540,0541 0577,0578		
Shinton	0159,0175	0356					
Shintoshi	0175						
Shiva	0044	0758					
Shivaki	0019,0026,0175						
Shorai	0016						
SHOV	0033						
Siam	0711						
Siarem	0000,0025,0028,0029 0057,0096,0155,1032						
Sicatel	0001,0019						
Sice	0010						
Sidec	0019						
Siemens	0010,0018,0026,0054 0120,0231,0232,0233 0234,0235,0236,0711 0724,1005	0272,0275 0291,0369	0383				
Siera	0711						
Siesta	0254						
Sigma			2007				

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Signal			0456,0850,0855				
Silelis	0019						
Silma	0159						
Silva	0004,0033,0044,0724 0730,1015						
Silver	0016,0039,0044,0160 0711,1015						
Singer	0000,0004,0025,0026 0029,0033,0057,0146 0147,0149,0155,0168 0175,0711,0739,1032 1047						
Sintrack			0427				
Sinudyne	0006,0016,0025,0026 0029,0057,0109,0125 0155,0192,0197,0711	0278,0287					
Sirel	0000						
Skardin			0821,0822,2002		0644		
Sky	0711						
Sky bird			0386				
Sky Box			2007				
Sky digital			0880,0881				
Skylab			0373				
Sky master			0462,0479,0511 0513,0516,0523 0825,0827,0855 0880,0882,0883 2027			0638 0656	
Sky max			0424,0499				
Skysonic	0718						
Skytronic	0033						
Skyvision			0512				
SL			0497				
Slava	0004						
Smarago	0744						
Sogera	0037						
Sokol						3025	
Solavox	0005,0087,0745,1013						
Solonor	0082,1047						
Sonawa	0731						
Sonicx	0026						
Sonitron	0004,0074						
Soniko	0026						
Sonneclair	0037						
Sonoko	0004,0026,0033,0163 0175,1015						
Sony	0028,0044,0119,0126 0127,0128,0129,0130 0182,0199,0228,0260	0298,0299 0340,0342 0343,0344 0367,0750	0472,0804,0834		0556,0557 0575,0607 0617	0575 0621 0631 0657 3020	0563(TAPE) 0575(CDV) 0618(TUNE)

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Sonor	0739						
Sontec	0026,0033,0159,0170 0175,1015	0758					
Sound Color	0026,0175,0262						
Sound & Vision	0731						
Sound master	0033						
Soundwave		0758					
Sowtech	0170						
Spectra	0168,0175						
Standard	0004,0033,0037,0039 0159,0168,0172,0175 0731						
Star			0459,0470,0802 0846,0868,0871 0875				
Starlite	0033,0175	0758					
Starlux	0033						
Stenway	0039,0731						
Stern	0078						
Strato	1015						
Strong			0399,0423,0426 0480,0492,0514 0521,0864,0865 0868,2023				
STS			0393				
STV			0413				
Stvi	0004,0019						
Stylandia	0033,0039						
Sumida			0506				
Sunkai	0016,0028,0088,0711 0731,0742,0744,1001	0760					
Sunstar	0033,0159,0705	0755	0497,0506				
Suntronic		0755					
Sun Moon Star			0813				
Super Max			0846,0848,0849 0850				
Superla	0000,0019,0730						
SuperTech	0015,0023,0026,0033 0039,0159,0175,0730 0731,1015						
Supex			0858,0862,0869				
Supra	0026,0033,0168	0758					
Susumu	0735						
Syc Line	0033						
Sydney	0002,0730						
Sylvania					0553,0604		
Symphonic		0755					
Sytong	0730						
Tactics	0004						
TADA				0448			

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Tadiran			0817				
Tadistar	0169,0175						
Tagra			0512				
Tai Wah.	0218,0219						
Taisho	0019	0756					
Tanaki	0001						
Tandberg	0000,0007,0016,0156 0180,0197,0266,1013 1025,1026,1027	0322	0424				
Tandy	0047,0731,1047						
Tantec			0396				
Tashiko	0004,0026,0042,0097 0730	0755,0758					
Tatung	0002,0004,0026,0028 0031,0044,0097,0131 0175	0278,0755 0757,0760				0659	
Taurus	0019						
Tay Shoen				0517			
Teac	0004,0052,0712,0740 0742	0755,0758			0608,0611	0634	
Tec	0004,0006,0011,0019 0023,0026,0033,0145 0159,0168,0735,0743 1013						
Tecco	0004,0033,0145,1025						
Techica	0731						
Techline	0096,0738						
Technema	0037						
Technica	0039						
Technics	0110,1050				0542,0558 0609		0639
Technikus			0386				
Techniland			0512				
Technisat	0026,0156	0760	0409,0426,0428 0429,0430,0431 0487,0499,2018				
Technosat			0263,0386,0467 0802,0869				
Technovision	0263						
Technowelt			0520				
Tecnison	0004,0033,0175						
Teco			0506				
Tedelex	0033		0466				
Teinel	0019,0026						
Teknant	0026,0033						
Teknika			0471				
Tekon	0033						
Telasat			0516				
Tele +1	0248						
Teleavia	0186,0733						

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Teleciel			0521				
Telecom			0386,0884				
Telecor	0731						
Telefunken	0019,0054,0067,0075 0098,0132,0133,0134 0135,0140,0145,0165 0185,0186,0231,0235 0722,0733,0735,0737 0743,0746,1004,1005 1024,1025,1026,1027 1035,1037,1044	0270,0273 0279,0292 0318,0319 0321,0323 0330,0345 0346,0347	0426				
Telegazi	0731						
Teleka			0506,0521				
Telemaster			0514				
Telemax			0432				
Telemeister		0359	0398,0409,0428 0430,0469,0487				
Teleopta	0033						
Telepac	0033						
Telerent	0027						
Telesat			0516				
Teleservice	0203,0246						
Telestar	0169,0175					3031,3032	
Teletech	0033,0145,0738	0755,0759	0513				
Teleton	0004,0011,0047,0078						
Televideon	0730						
Televiso	0739,1047						
Telewire			0386,0512				
Teleexa	0096						
Tensai	0004,0013,0016,0019 0026,0033,0037,0039 0057,0096,0159,0168 0172,0175,0178,0221 0262,0724,0731,1032 1046	0755,0756 0758,0759					
Tenson	0037						
Tennessee	0026						
Tesla	0001,0019						
Tetran	0037						
Tevion	0738	0760				0683	
Thomson	0000,0001,0004,0019 0037,0045,0047,0065 0067,0070,0075,0077 0078,0098,0100,0103 0117,0159,0185,0186 0222,0224,0711,0722 0733,0735,0737,0743 0744,0746,1024,1025 1026,1027,1029,1036 1044	0270,0273 0279,0292 0318,0323 0324,0328	0372,0520,0804 2009,2017			0668	0668

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Thorn-Ferguson	0001,0002,0004,0005 0006,0010,0013,0019 0022,0026,0028,0031 0033,0041,0042,0044 0045,0052,0054,0074 0077,0084,0111,0120 0126,0127,0135,0136 0137,0140,0141,0142 0144,0148,0152,0159 0160,0175,0185,0186 0191,0221,0229,0256 0722,0735,1012,1013 1015,1024,1025,1031 1037	0270,0273 0300,0303 0304,0305 0306,0308 0319,0329 0330,0348 0368,0758	0371,0372,0394 0395,0400,0401 0402,0433,0485				
Thundermax			0424				
Ticsonic	0004						
TMK		0286					
Tobo	0033						
Togoshi	0044						
Tokai	0019	0758	0499			0684	
Tokyo	0707,0730						
Tomashi	0731						
Tomita	0004						
Tonna			0386,0512				
Topfield			2024				
Topline		0760					
Top Vision	0019						
Toshiba	0004,0022,0042,0044 0052,0094,0119,0138 0139,0141,0142,0707 0732,1049,1051	0273,0292 0307	0442,0444,0833	0522		0571,0640	
Towada	0019,0096	0759					
Toyosi	0001						
TPS			0805				
Tr.Continents	0000,0041						
Trans				0518			
Transonic	0026,0742						
Transtec	0730						
Trevi	0033,0039,0163						
Trilux	0175,0189,0714						
Tristar	0039,0731,1015						
Triumph	0006,0009,0724,0732						
Tronic	0004,0033,0168						
Trwam TV			2005				
Uher	0011,0012,0027,0036 0037,0038,0078,0096 0159,0255,1020	0273,0289 0758					

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Ultravox	0003,0004,0025,0026 0037,0057,0082,0096 0146,0155,0159,0175 0730	0276	0386				
Unbranded			0481				
Unic	0000,0004,0019						
Unic-Radio	0170						
Uniden			0403,0404,0406 0443,0830,0831				
Unimor	0175						
United Satellite			0440,0499,0506				
Unitor			0373				
Universum	0004,0005,0006,0007 0009,0010,0011,0013 0015,0016,0018,0019 0023,0026,0027,0028 0031,0033,0043,0044 0045,0052,0054,0064 0074,0078,0087,0088 0094,0097,0105,0110 0120,0126,0127,0139 0151,0159,0160,0170 0175,0187,0191,0197 0199,0221,0232,0233 0234,0235,0258,0722 0724,0738,0741,1004 1005,1008,1009,1011 1012,1013,1015,1030 1046,1049,1050	0755,0758 0759,0760	0371,0372,0520			0682	
Univox	0001,0019,0026,0175						
Unk	0019,0026,0031,0159						
US Electronics			0417				
Utax	0004						
Vanguard	0004,0047						
Vector		0313	0430,0487				
Vectra	0175						
Veco	0175						
Vegavox	0169						
Ventana			0424,0499				
Vestel	0023,0026,0159,0711						
Vexa	0004,0039,0159,0163 0175						
Victor		0318,0328 0366			0605		
Video		0313					
Videocon	0033,0138,0141,0715						
Videologic	0004,0039						
Videoton	0001,0004,0019,0023 0047,0169,1024						
Videologique	0730,0731						
Videosat	0145						

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Videosysyem	0159						
Videotechnic	0730						
Vidicron	0026,0037						
Viewstar			0477				
Visiola	0730						
Vision	0037,0159		2029				
Visionrex	0000						
Vortec			0426,0459,0476 0801,0855				
Vortic Star			0801				
Voxson	0032,0041,0045,0155						
Vtech			0434,0507				
Walkie	0011						
Waltham	0001,0004,0015,0019 0023,0026,0159,0169 0172,0175,0733,1024						
Wamishi	0742						
Watson	0006,0026,0037,0039 0041,0057,0159,0175 0705,0731,0738,1005 1015	0757					
Watt Radio	0001,0003,0004,0015 0023,0025,0029,0030 0057,0159,0170,0730 1032						
Wega Color	0044,0119,0143						
Wegavox	0023,0169						
Wela			0497				
Weltblick	0026,0037,0175	0758					
Wharfedale	0718					0687	
White Westinghouse	0003,0004,0009,0019 0024,0026,0037,0078 0096,0159,0169,0170 0175,0730	0276,0282					
Wesder						0689	
Weston	0019						
WeTeKom			0516				
Wilson						3014	
Winco	0740						
Winer			0080,0387,0449 0844	0501			
Wintergarten			0511				
Winternitz	0168		0372				
Winston	0039,0163,0175						
WISI			0409,0420,0435 0436,0437,0438 0439				
WISO				0503 0504			
Worldtech	0159						

Brand/Device	TV/TXT	VCR	SAT/DSS	Cable	HIFI/CD	LD/DVD	AUX
Xoro						3017	
Woorisat			0514				
Wittenberg			0371				
Xsat			0812,2019				
Xcellent	0175						
Xenon		0322					
Xonycs	0026,0175						
Xrypton	0026,0175						
Yakumo						3018	
Yamaha	0026				0543,0544 0612	0684,3026	0675
Yamakawa						3016	
Yamishi	0731						
Yoko	0004,0019,0026,0039 0097,0159,0168,0730 0731,0741,1009,1015	0758					
York	0039						
Yorx	0731						
Zampa	0101						
Zanussi	0078						
Zehnder			0390,0507,0514				
Zenith	0203,0237		0441,0444,0445 0446,0447			0570,0682	
Zinwell			0821				
Zodica			0521				
Zwergnase			0506				
Others	0206,0207,0208,0264 0265,1002,1006,1014 1016,1017,1028,1034	0350,0351 0352,0353	0820,0861,2025			0674	