

Media Player

Reference Guide GB

Guide de référence FR

Referenzanleitung DE

WARNING

To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

To reduce the risk of fire or electric shock, do not expose this appliance to dripping or splashing, and do not place objects filled with liquids, such as vases, on the appliance.

To reduce the risk of fire, do not cover the ventilation opening of the appliance with newspapers, tablecloths, curtains, etc. Do not expose the appliance to naked flame sources (for example, lighted candles).



To avoid electric shock, do not open the cabinet. Refer servicing to qualified personnel only.

CAUTION

Danger of explosion if battery is incorrectly replaced.

Replace only with the same or equivalent type.

Do not expose batteries or appliances with battery installed to excessive heat, such as sunshine and fire.



This symbol is intended to alert the user to the presence of uninsulated “dangerous voltage” within the product’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

These graphical symbols are located on the AC adapter.

Notice for customers in the United Kingdom and Republic of Ireland

A molded plug complying with BS1363 is fitted to this equipment for your safety and convenience.

Should the fuse in the plug supplied need to be replaced, a fuse of the same rating as the supplied one and approved by ASTA or BSI to BS1362, (i.e., marked with or mark) must be used.

If the plug supplied with this equipment has a detachable fuse cover, be sure to attach the fuse cover after you change the fuse. Never use the plug without the fuse cover. If you should lose the fuse cover, please contact your nearest Sony service station.



Disposal of waste batteries and electrical and electronic equipment (applicable in the European Union and other European countries with separate collection systems)

This symbol on the product, the battery or on the packaging indicates that the product and the battery shall not be treated as household waste. On certain batteries this symbol might be used in combination with a chemical symbol. The chemical symbols for mercury (Hg) or lead (Pb) are added if the battery contains more than 0.0005% mercury or 0.004% lead. By ensuring these products and batteries are disposed of correctly, you will help prevent potentially negative consequences for the environment and human health which could otherwise be caused by inappropriate waste handling. The recycling of the materials will help to conserve natural resources.

In case of products that for safety, performance or data integrity reasons require a permanent connection with an incorporated battery, this battery should be replaced by qualified service staff only. To ensure that the battery and the electrical and electronic equipment will be treated properly, hand over these products at end-of-life to the applicable collection point for the recycling of electrical and electronic equipment. For all other batteries, please view the section on how to remove the battery from the product safely. Hand the battery over to the applicable collection point for the recycling of waste batteries. For more detailed information about recycling of this product or battery, please contact your local Civic Office, your household waste disposal service or the shop where you purchased the product or battery.

For customers in Canada, Mexico and Brazil

The above symbol is applicable in the European Union and other European countries with separate collection systems.

Notice for customers:

The following information is only applicable to equipment sold in countries applying EU directives.

This product has been manufactured by or on behalf of Sony Corporation, 1-7-1 Konan Minato-ku Tokyo, 108-0075 Japan. Inquiries related to product compliance based on European Union legislation shall be addressed to the authorized representative, Sony Deutschland GmbH, Hedelfinger Strasse 61, 70327 Stuttgart, Germany.

For any service or guarantee matters, please refer to the addresses provided in the separate service or guarantee documents.

The validity of the CE marking is restricted to only those countries where it is legally enforced, mainly in the countries EEA (European Economic Area).



WARNING **DO NOT INGEST BATTERY, CHEMICAL BURN HAZARD**

The remote control supplied with this product contains a coin/button cell battery. If the coin/button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.

Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children.

If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

This equipment has been tested and found to comply with the limits set out in the EMC Directive using a connection cable shorter than 3 metres.

Precautions

- The player is not disconnected from the AC power source (mains) as long as it is connected to the wall outlet, even if the player itself has been turned off.
- Install this unit so that the AC power cord can be unplugged from the wall socket immediately in the event of trouble.
- The nameplate is located on the bottom of the player.

Installing

Do not install this player in a confined space, such as a bookshelf or similar unit.

For customers in Canada

Sony Customer Support

<http://esupport.sony.com/CA/>


1-877-899-SONY

Please Call Before Returning the Product to the Store


On supplied AC power cords

Your Media Player is supplied with AC power cords with four different types of plugs. For your safety, use only the cord that is intended for use in your country/region. Never use other types of cords.


AC power cord (A): for customers in Canada and Mexico




AC power cord (B): for customers in the United Kingdom and Republic of Ireland



AC power cord (C): for customers in Brazil



AC power cord (D): for customers in other European countries



Precautions

On placement

- Place the player in a location with adequate ventilation to prevent heat build-up in the player.
- Do not place the player on a soft surface such as a rug that might block the ventilation holes.
- Do not place the player in a location near heat sources, or in a place subject to direct sunlight, excessive dust, or mechanical shock.
- Do not place the player outdoors, in vehicles, on ships, or on other vessels.
- If the player is brought directly from a cold to a warm location, or is placed in a very damp room, moisture may form on the outer surface and on interior of the player. Should this occur, the player may not operate properly. In this case, leave the player turned on for about half an hour until the moisture evaporates.
- Do not install the player in an inclined position. It is designed to be operated in a horizontal position only.
- Do not place heavy or unstable objects on the player.
- Disconnect the AC power cord and all other cables from the player when you move the player.
- Keep the player away from equipment with strong magnets, such as microwave ovens, or large loudspeakers.

On power sources

- Follow the procedure below when disconnecting the AC power cord.
 - ① Disconnect the LAN cable or pause the download by using the 4K application setting in the "Application" items of the player home menu.
 - ② Wait for about five minutes after turning the player off.
 - ③ Make sure that the hard disk drive is not operating (the power indicator and HDD indicator are off).
 - ④ Disconnect the AC power cord.
- Disconnect the player from the wall outlet if you are not going to use the player for a long time. To disconnect the AC power cord, grasp the plug itself; never pull the cord.

- Observe following points to prevent the AC power cord being damaged. Do not use the AC power cord if it is damaged, as doing so may result in an electric shock or fire.
 - Do not pinch the AC power cord between the player and wall, shelf, etc.
 - Do not put anything heavy on the AC power cord or pull on the AC power cord itself.

On AC adapter

- Use the supplied AC adapter for this player, as other adapters may cause a malfunction.
- Do not disassemble or reverse-engineer.
- Do not confine the AC adapter in a closed place such as a bookshelf or an AV cabinet.
- Do not connect the AC adapter to a traveler's electric transformer, which may generate heat and cause a malfunction.
- Do not drop or apply shock.

On adjusting volume

Do not turn up the volume while listening to a section with very low level inputs or no audio signals. If you do, your ears and the speakers may be damaged when a peak level section is played.

On cleaning

Clean the cabinet, panel, and controls with a soft cloth. Do not use any type of abrasive pad, scouring powder or solvent such as alcohol or benzene.


On replacement of parts

In the events that this player is repaired, repaired parts may be collected for reuse or recycling purposes.

On connecting to the HDMI jack

Observe the following as improper handling may damage the HDMI jack and the connector.

- Carefully align the HDMI jack on the rear of the player and the HDMI connector by checking their shapes. Make sure the connector is not upside down or tilted.



- Be sure to disconnect the HDMI cable when moving the player.



- Hold the HDMI connector straight when connecting or disconnecting the HDMI cable. Do not twist or force the HDMI connector into the HDMI jack.

IMPORTANT NOTICE

Caution: This player is capable of holding a still video image or on-screen display image on your television screen indefinitely. If you leave the still video image or on-screen display image displayed on your TV for an extended period of time, you risk permanent damage to your television screen. Plasma display panel televisions and projection televisions are susceptible to this.

If you have any questions or problems concerning your player, please consult your nearest Sony dealer.

About MPEG-4 AVC


THIS PRODUCT IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL USE OF A CONSUMER OR OTHER USES IN WHICH IT DOES NOT RECEIVE REMUNERATION TO (i) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC VIDEO") AND/OR (ii) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO.

NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE [HTTP://WWW.MPEGLA.COM](http://www.mpegla.com)

Replacing the battery of the remote control


Replace the battery in the remote control with a new one if it is low by following the steps below.

- 1 Pull out the battery compartment by pressing the button with a thin, sharp object such as the point of a pen.**



- 2 Replace the old battery with a new one.** Insert the new battery with the ⊕ side facing up.

CR2032 battery
manufactured by Sony



- 3 Close the battery compartment.**

Trademark Information

- The terms HDMI™ and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.
- Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.
- TUXERA is a registered trademark of Tuxera Inc. in the US and other countries.
- Other system and product names are generally trademarks or registered trademarks of the manufacturers. ™ and ® marks are not indicated in this document.



LEADING FILE SYSTEM INTEROPERABILITY

Specifications

Input/Output jacks	
HDMI OUT 1 (for AUDIO VIDEO)	HDMI 19-pin standard connector Video: 3840 × 2160 Frame rate: 24p, 25p, 30p, 50p, 60p Audio: Linear PCM, Dolby Digital, Dolby Digital Plus
HDMI OUT 2 (for AUDIO)	HDMI 19-pin standard connector Linear PCM, Dolby Digital, Dolby Digital Plus
LAN (100)	100 BASE-TX Terminal
EXTRA HDD	Rear USB port: For connecting external hard disk drive*1 *2
USB	Front USB port: For connecting USB memory*2
Power and others	
Power requirements	Input: DC 19.5 V, 1.6 A
Power consumption	On: 35 W Standby: 0.5 W*3
AC adapter	Input: 100 V - 240 V AC, 50/60 Hz, 1.0 A Output: DC 19.5 V, 4.35 A
Operating temperature	5 °C to 35 °C (41 °F to 95 °F)
Operating humidity	25% to 80%
Dimensions (approx.)	250 mm × 250 mm × 50 mm (9 7/8 in. × 9 7/8 in. × 2 in.) (width/depth/height) excl. projecting parts
Mass (approx.)	1.8 kg (4.0 lb.)
Accessories	
Supplied accessories	AC power cord (4)/AC adapter (1)/Remote control RMT-D304 with CR2032 battery (1) /Startup Guide, Reference Guide and Warranty card

*1 This function is not available in some countries/regions.

*2 For details on USB devices that can be connected to the player, see "Help Guide" (http://rd1.sony.net/help/hv/fmpx5/h_zz).

*3 The value represents approximate power consumption in ordinary operation. Standby power consumption may increase immediately after the power is turned off or while the software is being updated.

Specifications and design are subject to change without notice.

For customers in Canada

END USER LICENSE AGREEMENT

FOR CERTAIN SOFTWARE AND SERVICE TO BE USED WITH YOUR SONY PRODUCT

IMPORTANT – READ THIS AGREEMENT BEFORE USING YOUR SONY PRODUCT. USING YOUR PRODUCT INDICATES YOUR ACCEPTANCE OF THIS AGREEMENT.

If you do not agree to the terms of this EULA or Sony's applicable privacy policy, as amended from time to time by Sony in its discretion, Sony is unwilling to license the Sony Software (as defined below) to you and unwilling to allow you to access the Sony Services & Content (as defined below), and you should promptly contact Sony for instructions on the return of the entire Sony Product and included Sony Software for a refund of the purchase price of the Sony Product.

This End User License Agreement ("EULA") is a legal agreement between you and Sony Electronics Inc. ("Sony"), the licensor of the software (other than the software which is governed by other licenses as defined below, as "Excluded Software") included in this Sony Product and related materials which shall be collectively referred to as the "Sony Software." This EULA covers the Sony Software and that of Sony's affiliates and third party licensors ("Third Party Licensors") and accompanying printed or online documentation. The Sony Software includes software in your Sony Product, including updates or modified software, provided to you by Sony, whether stored on media or downloaded to the Sony Product via any method, but not Excluded Software as defined below.

Note: This EULA contains a binding individual arbitration clause and class action waiver. If you wish to opt out of these provisions, please follow the instructions in Section entitled "Resolving Disputes; Arbitration; Small Claims Waiver" below.

This Sony Product also includes the Sony Entertainment Network feature which provides access to selected content services ("Services") from third party content providers including Sony entities other than Sony Electronics Inc. ("Third Party Providers") as a courtesy to you. The Sony Entertainment Network feature also provides you access to selected Sony content services ("Sony Content Services"), which services and related content ("Sony Content") shall both be considered Sony Software under this EULA. The Sony Entertainment Network feature requires an Internet connection. Your ability to access the Services, and the quality of the Services presented, are subject to your Internet provider's service and terms as well as the broadband Internet connection speed you use. Your ability to access the Services, and the

quality of the Services presented, are subject to your Internet provider's service and terms. Video quality and picture size varies and is dependent upon the speed of your broadband service from your Internet provider and delivery by the Third Party Providers. The content, including but not limited to data, music, sound, audio, photographs, images, graphics, likenesses, software, text, video, messages, tags, or other materials, provided by Third Party Providers ("Content") and the availability of the Services are at the sole discretion and under the control of the Third Party Providers. The Content and Services of each Third Party Provider are provided pursuant to the terms and conditions of that Third Party Provider. Premium Content may require additional fees and/or registration with the Third Party Provider through a computer. The Services and the Content may only be used for your own personal, private viewing, and shall not be used for non-theatrical exhibition, or any viewing or exhibition for which (or in a venue in which) an admission, access, or viewing fee is charged, or for any public exhibition or viewing. The Services may be changed at any time and may be unavailable from time to time.

You understand, acknowledge and agree that access to certain Sony Product features, including but not limited to your ability to access the Sony Content & Services, requires an Internet connection for which you are solely responsible. You are solely responsible for payment of any third party fees associated with your Internet connection, including but not limited to Internet service provider or airtime charges. The quality of the Sony Content & Services presented is subject to your Internet provider's service and terms, and is also dependent upon the speed of your Internet service. Operation of the Sony Product and Sony Software, and access to the Sony Content & Services, may be limited or restricted depending on the capabilities, bandwidth or technical limitations of your Internet connection and service. You understand, acknowledge and agree that Internet connectivity is provided by third parties over which Sony has no control. The provision, quality, availability and security of such Internet connectivity, software and services are the sole responsibility of such third parties.

THE SONY SOFTWARE AND THE SERVICES MAY ALLOW SONY, THE THIRD PARTY PROVIDERS, AND/OR OTHER THIRD PARTIES TO COLLECT DATA FROM, CONTROL, AND/OR MONITOR THE SONY PRODUCT AND OTHER DEVICES RUNNING OR INTERACTING WITH THE SONY SOFTWARE.

SOFTWARE LICENSE

You cannot use the Sony Software except as specified herein. The Sony Software is licensed, not sold. Sony and its Third Party Licensors grant you a limited license to use the Sony Software only on the Sony Product. The Sony Software may create data files automatically for use with the Sony Software, and you agree that any such data files

are deemed to be a part of the Sony Software. The Sony Software is licensed as a single product, and you may not separate its component parts for use on more than one device unless expressly authorized by Sony. You agree not to modify, reverse engineer, decompile or disassemble the Sony Software in whole or in part or to use the Sony Software in whole or in part for any purpose other than allowed under this EULA. In addition, you may not rent, lease, sublicense, or sell the Sony Software, but you may transfer all of your rights under this EULA only as part of a sale or transfer of the Sony Product provided you retain no copies, transfer all of the Sony Software (including all copies, component parts, any media, printed materials, all versions and any upgrades of the Sony Software, and this EULA), and the recipient agrees to the terms of this EULA. Sony and its Third Party Licensors retain all rights that this EULA does not expressly grant to you. You shall not (a) bypass, modify, defeat, or circumvent any of the functions or protections of the Sony Software or any mechanisms operatively linked to the Sony Software; or (b) remove, alter, cover, or deface any trademarks or notices on the Sony Software. You understand, acknowledge, and agree that the software, network services, or other products other than the Sony Software upon which the Sony Software's performance may depend might be interrupted or discontinued at the discretion of the suppliers (software suppliers, service providers, Third Party Providers, etc.) or Sony.

EXCLUDED SOFTWARE

Notwithstanding the foregoing limited license grant, you acknowledge that the Sony Product includes software subject to other terms and conditions governing the use of such software other than this EULA ("Excluded Software"). Certain Excluded Software may be covered by open source software licenses ("Open Source Components"), which means any software licenses approved as open source licenses by the Open Source Initiative or any substantially similar licenses, including but not limited to any license that, as a condition of distribution of the software licensed under such license, requires that the distributor make the software available in source code format. Terms and conditions applicable to Open Source Components are provided to you together with this EULA and/or stored in your Device which may include but are not limited to the "Help" or "About" menus. Please visit <http://www.sony.net/Products/Linux> for a list of applicable Excluded Software included in this Sony Product from time to time, and the applicable terms and conditions governing its use. Such terms and conditions may be changed by the applicable third party at any time without liability to you. To the extent required by the licenses covering Open Source Components, the terms of such licenses will apply in lieu of the terms of this EULA. To the extent the terms of the licenses applicable to Open Source Components prohibit any of the restrictions in this EULA with respect to such Open Source Components, such

restrictions will not apply to such Open Source Component. To the extent the terms of the licenses applicable to Open Source Components require Sony to make an offer to provide source code in connection with the Software, such offer is hereby made.

USER ACCOUNT

As part of the agreement to allow you to access, browse, or use the Services and the Content, Third Party Providers and/or other third parties may require that you establish a user account ("Account") for which you must provide them with true, accurate, current, and complete information about yourself and maintain/promptly update such information. You are responsible for maintaining the confidentiality of any and all of your passwords associated with any such Account.

DATA COLLECTION

Any Services provided by affiliates of Sony Corporation and/or third parties that you access may also allow affiliates of Sony Corporation and/or third parties to collect data about you and/or about the use of that service. Sony Corporation does not control and is not in any way liable for such data collection and you should consult the relevant privacy policy for each such Service before using it.

SONY'S RIGHTS TO USER'S MATERIAL

If you send any communications or materials to Sony by electronic mail or otherwise ("Materials"), including any selections, comments, data, questions, suggestions, or the like, all such Materials are, and will be treated as, non-confidential and non-proprietary. Thus, you give up any claim that use of such Materials violates any of your rights including moral rights, privacy rights, proprietary or other property rights, rights of publicity, rights to credit for material or ideas, or any other right, including the right to approve the way Sony uses such Materials. Any Material may be adapted, broadcast, changed, copied, disclosed, licensed, performed, posted, published, sold, transmitted, or used by Sony anywhere in the world, in any medium, forever and without attribution or compensation to you. Furthermore, you hereby assign all right, title, and interest in, and Sony is free to use, without any compensation to you, any ideas, know-how, concepts, techniques, or other intellectual property rights contained in the Materials, whether or not patentable, for any purpose whatsoever, including but not limited to developing, manufacturing, having manufactured, licensing, marketing, and selling products using such Materials. However, you agree and understand that Sony is not obligated to use any such ideas, know-how, concepts, or techniques or Materials, and you have no right to compel such use.

TRANSMITTED MATERIAL

Internet transmissions are never completely private or secure. You understand that any message or information you send to Sony may be read or intercepted by others, unless there is a special

notice that a particular message (for example, credit card information) is encrypted (sent in code). Sending a message to Sony does not cause Sony to have any special responsibility to you.

ADVERTISEMENTS, SERVICE COMMUNICATIONS

Inclusion of the Service of a Third Party Provider does not mean that Sony approves of, or endorses, or recommends that Third Party Provider or its Content. You understand and agree that the Services and/or Content may include advertisements ("Advertisements"), and that these Advertisements are necessary in order for the Services to be provided. If you use the Sony Entertainment Network service, the SEN and/or PSN Terms of Use/Service and the SEN and/or PSN Privacy Policy for your country will apply and you will be required to agree to them. You understand and agree that use of that service (and other services available through it) as well as other services than those provided by Sony Entertainment Network may result in you receiving or being shown recommendations and/or advertisements, service announcements, administrative messages, news updates and the like which Sony Corporation is not responsible nor liable for. SONY, ITS AFFILIATES, AND ITS THIRD PARTY PROVIDERS DISCLAIM ALL WARRANTIES, EXPRESS OR IMPLIED, AS TO THE ACCURACY, LEGALITY, RELIABILITY, OR VALIDITY OF ANY ADVERTISEMENT, SERVICE COMMUNICATIONS, OR CONTENT, AS WELL AS ANY LIABILITY ARISING UNDER ANY THEORY OF LAW FOR THE ADVERTISEMENTS, SERVICE COMMUNICATIONS, AND CONTENT.

OBJECTIONABLE CONTENT AND RULES FOR MINORS (UNDER AGE 16)

Certain Content may not be suitable for minors or other users. Such Content may or may not be rated or identified as having explicit language, or otherwise being for a mature audience. Therefore, you acknowledge that you are using the Services at your own risk and that Sony has no liability to you for the Content, including any Content that may be offensive. You are responsible for supervising the use of the Sony Product, the Sony Software, Excluded Software, the Services, and the Content by any minor. If you are under the age of 16, you should ask your parent(s) or a guardian before you: (i) e-mail Sony via the Service; (ii) send in any information; (iii) enter any contest or game that requires information about you or offers a prize; (iv) join any club or group; (v) post any information on any bulletin board or enter any chatroom; or (vi) buy anything online.

EXCLUSION OF WARRANTY

YOU UNDERSTAND, ACKNOWLEDGE, AND AGREE THAT THE CONTENT AND SERVICES ARE PROVIDED BY THIRD PARTY PROVIDERS AND/OR SOFTWARE IS PROVIDED BY THIRD PARTIES OVER WHICH SONY HAS NO CONTROL. THE SELECTION, PROVISION, QUALITY, PICTURE SIZE, AND AVAILABILITY OF SUCH CONTENT AND/OR SOFTWARE ARE THE SOLE RESPONSIBILITY OF SUCH THIRD PARTY PROVIDER

OR OTHER THIRD PARTY. YOU AGREE TO COMPLY WITH ANY AND ALL TERMS AND CONDITIONS THAT THE THIRD PARTY PROVIDERS MAY SET FOR ITS SERVICE, CONTENT AND/OR SOFTWARE. YOU FURTHER UNDERSTAND, ACKNOWLEDGE, AND AGREE THAT ACCESS, BROWSING, AND USAGE OF THE SERVICES REQUIRES INTERNET SERVICE PROVIDED BY YOU, AND FOR WHICH YOU ARE SOLELY RESPONSIBLE, INCLUDING BUT NOT LIMITED TO THE PAYMENT OF ANY THIRD PARTY FEES (SUCH AS INTERNET SERVICE PROVIDER OR AIRTIME CHARGES) FOR SUCH ACCESS AND FOR DISPLAY OR DELIVERY OF ADVERTISEMENTS INCLUDED WITH THE SERVICES. OPERATION OF THE SONY ENTERTAINMENT NETWORK FEATURE AND THE SERVICE MAY BE LIMITED OR RESTRICTED DEPENDING ON THE CAPABILITIES, BANDWIDTH OR TECHNICAL LIMITATIONS OF YOUR INTERNET SERVICE. SONY, ITS AFFILIATES, AND ITS THIRD PARTY PROVIDERS SHALL HAVE NO RESPONSIBILITY FOR THE TIMELINESS, DELETION, MIS-DELIVERY, OR FAILURE TO STORE ANY USER COMMUNICATIONS OR PERSONALIZED SETTINGS.

THE SONY SOFTWARE AND ACCOMPANYING DOCUMENTATION, THE SERVICES, AND THE CONTENT ARE FURNISHED TO YOU "AS IS" AND WITHOUT WARRANTIES OR CONDITIONS, STATUTORY OR OTHERWISE, OF ANY KIND. SONY, ITS AFFILIATES, ITS THIRD PARTY LICENSORS, AND ITS THIRD PARTY PROVIDERS EXPRESSLY DISCLAIM ALL WARRANTIES AND CONDITIONS, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, TITLE, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE. SONY, ITS AFFILIATES, ITS THIRD PARTY LICENSORS, AND ITS THIRD PARTY PROVIDERS DO NOT WARRANT THAT THE SONY SOFTWARE OR ACCOMPANYING DOCUMENTATION, THE SERVICES, OR THE CONTENT WILL MEET YOUR REQUIREMENTS OR THAT THE OPERATION OF THE SONY SOFTWARE, THE SERVICES, OR THE CONTENT WILL BE UNINTERRUPTED OR ERROR FREE. FURTHERMORE, SONY, ITS AFFILIATES, ITS THIRD PARTY LICENSORS, AND ITS THIRD PARTY PROVIDERS DO NOT WARRANT OR MAKE ANY REPRESENTATIONS OR CONDITIONS REGARDING THE USE OR THE RESULTS OF THE USE OF THE SONY SOFTWARE, THE SERVICES OR THE CONTENT IN TERMS OF ITS CORRECTNESS, ACCURACY, RELIABILITY OR OTHERWISE. NO ORAL OR WRITTEN INFORMATION OR ADVICE GIVEN BY SONY, ITS AFFILIATES, OR A SONY AUTHORIZED REPRESENTATIVE SHALL CREATE A WARRANTY OR CONDITION, OR IN ANY WAY CHANGE THIS EXCLUSION OF WARRANTY AND CONDITION. SHOULD THE SOFTWARE, MEDIA ON WHICH THE SOFTWARE IS FURNISHED, DOCUMENTATION, THE SERVICES, OR THE CONTENT PROVE DEFECTIVE, YOU (AND NOT SONY OR A SONY AUTHORIZED REPRESENTATIVE) ASSUME THE ENTIRE COST OF ALL NECESSARY SERVICING, REPAIR, OR CORRECTION.

LIMITATION OF LIABILITY

IN NO EVENT WILL SONY (INCLUDING BUT NOT LIMITED TO ANY NEGLIGENCE ISSUES RELATED TO THIRD PARTY LICENSORS OR THIRD PARTY PROVIDERS), ITS AFFILIATES, ITS THIRD PARTY LICENSORS OR ITS THIRD PARTY PROVIDERS BE LIABLE TO YOU FOR ANY SPECIAL, INDIRECT, INCIDENTAL, PUNITIVE, EXEMPLARY, OR CONSEQUENTIAL DAMAGES OF ANY KIND, INCLUDING BUT NOT LIMITED TO COMPENSATION, REIMBURSEMENT OR DAMAGES IN CONNECTION WITH, ARISING OUT OF OR RELATING TO THIS EULA, ON ACCOUNT OF THE LOSS OF USE OF THE SONY PRODUCT, DOCUMENTATION, THE SERVICES, THE CONTENT, DOWN TIME AND YOUR TIME, LOSS OF PRESENT OR PROSPECTIVE PROFITS, LOSS OF DATA, INFORMATION OF ANY KIND, BUSINESS PROFITS, OR OTHER COMMERCIAL LOSS, OR FOR ANY OTHER REASON WHATSOEVER, EVEN IF SONY, ITS AFFILIATES, ITS THIRD PARTY LICENSORS, OR ITS THIRD PARTY PROVIDERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. THE SONY SOFTWARE AND ACCOMPANYING DOCUMENTATION, THE SERVICES, AND THE CONTENT ARE FURNISHED TO YOU FOR USE AT YOUR OWN RISK. SONY, ITS AFFILIATES, ITS THIRD PARTY LICENSORS, AND ITS THIRD PARTY PROVIDERS WILL NOT BE LIABLE FOR DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY OR CONDITION, BREACH OF CONTRACT, NEGLIGENCE, STRICT LIABILITY OR ANY OTHER LEGAL THEORY RELATED TO THE SONY SOFTWARE, THE SERVICES, THE CONTENT, OR THIS EULA.

Some jurisdictions may not allow exclusions or limitations of incidental or consequential damages, exclusions or limitations of implied warranties or conditions, or allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you.

LIMITED WARRANTY ON MEDIA

In situations where the Sony Software or any part thereof is furnished on media, Sony warrants that for a period of ninety (90) days from the date of its delivery to you, the media on which the Sony Software is furnished to you will be free from defects in materials and workmanship under normal use. This limited warranty extends only to you as the original licensee. Sony's entire liability and your exclusive remedy will be replacement of the media not meeting Sony's limited warranty. ANY IMPLIED WARRANTIES OR CONDITIONS ON THE MEDIA, INCLUDING THE IMPLIED WARRANTIES AND CONDITIONS OF MERCHANTABILITY, TITLE, NON-INFRINGEMENT, AND/OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO NINETY (90) DAYS FROM THE DATE OF DELIVERY. SOME JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY OR CONDITION LASTS, SO THESE LIMITATIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM JURISDICTION TO JURISDICTION.

FEES

Sony and its Third Party Providers reserve the right at any time to charge fees for access to new Content or new Services or to portions of the existing Content or Services, or the Services as a whole. In addition, Third Party Providers may charge fees for access to their Content. In no event will you be charged for access to any portion or all of the Content and/or the Services unless Sony and/or a Third Party Provider obtain your prior agreement to pay such charges. If you do not consent to such charges, however, you may not have access to paid Content or Services for which such charges apply.

INTELLECTUAL PROPERTY / NOTICE FOR CLAIMS OF INTELLECTUAL PROPERTY VIOLATIONS AND AGENT FOR NOTICE

Sony respects the intellectual property rights of others, and we ask you to do the same. It is Sony's policy, at its discretion as appropriate, (a) to terminate and/or disable the Content of Third Party Providers or users of the Services who may infringe or repeatedly infringe the copyrights or other intellectual property rights of Sony, its Third Party Providers or others; and/or (b) to forward reports of intellectual property rights violations to Third Party Providers and others for review and action per the terms of such Third Party Provider's procedures for protection of intellectual property rights. The Sony Software and Content are protected by copyright laws and international copyright treaties, as well as other intellectual property laws and treaties. There may be proprietary logos, service marks, trademarks, likenesses, and trade names found in the Sony Software, the Content, or on the Services. By making the Sony Software and Content available on the Services, Sony and the Third Party Providers are not granting you any license to utilize those proprietary logos, service marks, trademarks, likenesses, or trade names. Any unauthorized use of the Sony Software, the Services, or the Content may violate copyright laws, trademark laws, the laws of privacy and publicity, and civil and criminal statutes. All right, title, and interest in and to the Sony Software and the Content, and any and all copies or portions thereof, are owned by Sony, its licensors, Third Party Licensors, suppliers and/or Third Party Providers. All rights not specifically granted under this EULA are reserved by Sony, its licensors, Third Party Licensors, suppliers and/or Third Party Providers.

You are responsible for all your activities hereunder, including all legal liability incurred from access, browsing, or use of the Services by you or by others who use the Services via your Sony Product or Account (as defined in the User Account section). You may use the Sony Software, the Services, and the Content for lawful purposes only. You may not distribute, exchange, modify, sell, or transmit anything you may copy from the Sony Software, the Services, or the Content, including but not limited to any data, text, software,

likenesses, photographs, images, graphics, audio, music, sound, video, messages, and tags, for any business, commercial, or public purpose. As long as you comply with the terms of this EULA, Sony grants you a nonexclusive, nontransferable, limited right to use the Sony Entertainment Network feature to access the Services and the Content as set forth in this EULA. You further agree not to interrupt/disrupt or attempt to interrupt/disrupt the operation of the Sony Software, the Service or the Content in any way.

If you believe your work has been copied in a way that constitutes copyright infringement, or that your intellectual property rights have otherwise been violated, please first contact the Third Party Provider for the particular Service. If you are unable to contact such Third Party Provider, or the content at issue is Sony's, you may contact Sony's Intellectual Property Agent (listed below) with the following information in a written notice: (a) an electronic or physical signature of the person authorized to act on behalf of the copyright or other intellectual property interest; (b) a description of the copyrighted work or other intellectual property that you claim has been infringed; (c) a description of the particular Service and where the material that you claim is infringing is located on such Service, with enough detail that we may find the material; (d) your address, telephone number, and e-mail address; (e) a statement by you that you have a good faith belief that the disputed use is not authorized by the copyright or intellectual property owner, its agent, or the law; and (f) a statement by you, made under penalty of perjury, that the above information in your notice is accurate and that you are the copyright or intellectual property owner or authorized to act on the copyright or intellectual property owner's behalf. Sony's agent for notice of copyright or other intellectual property right infringement is as follows: Intellectual Property Agent, c/o Sony Electronics Inc., 16530 Via Esprillo, San Diego, CA 92127; Facsimile (858) 942-1111; E-Mail IPagent@am.sony.com

INDEMNIFICATION

You agree to indemnify, defend, and hold harmless Sony and all of its agents, directors, officers, employees, information providers, licensors and licensees, affiliates, content providers, and direct and indirect parent(s) (collectively, "Indemnified Parties") from and against any and all liability and costs (including, without limitation, attorneys' fees and costs) incurred by the Indemnified Parties in connection with any claim arising out of (i) any breach or alleged breach by you of this EULA in any manner, (ii) any information you submit to Sony hereunder, (iii) any breach or alleged breach by you of a third party's rights, (iv) any damage caused by or alleged to have been caused by you to the Sony Software, the Services, or the Content. Counsel you select for defense or settlement of a claim must be consented to by Sony and/or Indemnified Party(s) prior to counsel being engaged to represent you and Sony and/or Indemnified Party(s). You and

your counsel will cooperate as fully as reasonably required by the Indemnified Party(s) in defense or settlement of any claim. Sony and/or Indemnified Party(s) reserve the right, at its own expense, to assume the exclusive defense or settlement, and control of any matter otherwise subject to indemnification by you. You shall not in any event consent to any judgment, settlement, attachment, or lien, or any other act adverse to the interest of Sony or any Indemnified Party without the prior written consent of Sony and/or Indemnified Party(s).

AUTOMATIC UPDATE FEATURE / MODIFICATION OF EULA AS TO SERVICES

From time to time, Sony or third parties may automatically update or otherwise modify the Sony Software, for example, but not limited to, for purposes of error correction, improvement of features, and enhancement of security features. Such updates or modifications may change or delete the nature of features or other aspects of the Sony Software, including features you may rely upon. You hereby agree that such activities may occur at Sony's sole discretion and that Sony may condition continued use of the Sony Software upon your complete installation or acceptance of such update or modifications. Sony may add to, change, or remove any part, term, or condition of the EULA as it applies to the Sony Software, the Services, and/or the Content at any time without prior notice to you. Any such additions, changes, or removals or any terms posted in the Sony Entertainment Network feature shall apply as soon as they are posted. By continuing to access the Services, the Sony Content Services, the Content, and/or the Sony Content after so posted, you are indicating your acceptance thereto. **SONY MAY ADD, CHANGE, DISCONTINUE, REMOVE, OR SUSPEND ANY OF THE SERVICES OR THE SONY CONTENT SERVICES, TEMPORARILY OR PERMANENTLY, AT ANY TIME, WITHOUT NOTICE AND WITHOUT LIABILITY. WITHOUT PREJUDICE TO ANY OTHER RIGHTS, SONY MAY SUSPEND OR TERMINATE THIS EULA AS TO THE SERVICES, THE SONY CONTENT SERVICES, THE CONTENT, AND/OR THE SONY CONTENT IMMEDIATELY UPON NOTICE IF YOU FAIL TO COMPLY WITH THE TERMS AND CONDITIONS OF THIS EULA.** Sony may take any legal and technical remedies to prevent violation of and/or to enforce this EULA, including, without limitation, immediate termination of your access to the Services, if Sony believes in its discretion that you are violating this EULA.

HIGH RISK ACTIVITIES

The Sony Software is not fault-tolerant and is not designed, manufactured or intended for use or resale as on-line control equipment in hazardous environments requiring fail-safe performance, such as in the operation of nuclear facilities, aircraft navigation or communication systems, air traffic control, direct life support machines, or weapons systems, in which the failure of the Sony Software could lead to death, personal injury, or severe physical or environmental damage ("High Risk

Activities"). SONY, EACH OF THE THIRD PARTY LICENSORS, AND EACH OF THEIR RESPECTIVE AFFILIATES SPECIFICALLY DISCLAIM ANY EXPRESS OR IMPLIED WARRANTY OR CONDITION OF FITNESS FOR HIGH RISK ACTIVITIES.

RESTRICTIONS ON EXPORT OF ENCRYPTION TECHNOLOGY

The Sony Software and the Content may contain encryption technology. You acknowledge that any export of Sony Software or the Content containing encryption technology from the United States or subsequent re-export of such software by a person located outside of the United States requires a license or other authorization from the U.S. Department of Commerce's Bureau of Industry and Security. You further acknowledge that the Sony Software or the Content containing encryption technology and acquired from Sony is not intended for use by a foreign government end user. By accepting this license agreement, you agree to abide by all relevant U.S. export laws and regulations in the purchase and use of the Sony product being acquired, including but not limited to those regulations relating to the export control of cryptographic items and not to transfer, or authorize the transfer, of the Sony Software or the Content to a prohibited country or otherwise in violation of any such restrictions or regulations.

US GOVERNMENT RESTRICTED RIGHTS

The Sony Software is provided with RESTRICTED RIGHTS. Use, duplication or disclosure by the United States Government is subject to restrictions as set forth in subparagraphs (c)(1) and (c)(2) of the Commercial Computer Software clause at FAR 52.227 19, and subparagraph (c)(i)(ii) of the Rights in Technical Data and Computer Software clause at DOD FAR 252.227-7013 and any comparable federal, state or local law or regulation. Manufacturer is Sony Electronics Inc., 16530 Via Esprillo, San Diego, CA 92127.

JURY TRIAL WAIVER

THE PARTIES HERETO WAIVE TRIAL BY JURY WITH RESPECT TO ANY MATTERS ARISING UNDER OR RELATING TO THIS EULA. Any cause of action you may have with respect to the Services must be commenced within one (1) year after the claim or cause of action arises.

ENTIRE AGREEMENT, NOTICE, WAIVER, SEVERABILITY

This EULA, the limited warranty accompanying the Sony Product, Sony's then-current privacy policy, and any additional terms and conditions posted on the Services, together constitute the entire agreement between you and Sony with respect to the Sony Product, the Sony Software, the Services, and the Content. Any notice by Sony hereunder may be made by letter, e-mail, or posting on the Services. The failure of Sony to exercise or enforce any right or provision of this EULA shall not constitute a waiver of such right or provision. If any part of this EULA is held invalid, illegal, or unenforceable, that provision shall be enforced to

the maximum extent permissible so as to maintain the intent of this EULA, and the other parts will remain in full force and effect.

THIRD PARTY BENEFICIARIES

Each Third Party Licensor and each Third Party Provider is an express intended third-party beneficiary of, and shall have the right to enforce, each provision of this EULA with respect to the software, service, and content, as applicable, of such party.

TERM

This EULA is effective until terminated. Sony may terminate this EULA immediately if you fail to comply with its terms by giving you notice. In such event, you must destroy the Sony Software and accompanying documentation, and all copies you have made of them. In addition, upon termination you will have no recourse against Sony, its affiliates, its Third Party Licensors, or its Third Party Providers for your inability to use the Sony Software or the accompanying documentation, the Services, or the Content.

DE-REGISTRATION OF YOUR DEVICE

Should you return your Sony Product to its place of purchase, transfer your Sony Product in accordance with this EULA, or if this EULA is terminated, you agree to: (i) de-register the Sony Product by deleting any and all accounts you may have established on or have accessed through the Sony Product; and (ii) reset the Sony Product to its original factory settings. YOU ARE SOLELY RESPONSIBLE FOR MAINTAINING THE CONFIDENTIALITY OF ANY ACCOUNTS YOU HAVE WITH THIRD PARTIES AND ANY USERNAMES AND PASSWORDS ASSOCIATED WITH YOUR USE OF THE SONY PRODUCT.

RESOLVING DISPUTES; ARBITRATION; SMALL CLAIMS WAIVER

This EULA will not be governed or interpreted in any way by referring to any law based on the Uniform Computer Information Transactions Act (UCITA) or any other act derived from or related to UCITA. Further, the United Nations Convention on Contracts for the International Sale of Goods shall not apply to this EULA.

If a Dispute arises, you agree to first give notice to us by contacting Sony Electronics Inc. at 16530 Via Esprillo, San Diego, California 92127, Attn: Legal Department, and engaging in good faith negotiations to attempt to resolve any Dispute for at least 14 days, except that you or Sony (or any of its affiliates) may skip this informal negotiation procedure for Disputes enforcing, protecting, or concerning the validity of intellectual property rights. "Dispute" is defined as any disagreement, cause of action, claim, controversy, or proceeding between you and any Sony entity related to or arising out of the Sony Product, Sony Software, Sony Services & Content or this EULA. Dispute is to be given the broadest possible meaning that will be enforced.

ANY DISPUTE THAT IS NOT RESOLVED THROUGH THE INFORMAL NEGOTIATION PROCESS DESCRIBED ABOVE SHALL BE RESOLVED EXCLUSIVELY THROUGH BINDING ARBITRATION.

To begin arbitration, either you or we must make a written demand to the other for arbitration. The arbitration will take place before a single arbitrator. It will be administered in keeping with the Expedited Procedures of the Commercial Arbitration Rules, and the Supplementary Proceedings for Consumer-Related disputes when applicable ("Rules") of the American Arbitration Association ("AAA") in effect when the claim is filed. You may get a copy of AAA's Rules by contacting AAA at (800) 778-7879 or visiting www.adr.org. The filing fees to begin and carry out arbitration will be shared between you and us, but in no event shall your fees ever exceed the amount allowable by the special rules for Consumers Disputes provided for by AAA, at which point Sony will cover all additional administrative fees and expenses. This does not prohibit the arbitrator from giving the winning party their fees and expenses of the arbitration when appropriate pursuant to the Rules. Unless you and we agree differently, the arbitration will take place in the county and state where you live, and applicable federal or state law shall govern the substance of any Dispute. The Federal Arbitration Act, 9 U.S.C. § 1, et seq., will govern the arbitration itself and not any state law on arbitration. The arbitrator's decision will be binding and final, except for a limited right of appeal under the Federal Arbitration Act. The arbitrator may award declaratory or injunctive relief only in favor of the party seeking relief, and only to the extent necessary to provide relief warranted by that party's individual claim. Any court with jurisdiction over the parties may enforce the arbitrator's decision.

Despite the above, you have the right to litigate any Dispute in small claims court or other similar court of limited jurisdiction in the United States, to the extent the amount at issue does not exceed \$15,000, and as long as such court has proper jurisdiction and all other requirements (including amount in controversy) are satisfied.

Despite anything to the contrary in this EULA, you may reject changes made to the binding arbitration provision if: (1) you've already begun authorized use of the Sony Product at the time the change was/is made; and (2) you mail written notice to the address in the immediately preceding paragraph within 30 days after the particular change was/is made. Should such a situation arise, you will still be bound by the Dispute procedures you previously agreed to and existing before the change you rejected was made.

Any Dispute determined not subject to arbitration and not initiated in small claims court will be litigated by either party in a court of competent jurisdiction in either the Superior Court for the

County of San Diego or in the United States District Court for the Southern District of California.

Notwithstanding the foregoing to the contrary, either party may initiate litigation immediately with respect to any matter arising out of or in connection with this Agreement for which equitable relief (or an equivalent type of urgent legal relief) is sought. You agree that any violation of or non-compliance with any term or condition this EULA by you will constitute an unlawful and unfair business practice, and will cause irreparable harm to Sony, its affiliates or third party licensors for which monetary damages would be inadequate, and you consent to Sony obtaining any injunctive or equitable relief that Sony deems necessary or appropriate in such circumstances. These remedies are in addition to any other remedies that may be available to Sony under contract, at law or in equity.

FEEDBACK

Should you have any questions concerning this EULA, you may contact Sony by writing to Sony Technical Response Center, 12451 Gateway Boulevard, Fort Myers, Florida 33913, USA.

© 2014 Sony Electronics Inc. All Rights Reserved.

For customers in European countries

NOTICES AND LICENCES FOR SOFTWARE USED IN THIS PRODUCT

Refer to the following:

This document is available on the following website:
<http://support.sony-europe.com>

The General Public License and the Lesser General Public License are available on the following website:

<http://www.gnu.org/licenses/translations.html>

END USER LICENCE AGREEMENT FOR CERTAIN SOFTWARE AND SERVICE TO BE USED WITH YOUR SONY PRODUCT

IMPORTANT – READ THIS AGREEMENT BEFORE USING YOUR SONY PRODUCT. USING YOUR PRODUCT INDICATES YOUR ACCEPTANCE OF THIS AGREEMENT.

If you do not agree to the terms of this EULA, as amended from time to time by Sony in its discretion, Sony is unwilling to license the Sony Software (as defined below) to you and unwilling to allow you to access the Sony Services & Content (as defined below), and you should promptly contact Sony for instructions on the return of the entire Sony Product and included Sony Software for a refund of the purchase price of the Sony Product.

This End User Licence Agreement (“EULA”) is a legal agreement between you and Sony Corporation, a company incorporated in Japan (“Sony”), the licensor of the software (other than the software which is governed by other licences as indicated below, the “Excluded Software”) included in this Sony Product and related materials which shall be collectively referred to as the “Sony Software.” This EULA covers the world-wide market (except for the United States of America, Canada and Japan) as a territory, and also covers the Sony Software and that of Sony’s third party licensors (“Third Party Licensors”) and accompanying printed or online documentation. The Sony Software includes software in your Sony Product, other software, including updates or modified software, provided to you by Sony, whether stored on media or downloaded to the Sony Product via any method.

This Sony Product also includes Sony Entertainment Network feature which provides access to selected content services (“Services”) from third party content providers including Sony entities other than Sony Corporation (“Third Party Providers”) as a courtesy to you. The Sony Entertainment Network feature also provides you access to selected Sony content services (“Sony Content Services”), which services and related content (“Sony Content”) shall both be considered Sony Software under this EULA. The Sony

Entertainment Network feature requires an Internet connection. Your ability to access the Services, and the quality of the Services presented, are subject to your Internet provider’s service and terms as well as the broadband Internet connection speed you use. Video quality and picture size varies and is dependent upon the speed of your broadband service from your Internet provider and delivery by the Third Party Providers. The content, including but not limited to data, music, sound, audio, photographs, images, graphics, likenesses, software, text, video, messages, tags, or other materials, provided by Third Party Providers (“Content”) and the availability of the Services are at the sole discretion and under the control of the Third Party Providers. The Content and Services of each Third Party Provider are provided pursuant to the terms and conditions of that Third Party Provider. Premium Content may require additional fees and/or registration with the Third Party Provider through a computer. The Services and the Content may only be used for your own personal, private viewing, and shall not be used for non-theatrical exhibition, or any viewing or exhibition for which (or in a venue in which) an admission, access, or viewing fee is charged, or for any public exhibition or viewing. The Services and/or Content may be changed at any time and may be unavailable from time to time.

SOFTWARE LICENCE

You cannot use the Sony Software except as specified herein. The Sony Software is licensed, not sold. Sony and its Third Party Licensors grant you a limited licence to use the Sony Software only on the Sony Product. The Sony Software may create data files automatically for use with the Sony Software, and you agree that any such data files are deemed to be a part of the Sony Software. The Sony Software is licensed as a single product, and you may not separate its component parts for use on more than one device unless expressly authorized by Sony. You may not use the Sony Software separately from the Sony Product. Except as such prohibition is restricted by the applicable law, you agree to be prohibited from modifying, reverse engineering, decompiling or disassembling the Sony Software in whole or in part for any purpose other than allowed under this EULA. In addition, you may not rent, lease, sublicense, or sell the Sony Software, but you may transfer all of your rights under this EULA only as part of a sale or transfer of the Sony Product provided you retain no copies, transfer all of the Sony Software (including all copies, component parts, any media, printed materials, all versions and any upgrades of the Sony Software, and this EULA), and the recipient agrees to the terms of this EULA. Sony and its Third Party Licensors retain all rights that this EULA does not expressly grant to you. You shall not (a) bypass, modify, defeat, or circumvent any of the functions or protections of the Sony Software or any mechanisms operatively linked to the Sony Software; or (b) remove, alter, cover, or deface any trademarks or notices on the Sony Software. You

understand, acknowledge, and agree that the software, network services, or other products other than the Sony Software upon which the Sony Software's performance may depend might be interrupted or discontinued at the discretion of the suppliers (software suppliers, service providers, Third Party Providers, etc.) or Sony.

EXCLUDED SOFTWARE

Notwithstanding the foregoing limited license grant, you acknowledge that the Sony Product includes software subject to other terms and conditions governing the use of such software other than this EULA ("Excluded Software"). Certain Excluded Software may be covered by open source software licenses ("Open Source Components"), which means any software licenses approved as open source licenses by the Open Source Initiative or any substantially similar licenses, including but not limited to any license that, as a condition of distribution of the software licensed under such license, requires that the distributor make the software available in source code format. Terms and conditions applicable to Open Source Components are provided to you together with this EULA and/or stored in your Device which may include but are not limited to the "Help" or "About" menus. Please visit <http://www.sony.net/Products/Linux> for a list of applicable Excluded Software included in this Sony Product from time to time, and the applicable terms and conditions governing its use. Such terms and conditions may be changed by the applicable third party at any time without liability to you. To the extent required by the licenses covering Open Source Components, the terms of such licenses will apply in lieu of the terms of this EULA. To the extent the terms of the licenses applicable to Open Source Components prohibit any of the restrictions in this EULA with respect to such Open Source Components, such restrictions will not apply to such Open Source Component. To the extent the terms of the licenses applicable to Open Source Components require Sony to make an offer to provide source code in connection with the Software, such offer is hereby made.

USER ACCOUNT

As part of the agreement to allow you to access, browse, or use the Services and the Content, Third Party Providers and/or other third parties may require that you establish a user account ("Account") for which you must provide them with true, accurate, current, and complete information about yourself and maintain/promptly update such information. You are responsible for maintaining the confidentiality of any and all of your passwords associated with any such Account.

DATA COLLECTION

Any Services provided by affiliates of Sony Corporation and/or third parties that you access may also allow affiliates of Sony Corporation and/or third parties to collect data about you and/or about the use of that service. Sony Corporation does not control and is not in any way liable for

such data collection and you should consult the relevant privacy policy for each such Service before using it.

SONY'S RIGHTS TO USER'S MATERIAL

If you send any communications or materials to Sony by electronic mail or otherwise ("Materials"), including any selections, comments, data, questions, suggestions, or the like, all such Materials are, and will be treated as, non-confidential and non-proprietary. Thus, to the maximum extent as permitted under the applicable law, you give up any claim that use of such Materials violates any of your rights including moral rights, privacy rights, proprietary or other property rights, rights of publicity, rights to credit for material or ideas, or any other right, including the right to approve the way Sony uses such Materials. Any Material may be adapted, broadcast, changed, copied, disclosed, licensed, performed, posted, published, sold, transmitted, or used by Sony anywhere in the world, in any medium, for the period in which the above-mentioned rights given up by you exist and without attribution or compensation to you. Furthermore, you hereby assign all right, title, and interest in, and Sony is free to use, without any compensation to you, any ideas, know-how, concepts, techniques, or other intellectual property rights contained in the Materials, whether or not patentable, for any purpose whatsoever, including but not limited to developing, manufacturing, having manufactured, licensing, marketing, and selling products using such Materials. However, you agree and understand that Sony is not obligated to use any such ideas, know-how, concepts, or techniques or Materials, and you have no right to compel such use.

TRANSMITTED MATERIAL

Internet transmissions are never completely private or secure. You understand that any message or information you send to Sony may be read or intercepted by others, unless there is a special notice that a particular message (for example, credit card information) is encrypted (sent in code). Sending a message to Sony does not cause Sony to have any special responsibility to you.

ADVERTISEMENTS, SERVICE COMMUNICATIONS

Inclusion of the Service of a Third Party Provider does not mean that Sony approves of, or endorses, or recommends that Third Party Provider or its Content. You understand and agree that the Services and/or Content may include advertisements ("Advertisements"), and that these Advertisements are necessary in order for the Services to be provided. If you use the Sony Entertainment Network service, the SEN and/or PSN Terms of Use/Service and the SEN and/or PSN Privacy Policy for your country will apply and you will be required to agree to them. You understand and agree that use of that service (and other services available through it) as well as other services than those provided by Sony Entertainment Network may result in you receiving

or being shown recommendations and/or advertisements, service announcements, administrative messages, news updates and the like which Sony Corporation is not responsible nor liable for. SONY, ITS AFFILIATES, AND ITS THIRD PARTY PROVIDERS DISCLAIM ALL WARRANTIES, EXPRESS OR IMPLIED, AS TO THE ACCURACY, LEGALITY, RELIABILITY, OR VALIDITY OF ANY ADVERTISEMENT, SERVICE COMMUNICATIONS, OR CONTENT, AS WELL AS ANY LIABILITY ARISING UNDER ANY THEORY OF LAW FOR THE ADVERTISEMENTS, SERVICE COMMUNICATIONS, AND CONTENT.

Some jurisdictions do not allow the exclusion of implied warranties, so the above exclusion may not apply to you.

OBJECTIONABLE CONTENT AND RULES FOR MINORS

Certain Content may not be suitable for minors or other users. Such Content may or may not be rated or identified as having explicit language, or otherwise being for a mature audience. Therefore, you acknowledge that you are using the Services at your own risk and that Sony has no liability to you for the Content, including any Content that may be offensive. You are responsible for supervising the use of the Sony Product, the Sony Software, Excluded Software, the Services, and the Content by any minor. If you have no legal competence to execute any agreement with any third party without consent of your parent(s), a guardian or other individuals who have a right to give the consent to you under the applicable law. You should obtain consent before you:

- (i) e-mail Sony via the Service; (ii) send in any information; (iii) enter any contest or game that requires information about you or offers a prize; (iv) join any club or group; (v) post any information on any bulletin board or enter any chatroom; or (vi) buy anything online.

EXCLUSION OF WARRANTY

YOU UNDERSTAND, ACKNOWLEDGE, AND AGREE THAT THE CONTENT AND SERVICES ARE PROVIDED BY THIRD PARTY PROVIDERS AND/OR SOFTWARE IS PROVIDED BY THIRD PARTIES OVER WHICH SONY HAS NO CONTROL. THE SELECTION, PROVISION, QUALITY, PICTURE SIZE, AND AVAILABILITY OF SUCH CONTENT AND/OR SOFTWARE ARE THE SOLE RESPONSIBILITY OF SUCH THIRD PARTY PROVIDER OR OTHER THIRD PARTY. YOU AGREE TO COMPLY WITH ANY AND ALL TERMS AND CONDITIONS THAT THE THIRD PARTY PROVIDERS MAY SET FOR ITS SERVICE, CONTENT AND/OR SOFTWARE. YOU FURTHER UNDERSTAND, ACKNOWLEDGE, AND AGREE THAT ACCESS, BROWSING, AND USAGE OF THE SERVICES REQUIRES INTERNET SERVICE PROVIDED BY YOU, AND FOR WHICH YOU ARE SOLELY RESPONSIBLE, INCLUDING BUT NOT LIMITED TO THE PAYMENT OF ANY THIRD PARTY FEES (SUCH AS INTERNET SERVICE PROVIDER OR AIRTIME CHARGES) FOR SUCH ACCESS AND FOR DISPLAY OR DELIVERY OF ADVERTISEMENTS INCLUDED WITH THE SERVICES. OPERATION OF THE SONY

ENTERTAINMENT NETWORK FEATURE AND THE SERVICE MAY BE LIMITED OR RESTRICTED DEPENDING ON THE CAPABILITIES, BANDWIDTH OR TECHNICAL LIMITATIONS OF YOUR INTERNET SERVICE. SONY, ITS AFFILIATES, AND ITS THIRD PARTY PROVIDERS SHALL HAVE NO RESPONSIBILITY FOR THE TIMELINESS, DELETION, MIS-DELIVERY, OR FAILURE TO STORE ANY USER COMMUNICATIONS OR PERSONALIZED SETTINGS.

THE SONY SOFTWARE AND ACCOMPANYING DOCUMENTATION, THE SERVICES, AND THE CONTENT ARE FURNISHED TO YOU "AS IS" AND WITHOUT WARRANTIES OR CONDITIONS, STATUTORY OR OTHERWISE, OF ANY KIND. SONY, ITS AFFILIATES, ITS THIRD PARTY LICENSORS, AND ITS THIRD PARTY PROVIDERS EXPRESSLY DISCLAIM ALL WARRANTIES AND CONDITIONS, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, TITLE, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE. SONY, ITS AFFILIATES, ITS THIRD PARTY LICENSORS, AND ITS THIRD PARTY PROVIDERS DO NOT WARRANT THAT THE SONY SOFTWARE OR ACCOMPANYING DOCUMENTATION, THE SERVICES, OR THE CONTENT WILL MEET YOUR REQUIREMENTS OR THAT THE OPERATION OF THE SONY SOFTWARE, THE SERVICES, OR THE CONTENT WILL BE UNINTERRUPTED OR ERROR FREE. FURTHERMORE, SONY, ITS AFFILIATES, ITS THIRD PARTY LICENSORS, AND ITS THIRD PARTY PROVIDERS DO NOT WARRANT OR MAKE ANY REPRESENTATIONS OR CONDITIONS REGARDING THE USE OR THE RESULTS OF THE USE OF THE SONY SOFTWARE, THE SERVICES OR THE CONTENT IN TERMS OF ITS CORRECTNESS, ACCURACY, RELIABILITY OR OTHERWISE. NO ORAL OR WRITTEN INFORMATION OR ADVICE GIVEN BY SONY, ITS AFFILIATES, OR A SONY AUTHORIZED REPRESENTATIVE SHALL CREATE A WARRANTY OR CONDITION, OR IN ANY WAY CHANGE THIS EXCLUSION OF WARRANTY AND CONDITION. SHOULD THE SOFTWARE, MEDIA ON WHICH THE SOFTWARE IS FURNISHED, DOCUMENTATION, THE SERVICES, OR THE CONTENT PROVE DEFECTIVE, YOU (AND NOT SONY OR A SONY AUTHORIZED REPRESENTATIVE) ASSUME THE ENTIRE COST OF ALL NECESSARY SERVICING, REPAIR, OR CORRECTION.

Some jurisdictions do not allow the exclusion of implied warranties, so the above exclusion may not apply to you.

LIMITATION OF LIABILITY

IN NO EVENT WILL SONY (INCLUDING BUT NOT LIMITED TO ANY NEGLIGENCE ISSUES RELATED TO THIRD PARTY LICENSORS OR THIRD PARTY PROVIDERS), ITS AFFILIATES, ITS THIRD PARTY LICENSORS OR ITS THIRD PARTY PROVIDERS BE LIABLE TO YOU FOR ANY SPECIAL, INDIRECT, INCIDENTAL, PUNITIVE, EXEMPLARY, OR CONSEQUENTIAL DAMAGES OF ANY KIND, INCLUDING BUT NOT LIMITED TO COMPENSATION, REIMBURSEMENT OR DAMAGES IN CONNECTION WITH, ARISING OUT OF OR RELATING TO THIS EULA, ON ACCOUNT OF THE LOSS OF USE OF THE SONY

PRODUCT, DOCUMENTATION, THE SERVICES, THE CONTENT, DOWN TIME AND YOUR TIME, LOSS OF PRESENT OR PROSPECTIVE PROFITS, LOSS OF DATA, INFORMATION OF ANY KIND, BUSINESS PROFITS, OR OTHER COMMERCIAL LOSS, OR FOR ANY OTHER REASON WHATSOEVER, EVEN IF SONY, ITS AFFILIATES, ITS THIRD PARTY LICENSORS, OR ITS THIRD PARTY PROVIDERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. THE SONY SOFTWARE AND ACCOMPANYING DOCUMENTATION, THE SERVICES, AND THE CONTENT ARE FURNISHED TO YOU FOR USE AT YOUR OWN RISK. SONY, ITS AFFILIATES, ITS THIRD PARTY LICENSORS, AND ITS THIRD PARTY PROVIDERS WILL NOT BE LIABLE FOR DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY OR CONDITION, BREACH OF CONTRACT, NEGLIGENCE, STRICT LIABILITY OR ANY OTHER LEGAL THEORY RELATED TO THE SONY SOFTWARE, THE SERVICES, THE CONTENT, OR THIS EULA.

Some jurisdictions may not allow exclusions or limitations of incidental or consequential damages, exclusions or limitations of implied warranties or conditions, or allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you.

LIMITED WARRANTY ON MEDIA

In situations where the Sony Software or any part thereof is furnished on media, Sony warrants that for a period of ninety (90) days from the date of original purchase by you, the media on which the Sony Software is furnished to you will be free from defects in materials and workmanship under normal use. This limited warranty extends only to you as the original licensee. Sony's entire liability and your exclusive remedy will be replacement of the media not meeting Sony's limited warranty. ANY IMPLIED WARRANTIES OR CONDITIONS ON THE MEDIA, INCLUDING THE IMPLIED WARRANTIES AND CONDITIONS OF MERCHANTABILITY, TITLE, NON-INFRINGEMENT, AND/OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO NINETY (90) DAYS FROM THE DATE OF ORIGINAL PURCHASE BY YOU. SOME JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY OR CONDITION LASTS, SO THESE LIMITATIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM JURISDICTION TO JURISDICTION.

FEES

Sony and its Third Party Providers reserve the right at any time to charge fees for access to new Content or new Services or to portions of the existing Content or Services, or the Services as a whole. In addition, Third Party Providers may charge fees for access to their Content. In no event will you be charged for access to any portion or all of the Content and/or the Services unless Sony and/or a Third Party Provider obtain your prior agreement to pay such charges. If you do not consent to such charges, however, you may not

have access to paid Content or Services for which such charges apply.

INTELLECTUAL PROPERTY / NOTICE FOR CLAIMS OF INTELLECTUAL PROPERTY VIOLATIONS AND AGENT FOR NOTICE

Sony respects the intellectual property rights of others, and we ask you to do the same. It is Sony's policy, at its discretion as appropriate, (a) to terminate and/or disable the Content of Third Party Providers or users of the Services who may infringe or repeatedly infringe the copyrights or other intellectual property rights of Sony, its Third Party Providers or others; and/or (b) to forward reports of intellectual property rights violations to Third Party Providers and others for review and action per the terms of such Third Party Provider's procedures for protection of intellectual property rights. The Sony Software and Content are protected by copyright laws and international copyright treaties, as well as other intellectual property laws and treaties. There may be proprietary logos, service marks, trademarks, likenesses, and trade names found in the Sony Software, the Content, or on the Services. By making the Sony Software and Content available on the Services, Sony and the Third Party Providers are not granting you any licence to utilize those proprietary logos, service marks, trademarks, likenesses, or trade names. Any unauthorized use of the Sony Software, the Services, or the Content may violate copyright laws, trademark laws, the laws of privacy and publicity, and civil and criminal statutes. All right, title, and interest in and to the Sony Software and the Content, and any and all copies or portions thereof, are owned by Sony, its licensors, Third Party Licensors, suppliers and/or Third Party Providers. All rights not specifically granted under this EULA are reserved by Sony, its licensors, Third Party Licensors, suppliers and/or Third Party Providers.

You are responsible for all your activities hereunder, including all legal liability incurred from access, browsing, or use of the Services by you or by others who use the Services via your Sony Product or Account (as defined in the User Account section). You may use the Sony Software, the Services, and the Content for lawful purposes only. You may not distribute, exchange, modify, sell, or transmit anything you may copy from the Sony Software, the Services, or the Content, including but not limited to any data, text, software, likenesses, photographs, images, graphics, audio, music, sound, video, messages, and tags, for any business, commercial, or public purpose. As long as you comply with the terms of this EULA, Sony grants you a nonexclusive, nontransferable, limited right to use the Sony Entertainment Network feature to access the Services and the Content as set forth in this EULA. You further agree not to interrupt/disrupt or attempt to interrupt/disrupt the operation of the Sony Software, the Service or the Content in any way.

If you believe your work has been copied in a way that constitutes copyright infringement, or that your intellectual property rights have otherwise been violated, please first contact the Third Party Provider for the particular Service. If you are unable to contact such Third Party Provider, or the content at issue is Sony's, you may contact Sony (the contact point of which is described in the documents accompanying with Sony Product) with the following information in a written notice: (a) an electronic or physical signature of the person authorized to act on behalf of the copyright or other intellectual property interest; (b) a description of the copyrighted work or other intellectual property that you claim has been infringed; (c) a description of the particular Service and where the material that you claim is infringing is located on such Service, with enough detail that we may find the material; (d) your address, telephone number, and e-mail address; (e) a statement by you that you have a good faith belief that the disputed use is not authorized by the copyright or intellectual property owner, its agent, or the law; and (f) a statement by you, made under penalty of perjury, that the above information in your notice is accurate and that you are the copyright or intellectual property owner or authorized to act on the copyright or intellectual property owner's behalf.

INDEMNIFICATION

To the maximum extent as permitted under the applicable law, you agree to indemnify, defend, and hold harmless Sony and all of its agents, directors, officers, employees, information providers, licensors and licensees, affiliates, content providers, and direct and indirect parent(s) (collectively, "Indemnified Parties") from and against any and all liability and costs (including, without limitation, attorneys' fees and costs) incurred by the Indemnified Parties in connection with any claim arising out of (i) any breach or alleged breach by you of this EULA in any manner, (ii) any information you submit to Sony hereunder, (iii) any breach or alleged breach by you of a third party's rights, (iv) any damage caused by or alleged to have been caused by you to the Sony Software, the Services, or the Content. To the maximum extent as permitted under the applicable law, counsel you select for defense or settlement of a claim must be consented to by Sony and/or Indemnified Party(s) prior to counsel being engaged to represent you and Sony and/or Indemnified Party(s). You and your counsel will cooperate as fully as reasonably required by the Indemnified Party(s) in defense or settlement of any claim. Sony and/or Indemnified Party(s) reserve the right, at its own expense, to assume the exclusive defense or settlement, and control of any matter otherwise subject to indemnification by you. You shall not in any event consent to any judgment, settlement, attachment, or lien, or any other act adverse to the interest of Sony or any Indemnified Party without the prior written consent of Sony and/or Indemnified Party(s).

AUTOMATIC UPDATE FEATURE / MODIFICATION OF EULA AS TO SERVICES

From time to time, Sony or third parties may automatically update or otherwise modify the Sony Software, for example, but not limited to, for purposes of error correction, improvement of features, and enhancement of security features. Such updates or modifications may change or delete the nature of features or other aspects of the Sony Software, including features you may rely upon. You hereby agree that such activities may occur at Sony's sole discretion and that Sony may condition continued use of the Sony Software upon your complete installation or acceptance of such update or modifications. Sony may add to, change, or remove any part, term, or condition of the EULA as it applies to the Sony Software, the Services, and/or the Content at any time without prior notice to you. Any such additions, changes, or removals or any terms posted in the Sony Entertainment Network feature shall apply as soon as they are posted. By continuing to access the Services, the Sony Content Services, the Content, and/or the Sony Content after so posted, you are indicating your acceptance thereto. **SONY MAY ADD, CHANGE, DISCONTINUE, REMOVE, OR SUSPEND ANY OF THE SERVICES OR THE SONY CONTENT SERVICES, TEMPORARILY OR PERMANENTLY, AT ANY TIME, WITHOUT NOTICE AND WITHOUT LIABILITY. WITHOUT PREJUDICE TO ANY OTHER RIGHTS, SONY MAY SUSPEND OR TERMINATE THIS EULA AS TO THE SERVICES, THE SONY CONTENT SERVICES, THE CONTENT, AND/OR THE SONY CONTENT IMMEDIATELY UPON NOTICE IF YOU FAIL TO COMPLY WITH THE TERMS AND CONDITIONS OF THIS EULA.** Sony may take any legal and technical remedies to prevent violation of and/or to enforce this EULA, including, without limitation, immediate termination of your access to the Services, if Sony believes in its discretion that you are violating this EULA.

HIGH RISK ACTIVITIES

The Sony Software is not fault-tolerant and is not designed, manufactured or intended for use or resale as on-line control equipment in hazardous environments requiring fail-safe performance, such as in the operation of nuclear facilities, aircraft navigation or communication systems, air traffic control, direct life support machines, or weapons systems, in which the failure of the Sony Software could lead to death, personal injury, or severe physical or environmental damage ("High Risk Activities"). **SONY, EACH OF THE THIRD PARTY LICENSORS, AND EACH OF THEIR RESPECTIVE AFFILIATES SPECIFICALLY DISCLAIM ANY EXPRESS OR IMPLIED WARRANTY OR CONDITION OF FITNESS FOR HIGH RISK ACTIVITIES.**

RESTRICTIONS ON EXPORT OF ENCRYPTION TECHNOLOGY

The Sony Software and the Content may contain encryption technology. You acknowledge that any export of Sony Software or the Content containing encryption technology from your residence or

subsequent re-export of such software by a person located outside of your residence might require a licence or other authorization from any governmental authority. By accepting this licence agreement, you agree to abide by all applicable export laws and regulations in the purchase and use of the Sony product being acquired, including but not limited to those regulations relating to the export control of cryptographic items and not to transfer, or authorize the transfer, of the Sony Software or the Content to a prohibited country or otherwise in violation of any such restrictions or regulations.

JURY TRIAL WAIVER

EVEN IF TRIAL BY JURY MAY BE ADOPTED UNDER THE APPLICABLE LAW, THE PARTIES HERETO WAIVE TRIAL BY JURY WITH RESPECT TO ANY MATTERS ARISING UNDER OR RELATING TO THIS EULA TO THE MAXIMUM EXTENT AS PERMITTED UNDER THE APPLICABLE LAW. Any cause of action you may have with respect to the Services must be commenced within one (1) year after the claim or cause of action arises to the maximum extent as permitted under the applicable law. Some jurisdictions do not allow limitations on the time for commencement of actions (or prescribe a longer period), so this limitation may not apply to you.

ENTIRE AGREEMENT, NOTICE, WAIVER, SEVERABILITY AND JURISDICTION

This EULA, the limited warranty accompanying the Sony Product, Sony's then-current privacy policy, and any additional terms and conditions posted on the Services, together constitute the entire agreement between you and Sony with respect to the Sony Product, the Sony Software, the Services, and the Content. Any notice by Sony hereunder may be made by letter, e-mail, or posting on the Services. The failure of Sony to exercise or enforce any right or provision of this EULA shall not constitute a waiver of such right or provision. If any part of this EULA is held invalid, illegal, or unenforceable, that provision shall be enforced to the maximum extent permissible so as to maintain the intent of this EULA, and the other parts will remain in full force and effect. To the extent permissible by law, this agreement shall be governed by and construed in accordance with the laws of Japan.

THIRD PARTY BENEFICIARIES

Each Third Party Licensor and each Third Party Provider is an express intended third-party beneficiary of, and shall have the right to enforce, each provision of this EULA with respect to the software, service, and content, as applicable, of such party.

TERM

This EULA is effective until terminated. Sony may terminate this EULA immediately if you fail to comply with its terms by giving you notice. In such event, you must destroy the Sony Software and accompanying documentation, and all copies you

have made of them. In addition, upon termination you will have no recourse against Sony, its affiliates, its Third Party Licensors, or its Third Party Providers for your inability to use the Sony Software or the accompanying documentation, the Services, or the Content.

DE-REGISTRATION OF YOUR DEVICE

Should you return your Sony Product to its place of purchase, transfer your Sony Product in accordance with this EULA, or if this EULA is terminated, you agree to: (i) de-register the Sony Product by deleting any and all accounts you may have established on or have accessed through the Sony Product; and (ii) reset the Sony Product to its original factory settings. YOU ARE SOLELY RESPONSIBLE FOR MAINTAINING THE CONFIDENTIALITY OF ANY ACCOUNTS YOU HAVE WITH THIRD PARTIES AND ANY USERNAMES AND PASSWORDS ASSOCIATED WITH YOUR USE OF THE SONY PRODUCT.

Avertissement

Afin de réduire les risques d'incendie ou de choc électrique, n'exposez pas cet appareil à la pluie ou à l'humidité.

Pour éviter les risques d'incendie ou de choc électrique, n'exposez pas l'appareil aux gouttes ou aux éclaboussures, et ne placez pas sur ce dernier d'objets contenant des liquides, tels que des vases.

Pour éviter les risques d'incendie, ne couvrez pas l'orifice de ventilation de l'appareil avec des journaux ou des nappes, des rideaux, etc. Ne placez pas l'appareil à proximité de flammes nues, telles que des bougies allumées.



Pour éviter tout choc électrique, n'ouvrez pas le boîtier. Confiez les réparations uniquement à du personnel qualifié.

MISE EN GARDE

Danger d'explosion si la pile n'est pas remplacée correctement.

Remplacez-la uniquement par une pile identique ou de type équivalent.

N'exposez pas les batteries ou les appareils utilisant des batteries à une chaleur excessive, telle que le soleil ou du feu.



Ce symbole est destiné à avertir l'utilisateur de la présence d'une « tension dangereuse » non isolée dans le coffret du produit dont la valeur peut être suffisante pour provoquer un choc électrique sur des personnes.



Ce symbole est destiné à avertir l'utilisateur de la présence d'instructions d'utilisation et de maintenance (entretien) importantes dans le document accompagnant l'appareil.

Ces symboles graphiques se trouvent sur l'adaptateur secteur.

Avis concernant les clients au Royaume-Uni et en République d'Irlande

Une fiche moulée conforme à la norme BS1363 est installée sur cet équipement pour votre confort d'utilisation et votre sécurité.

Si vous devez remplacer le fusible dans la prise fournie, vous devez utiliser un fusible ayant les mêmes caractéristiques que le fusible fourni et agréé par l'ASTA ou le BSI comme étant conforme à la norme BS1362 (indiqué sur le marquage).

Si la prise fournie avec cet équipement est munie d'un couvercle de fusible, veillez à bien fixer le couvercle de fusible après avoir changé le fusible. N'utilisez jamais la prise sans le couvercle de fusible. En cas de perte du couvercle de fusible, contactez votre atelier de réparation Sony le plus proche.



Elimination des piles et accumulateurs et des Equipements Electriques et Electroniques usages (Applicable dans les pays de l'Union Européenne et aux autres pays européens disposant de systèmes de collecte sélective)

Ce symbole apposé sur le produit, la pile ou l'accumulateur ou sur l'emballage, indique que le produit et les piles et accumulateurs fournis avec ce produit ne doivent pas être traités comme de simples déchets ménagers.

Sur certains types de piles, ce symbole apparaît parfois combiné avec un symbole chimique. Les symboles pour le mercure (Hg) ou le plomb (Pb) sont rajoutés lorsque ces piles contiennent plus de 0,0005% de mercure ou 0,004% de plomb. En vous assurant que les produits, piles et accumulateurs sont mis au rebut de façon appropriée, vous participez activement à la prévention des conséquences négatives que leur mauvais traitement pourrait provoquer sur l'environnement et sur la santé humaine. Le recyclage des matériaux contribue par ailleurs à la préservation des ressources naturelles.

Pour les produits qui pour des raisons de sécurité, de performance ou d'intégrité de données nécessitent une connexion permanente à une pile ou à un accumulateur, il conviendra de vous rapprocher d'un Service Technique qualifié pour effectuer son remplacement. En rapportant votre appareil électrique, les piles et accumulateurs en fin de vie à un point de collecte approprié vous vous assurez que le produit, la pile ou l'accumulateur incorporé sera traité correctement. Pour tous les autres cas de figure et afin d'enlever les piles ou accumulateurs en toute sécurité de votre appareil, reportez-vous au manuel

d'utilisation. Rapportez les piles et accumulateurs, et les équipements électriques et électroniques usagés au point de collecte approprié pour le recyclage. Pour toute information complémentaire au sujet du recyclage de ce produit ou des piles et accumulateurs, vous pouvez contacter votre municipalité, votre déchetterie locale ou le point de vente où vous avez acheté ce produit.

Pour les clients au Canada, au Mexique et au Brésil

Le symbole ci-dessus concerne l'Union européenne et les autres pays européens disposant de systèmes de collecte séparée.

Avis concernant les consommateurs :

Les informations suivantes ne sont applicables qu'aux équipements vendus dans les pays appliquant les directives européennes.

Ce produit a été fabriqué par ou pour le compte de Sony Corporation, 1-7-1 Konan Minato-ku Tokyo, 108-0075 Japon. Toutes les questions relatives à la conformité des produits basées sur la législation européenne doivent être adressées à son représentant, Sony Deutschland GmbH, Hedelfinger Strasse 61, 70327 Stuttgart, Allemagne.

Pour toute question relative au Service Après-Vente ou à la Garantie, merci de bien vouloir vous référer aux coordonnées qui vous sont communiquées dans les documents « Service (SAV) » ou Garantie.

La validité du marquage CE est limitée aux seuls pays où cela est légalement obligatoire, essentiellement dans les pays de l'Espace économique européen (EEA).

AVERTISSEMENT **NE PAS INGÉRER LA PILE, RISQUE DE BRÛLURE CHIMIQUE**

La télécommande fournie avec ce produit contient une pile bouton en forme de pièce. Si la pile bouton en forme de pièce est avalée, cela peut provoquer des brûlures internes graves en seulement 2 heures et entraîner la mort.

Gardez les piles neuves et usagées hors de portée des enfants. Si le compartiment de la pile ne se ferme pas de manière sûre, arrêtez d'utiliser le produit et maintenez-le hors de portée des enfants.

Si vous pensez que les piles ont pu être avalées ou placées dans un endroit quelconque du corps, consultez immédiatement un médecin.

Cet équipement a été testé et déterminé comme étant conforme aux limites définies dans la Directive Compatibilité électromagnétique (EMC) en utilisant un câble de connexion de moins de 3 mètres.

Précautions

- Le lecteur n'est pas déconnecté de la source d'alimentation secteur tant qu'il est connecté à la prise murale, même si le lecteur lui-même est éteint.
- Installez cette unité de telle sorte que le cordon d'alimentation secteur puisse être débranché immédiatement de la prise murale en cas de problème.
- La plaque signalétique se trouve au bas du lecteur.

Installation

N'installez pas ce lecteur dans un espace confiné, tel qu'une bibliothèque ou un endroit similaire.

Pour les clients au Canada

Assistance client Sony

<http://esupport.sony.com/CA/>

1-877-899-SONY


Veuillez appeler avant de retourner le produit au magasin

Cordons d'alimentation secteur fournis


Votre lecteur multimédia est fourni avec des cordons d'alimentation secteur et quatre types de fiches différentes.

Pour votre sécurité, utilisez uniquement les cordons prévus pour une utilisation dans votre pays ou votre région. N'utilisez jamais d'autre types de cordons.

Cordon d'alimentation secteur (A) : pour les clients au Canada et au Mexique




Cordon d'alimentation secteur (B) : pour les clients au Royaume-Uni et en République d'Irlande



Cordon d'alimentation secteur (C) : pour les clients au Brésil





Assurez-vous de la présence de ces marques entre les broches.



Cordon d'alimentation secteur (D) : pour les clients dans les autres pays européens

Assurez-vous que les broches sont renforcées.



Précautions

Placement

- Placez le lecteur dans un emplacement disposant d'une ventilation appropriée pour permettre d'évacuer la chaleur de l'appareil.
- Ne placez pas le lecteur sur une surface molle, telle qu'une couverture, qui risquerait d'obstruer les orifices de ventilation.
- Ne placez pas le lecteur dans un emplacement situé à proximité de sources de chaleur, ou dans un endroit exposé à la lumière directe du soleil, à une poussière excessive ou à un choc mécanique.
- Ne placez pas le lecteur à l'extérieur, dans des véhicules, sur des bateaux ou d'autres navires.
- Si le lecteur est amené directement d'un emplacement frais vers un endroit chaud, ou s'il est placé dans une pièce très humide, de la buée peut se former sur la surface extérieure et à l'intérieur du lecteur.

Si cela se produit, le lecteur peut ne pas fonctionner correctement. Dans ce cas, laissez le lecteur allumé pendant environ une demi-heure, jusqu'à ce que la buée s'évapore.

- N'installez pas le lecteur en position inclinée. Il est conçu pour être utilisé uniquement en position horizontale.
- Ne placez pas d'objets lourds ou instables sur le lecteur.
- Déconnectez le cordon d'alimentation secteur et tous les autres câbles du lecteur lorsque vous le déplacez.
- Tenez le lecteur à l'écart de tout équipement comportant des aimants, tels que les fours à micro-ondes ou de gros haut-parleurs.

Sources d'alimentation

- Suivez la procédure ci-dessous lorsque vous déconnectez le cordon d'alimentation secteur.
 - ① Déconnectez le câble LAN ou mettez le téléchargement en pause en utilisant le paramètre de l'application 4K dans les éléments de la section « Application » du menu Accueil du lecteur.
 - ② Attendez environ cinq minutes après avoir arrêté le lecteur.
 - ③ Assurez-vous que le lecteur de disque dur ne fonctionne pas (le témoin d'alimentation et le témoin du disque dur sont éteints).
 - ④ Déconnectez le cordon d'alimentation secteur.

- Déconnectez le lecteur de la prise murale si vous prévoyez de ne pas utiliser le lecteur pendant une période prolongée. Pour déconnecter le cordon d'alimentation secteur, saisissez la prise elle-même, ne tirez jamais sur le cordon.
- Respectez les points suivants pour éviter d'endommager le cordon d'alimentation secteur. N'utilisez pas le cordon d'alimentation secteur s'il est endommagé, car cela pourrait provoquer un choc électrique ou un incendie.
 - Ne pincez pas le cordon d'alimentation secteur entre le lecteur et un mur, une étagère, etc.
 - Ne placez aucun objet lourd sur le cordon d'alimentation secteur et ne tirez pas sur le cordon d'alimentation.

Adaptateur secteur

- Utilisez l'adaptateur secteur fourni pour ce lecteur, car d'autres adaptateurs peuvent provoquer un mauvais fonctionnement.
- Ne le démontez pas et ne pratiquez pas d'ingénierie inverse.
- Ne confinez pas l'adaptateur secteur dans un endroit fermé, tel qu'une étagère ou un boîtier AV.
- Ne connectez pas l'adaptateur secteur à un transformateur électrique de voyage, qui peut générer de la chaleur et provoquer un mauvais fonctionnement.
- Ne le laissez pas tomber et ne lui faites pas subir de choc.

Réglage du volume

Ne montez pas le volume lorsque vous écoutez une section comportant des niveaux d'entrée très faibles ou aucun signal audio. Si vous faites cela, vous risquez d'endommager vos oreilles et les haut-parleurs lors de la lecture d'une section comportant un niveau sonore brusquement élevé.

Nettoyage

Nettoyez le boîtier, le panneau et les commandes avec un chiffon doux. N'utilisez pas de tampon abrasif, de poudre à récurer ou de solvant comme de l'alcool ou de l'essence.

Remplacement de pièces


Dans le cas où ce lecteur est réparé, les pièces réparées peuvent être collectées à des fins de réutilisation ou de recyclage.

Connexion à la prise HDMI


Respectez les indications suivantes, car une manipulation incorrecte peut endommager la prise HDMI et le connecteur.

- Alignez soigneusement la prise HDMI à l'arrière du lecteur avec le connecteur HDMI en vérifiant leur forme. Assurez-vous que le connecteur n'est pas à l'envers ou incliné.


Prise HDMI



Prise HDMI



- Veillez à déconnecter le câble HDMI lorsque vous déplacez le lecteur.



- Tenez le connecteur HDMI bien droit lorsque vous connectez ou déconnectez le câble HDMI. Ne tordez pas et ne forcez pas le connecteur HDMI dans la prise HDMI.

AVIS IMPORTANT

Mise en garde : Ce lecteur peut maintenir indéfiniment sur l'écran de votre téléviseur une image vidéo fixe ou une image affichée sur l'écran. Si vous laissez l'image vidéo fixe ou l'image affichée sur l'écran affichée sur votre téléviseur pendant une période prolongée, vous risquez d'endommager l'écran de votre téléviseur de manière définitive. Les téléviseurs équipés d'un écran plasma et les téléviseurs à projection sont sensibles à ce phénomène.

Pour toute question ou problème concernant votre lecteur, consultez votre revendeur Sony le plus proche.


À propos de la norme MPEG-4 AVC

CE PRODUIT FAIT L'OBJET D'UNE LICENCE DE PORTEFEUILLE DE BREVETS AVC POUR UNE UTILISATION PERSONNELLE D'UN PARTICULIER OU D'AUTRES UTILISATIONS POUR LESQUELLES IL NE REÇOIT PAS DE RÉMUNÉRATION POUR (i) ENCODER DE LA VIDÉO SELON LA NORME AVC (« VIDÉO AVC ») ET/OU (ii) DÉCODER DE LA VIDÉO AVC ENCODÉE PAR UN PARTICULIER ENGAGÉ DANS UNE ACTIVITÉ PERSONNELLE ET/OU OBTENUE AUPRÈS D'UN FOURNISSEUR DE VIDÉOS QUI DÉTIENT UNE LICENCE LUI PERMETTANT DE PROPOSER DES VIDÉOS AVC. AUCUNE LICENCE N'EST OCTROYÉE DE FAÇON EXPLICITE OU IMPLICITE POUR TOUTE AUTRE UTILISATION. DES INFORMATIONS SUPPLÉMENTAIRES SONT DISPONIBLES AUPRÈS DE MPEG LA, L.L.C. VOIR [HTTP://WWW.MPEGLA.COM](http://www.mpegla.com)

Remplacement de la pile de la télécommande


Remplacez la pile de la télécommande par une pile neuve si elle est épuisée, en suivant les étapes ci-dessous.

- 1 Retirez le compartiment de la pile en appuyant sur le bouton avec un objet mince et pointu, comme la pointe d'un crayon.**



- 2 Remplacez la pile usagée par une pile neuve.** Insérez la nouvelle pile, en orientant le côté portant le signe ⊕ vers le haut.

Pile CR2032
fabriquée par Sony



- 3 Fermez le compartiment de la pile.**

Informations relatives aux marques commerciales

- Les termes HDMI™ et HDMI High-Definition Multimedia Interface, et le logo HDMI sont des marques commerciales ou des marques déposées de HDMI Licensing LLC aux États-Unis et dans d'autres pays.
- Fabriqué sous licence de Dolby Laboratories. Dolby et le symbole double-D sont des marques déposées de Dolby Laboratories.
- TUXERA est une marque déposée de Tuxera Inc. aux États-Unis et dans d'autres pays.
- Les autres noms de systèmes et de produits sont généralement des marques commerciales ou des marques déposées des fabricants. Les symboles ™ et ® ne sont pas indiqués dans ce document.

HDMI  **DOLBY DIGITAL PLUS**

TUXERA

LEADING FILE SYSTEM INTEROPERABILITY

Caractéristiques techniques

Prises d'entrée/sortie	
HDMI OUT 1 (pour AUDIO VIDEO)	Connecteur standard 19 broches HDMI Vidéo : 3840 × 2160 Fréquence d'images : 24p, 25p, 30p, 50p, 60p Audio : PCM linéaire, Dolby Digital, Dolby Digital Plus
HDMI OUT 2 (pour AUDIO)	Connecteur standard 19 broches HDMI PCM linéaire, Dolby Digital, Dolby Digital Plus
LAN (100)	Terminal 100 BASE-TX
EXTRA HDD	Port USB arrière : pour la connexion du lecteur de disque dur externe*1 *2
USB	Port USB avant : pour la connexion de la mémoire USB*2
Alimentation et autres éléments	
Caractéristiques de l'alimentation	Entrée : CC 19,5 V, 1,6 A
Consommation électrique	Marche : 35 W Veille : 0,5 W*3
Adaptateur secteur	Entrée : 100 V - 240 V CA, 50/60 Hz, 1,0 A Sortie : CC 19,5 V, 4,35 A
Température de fonctionnement	5 °C à 35 °C (41 °F à 95 °F)
Humidité de fonctionnement	25% à 80%
Dimensions (environ)	250 mm × 250 mm × 50 mm (9 7/8 po × 9 7/8 po × 2 po) (largeur/profondeur/hauteur), à l'exclusion des parties saillantes
Poids (environ)	1,8 kg (4,0 lb.)
Accessoires	
Accessoires fournis	Cordon d'alimentation secteur (4)/Adaptateur secteur (1)/ Télécommande RMT-D304 avec batterie CR2032 (1)/Guide de démarrage, Guide de référence et carte de garantie

*1 Cette fonction n'est pas disponible dans certains pays ou certaines régions.

*2 Pour plus de détails sur les périphériques USB pouvant être connectés au lecteur, consultez le « Guide d'aide » (http://rd1.sony.net/help/hv/fmpx5/h_zz).

*3 La valeur représente la consommation électrique approximative en fonctionnement normal. La consommation électrique en veille peut augmenter immédiatement après l'arrêt ou pendant la mise à jour du logiciel.

Les caractéristiques techniques et la conception sont sujettes à modification sans préavis.

Pour les clients au Canada

CONTRAT DE LICENCE D'UTILISATION

**POUR CERTAINS LOGICIELS ET SERVICES
DEVANT ÊTRE UTILISÉS AVEC VOTRE PRODUIT
SONY**

**IMPORTANT – LISEZ CE CONTRAT AVANT
D'UTILISER VOTRE PRODUIT SONY.
L'UTILISATION DE VOTRE PRODUIT SIGNIFIE
QUE VOUS ACCEPTEZ CE CONTRAT.**

Si vous n'acceptez pas les termes de ce CLU ou la politique de confidentialité de Sony applicable, telle qu'amendée par Sony à sa discrétion, Sony ne pourra pas vous donner la licence du logiciel Sony (comme définie ci-dessous) ni vous autoriser l'accès aux Services et au Contenu Sony (comme défini ci-dessous), et vous devrez rapidement contacter Sony pour connaître les modalités de retour du produit Sony et du logiciel Sony afin d'obtenir un remboursement du prix d'achat du produit Sony.

Ce Contrat de licence d'utilisation (« CLU ») est un contrat légal entre vous et Sony Electronics Inc. (« Sony »), le donneur de licence des logiciels (autres que les logiciels qui sont gouvernés par d'autres licences comme il est indiqué ci-dessous, les « Logiciels exclus ») compris dans ce produit Sony et documents connexes qui seront collectivement appelés les « Logiciels Sony ». Ce CLU couvre les Logiciels Sony et ceux des filiales et tiers donneurs de licence de Sony (« Tiers donneurs de licence ») ainsi que la documentation imprimée ou en ligne s'y rattachant. Les Logiciels Sony comprennent le logiciel dans votre produit Sony, y compris des mises à jour ou des logiciels modifiés, qui vous sont fournis par Sony qu'ils soient enregistrés sur média ou téléchargés dans les produits Sony par tout moyen qui soit, mais ne comprennent pas les logiciels exclus définis ci-dessous.

Remarque: Ce CLU contient une clause d'arbitrage individuelle et une renonciation d'entreprendre tout recours. Si vous souhaitez vous désengager de ces provisions, veuillez suivre les instructions dans la Section intitulée « Résoudre des conflits ; Arbitrage ; Cour des petites créances » ci-dessous.

Ce produit Sony comprend aussi la fonction Sony Entertainment Network qui fournit l'accès à certains services de contenu (« Services ») de fournisseurs de contenu tiers, y compris des entités Sony autres que Sony Electronics Inc. (« Fournisseurs tiers ») à titre de courtoisie. La fonction Sony Entertainment Network vous fournit aussi l'accès à certains services de contenu de Sony (« Services de contenu Sony »), et ces services et ces contenus correspondants (« Contenu Sony »)

seront tous deux considérés comme étant des logiciels Sony en vertu de ce CLU. La fonction Sony Entertainment Network nécessite une connexion Internet. Votre capacité à accéder aux Services et la qualité des Services présentés dépendent du service et des conditions de votre fournisseur de service Internet ainsi que de la connexion Internet à bande large que vous utilisez. Votre capacité à accéder aux Services et la qualité des Services présentés dépendent du service et des conditions de votre fournisseur de service Internet. La qualité vidéo et la taille de l'image varient et dépendent de la vitesse de votre service à bande large offert par votre fournisseur Internet et livré par les Fournisseurs tiers. Les contenus, y compris sans en exclure d'autres, les données, la musique, le son, les photographies, les images, les graphiques, les ressemblances, les logiciels, le texte, la vidéo, les messages, les étiquettes ou autres documents, fournis par les Fournisseurs tiers (« Contenu ») et la disponibilité des Services dépendent entièrement et sont contrôlés par les Fournisseurs tiers. Le Contenu et les Services de chaque Fournisseur tiers sont fournis conformément aux conditions de ce Fournisseur tiers. Le Contenu de luxe peut nécessiter des frais supplémentaires et/ou l'inscription auprès du Fournisseur tiers par l'entremise d'un ordinateur. Les Services et le Contenu ne peuvent être utilisés que pour votre visionnement personnel et privé et ne doivent pas être utilisés pour des expositions non théâtrales ou tout visionnement ou toute exposition pour lesquels (ou à tout endroit dans lequel) des frais d'admission, d'accès ou de visionnement sont imposés ou pour des expositions ou des visionnements publics. Les Services peuvent être modifiés en tout temps et peuvent ne pas être disponibles de temps à autre.

Vous comprenez, reconnaissez et acceptez que l'accès à certaines fonctions produit Sony, y compris mais non limité à votre capacité d'accéder au Contenu et aux Services Sony, requiert une connexion à Internet pour laquelle vous êtes entièrement responsable. Vous êtes entièrement responsable du paiement des frais annexes associés à votre connexion à Internet, y compris mais non limité au fournisseur d'accès à Internet ou aux frais d'utilisation du réseau. La qualité du Contenu et des Services Sony présenté sont soumis aux termes et services de votre fournisseur d'accès à Internet, et dépend également de la vitesse de votre service Internet. L'utilisation du produit Sony et du logiciel Sony, ainsi que l'accès au Contenu et aux Services Sony, peut être limitée ou restreinte selon les capacités, la bande passante ou les limites techniques de votre connexion à Internet ou de vos services. Vous comprenez, reconnaissez et acceptez que la connectivité Internet est fournie par un tiers sur lequel Sony n'a aucun contrôle. Les prévisions, la qualité, la disponibilité et la sécurité de cette connectivité à Internet, aux logiciels et aux services, sont sous l'entière responsabilité de ce tiers.

LES LOGICIELS SONY ET LES SERVICES SONY PEUVENT PERMETTRE À SONY, AUX FOURNISSEURS TIERS ET/OU À D'AUTRES TIERS DE RECUEILLIR DES DONNÉES DU, DE CONTRÔLER ET/OU DE SURVEILLER LE PRODUIT SONY ET LES AUTRES DISPOSITIFS QUI FONCTIONNENT OU INTERAGISSENT AVEC LES LOGICIELS SONY.

PERMIS D'UTILISATION DE LOGICIELS

Vous ne pouvez pas utiliser les Logiciels Sony à l'exception de ce qui est précisé aux présentes. Les Logiciels Sony sont grevés d'une licence et non vendus. Sony et ses Tiers donneurs de licence vous octroient une licence restreinte à utiliser les Logiciels Sony seulement sur le produit Sony. Les Logiciels Sony peuvent créer des fichiers de données automatiquement pour être utilisés avec les Logiciels Sony, et vous acceptez que de tels fichiers de données fassent partie des Logiciels Sony. Les Logiciels Sony sont offerts sous licence à titre d'un seul produit et vous ne pouvez pas séparer ses composants pour les utiliser sur plus d'un seul appareil, à moins d'en obtenir l'autorisation expresse de Sony. Vous acceptez de ne pas modifier, désosser, décompiler ou démonter les Logiciels Sony, en tout ou en partie, ou de ne pas utiliser les Logiciels Sony, en tout ou en partie, pour tout autre but que celui permis en vertu de ce CLU. De plus, vous ne pouvez pas louer, donner à bail, octroyer une sous-licence ou vendre les Logiciels Sony, mais vous pouvez transférer tous vos droits en vertu de ce CLU seulement dans le cadre d'une vente ou d'un transfert du produit Sony à condition de ne pas garder de copies, de transférer tous les Logiciels Sony (y compris tous les exemplaires, composants, médias, documents imprimés, toutes les versions et mises à niveau des Logiciels Sony et de ce CLU) et que le récipiendaire accepte les conditions de ce CLU. Sony et ses Tiers donneurs de licence se réservent tous les droits que ce CLU ne vous accorde pas expressément. Vous ne pouvez pas (a) dévier, modifier, déjouer ou contourner les fonctions ou les protections des Logiciels Sony ou des mécanismes liés de façon opérationnelle aux Logiciels Sony; ou (b) retirer, modifier, couvrir ou détériorer les marques de commerce ou les avis sur les Logiciels Sony. Vous comprenez, reconnaissez et acceptez que les logiciels, les services de réseau ou les autres produits autres que les Logiciels Sony desquels peut dépendre le rendement des Logiciels Sony puissent être interrompus ou supprimés à la discrétion des fournisseurs (fournisseurs de logiciels, fournisseurs de services, Fournisseurs tiers, etc.) ou Sony.

LOGICIELS EXCLUS

Malgré l'octroi de licence limité précité, vous reconnaissez que les Produits Sony comprennent des logiciels soumis à d'autres conditions gouvernant l'utilisation de ces logiciels, différentes de ce CLU (« Logiciels exclus »). Certains Logiciels exclus peuvent être couverts par des licences

logicielles open source (« Composants Open Source »), soit toute licence logicielle approuvée comme licence open source par l'Open Source Initiative ou autre licence similaire, y compris mais non limité à toute licence qui, sous la condition de distribution du logiciel sous cette licence, requiert que le distributeur rende le logiciel disponible dans le format du code source. Les conditions applicables aux Composants Open Source vous sont fournies avec ce CLU et / ou stockées dans votre Appareil, dans les menus « Aide » ou « À propos » notamment. Veuillez consulter le site <http://www.sony.net/Products/Linux> pour obtenir une liste des Logiciels exclus pour ce produit Sony, ainsi que les conditions applicables à leur utilisation. Ces conditions peuvent être changées par le tiers concerné à tout moment, sans que votre responsabilité soit engagée. Dans les limites requises par les licences couvrant les Composants Open Source, les termes de ces licences s'appliquent à la place des termes de ce CLU. Lorsque les termes de licence applicables aux Composants Open Source interdisent l'une des restrictions de ce CLU concernant les Composants Open Source, ces restrictions ne s'appliquent pas aux Composants Open Source. Dans la mesure où les termes des licences applicables aux Composants Open Source requièrent que Sony fasse une offre pour fournir le code source concernant le Logiciel, cette offre est faite par la présente.

COMPTE D'UTILISATEUR

Dans le cadre de l'accord vous permettant d'accéder, de naviguer ou d'utiliser les Services et le Contenu, les Fournisseurs tiers et/ou d'autres tiers peuvent vous demander d'établir un compte d'utilisateur (« Compte ») pour lequel vous devrez leur fournir des renseignements véridiques, exacts, courants et complets à votre sujet et maintenir et mettre à jour dans les moindres délais de tels renseignements. Vous êtes responsable du maintien de la confidentialité de tous vos mots de passe associés à un tel Compte.

COLLECTE DES DONNÉES

Tous les services fournis par des filiales de Sony Corporation et / ou de tiers auxquels vous accédez peuvent également permettre aux filiales de Sony Corporation et / ou aux tiers de collecter des données vous concernant et / ou concernant l'utilisation de ce service. Sony Corporation ne contrôle pas et n'est en aucun cas responsable de cette collecte de données et vous devez consulter la politique de confidentialité correspondante de ce Service avant de l'utiliser.

LES DROITS DE SONY ENVERS LA DOCUMENTATION DE L'UTILISATEUR

Si vous envoyez des messages ou des documents à Sony par courriel ou autrement (« Documentation »), y compris tous les commentaires, sélections, données, questions, suggestions et autres du même genre, une telle Documentation sera considérée comme non confidentielle et non exclusive. Par conséquent,

vous abandonnez toute allégation que l'utilisation d'une telle Documentation viole vos droits, y compris les droits moraux, de confidentialité, d'exclusivité ou d'autres droits de propriété, de publicité, de crédit pour des renseignements ou des idées, ou tout autre droit, y compris le droit d'approuver la façon dont Sony utilise une telle Documentation. Toute Documentation peut être adaptée, diffusée, modifiée, copiée, divulguée, brevetée, exécutée, affichée, publiée, vendue, transmise ou utilisée par Sony partout dans le monde, par tous les moyens, à vie et sans vous devoir d'attribution ou de compensations. De plus, vous cédez par les présentes tous vos droits, titres et intérêts envers, et Sony est libre d'utiliser, sans vous remettre de compensation, tous les concepts, idées, savoir-faire, techniques ou autres droits de propriété intellectuelle se trouvant dans la Documentation, qu'ils soient brevetables ou non, pour quelque but que ce soit, y compris, sans en exclure d'autres, développer, fabriquer, faire fabriquer, attribuer une licence, commercialiser et vendre des produits utilisant une telle Documentation. Cependant, vous acceptez et comprenez que Sony n'est pas obligée d'utiliser de tels concepts, idées, savoir-faire ou techniques ou Documentation et vous n'avez aucun droit d'obliger une telle utilisation.

DOCUMENTATION TRANSMISE

Les transmissions Internet ne sont jamais entièrement privées ou sécurisées. Vous comprenez que tout message ou renseignement que vous envoyez à Sony peut être lu ou intercepté par d'autres, à moins qu'il y ait un avis spécial qu'un message précis (par exemple, renseignements sur les cartes de crédit) est encodé (envoyé par code). Envoyer un message à Sony ne signifie pas que Sony a une responsabilité spéciale envers vous.

ANNONCES, COMMUNICATIONS DE SERVICES

L'inclusion des Services d'un Fournisseur tiers ne signifie pas que Sony approuve, endosse ou recommande le Fournisseur tiers ou son Contenu. Vous comprenez et acceptez que les Services et / ou le Contenu peuvent comprendre des annonces (« Annonces ») et que ces Annonces sont nécessaires afin que les Services puissent être fournis. Si vous utilisez le service Sony Entertainment Network, les termes d'utilisation / service et la politique de confidentialité de votre pays de SEN et / ou PSN s'appliqueront et vous devrez les accepter. Vous comprenez et acceptez que l'utilisation de ce service (et autres services disponibles) ainsi que d'autres services que ceux fournis par Sony Entertainment Network puisse entraîner la réception ou l'affichage de recommandations et / ou d'annonces, des annonces de service, des messages administratifs, des bulletins de nouvelles et autres du même genre dont Sony Corporation n'est pas responsable. SONY, SES SOCIÉTÉS AFFILIÉES ET SES FOURNISSEURS TIERS RENONCENT À TOUTES LES GARANTIES, EXPRESSES OU IMPLICITES, RELATIVES À L'EXACTITUDE, LA LÉGALITÉ, LA FIABILITÉ OU LA VALIDITÉ DE TOUTE ANNONCE, COMMUNICATION

DE SERVICE OU DE TOUT CONTENU, AINSI QU'À TOUTE RESPONSABILITÉ DÉCOULANT DE TOUTE THÉORIE JURIDIQUE POUR LES ANNONCES, LES COMMUNICATIONS DE SERVICE ET LE CONTENU.

CONTENU INCONVENANT ET RÈGLEMENTS POUR LES MINEURS (MOINS DE 16 ANS)

Certains Contenus peuvent ne pas être appropriés pour les mineurs ou d'autres utilisateurs. Un tel Contenu peut être ou ne pas être classé ou identifié comme ayant un langage explicite ou étant destiné à des adultes. Par conséquent, vous reconnaissez que vous utilisez les Services à votre propre risque et que Sony n'a aucune responsabilité envers vous pour le Contenu, y compris tout Contenu pouvant être offensant. Vous devez superviser l'utilisation du produit Sony, des Logiciels Sony, des Logiciels exclus, des Services et du Contenu par tout mineur. Si vous avez moins de 16 ans, vous devez demander à votre(vos) parent(s) ou un gardien avant : (i) d'envoyer un courriel à Sony par l'entremise des Services; (ii) d'envoyer tout renseignement; (iii) de participer à tout concours ou jeu qui nécessite des renseignements à votre sujet ou qui offre un prix; (iv) de joindre un club ou un groupe; (v) d'afficher tout renseignement sur tout babillard ou d'entrer dans un bavardoir; ou (vi) d'acheter quoi que ce soit en ligne.

EXCLUSION DE GARANTIE

VOUS COMPRENEZ, RECONNAISSEZ ET ACCEPTEZ QUE LE CONTENU ET LES SERVICES SONT FOURNIS PAR DES FOURNISSEURS TIERS ET/OU QUE LES LOGICIELS SONT FOURNIS PAR DES TIERS SUR LESQUELS SONY N'A AUCUN CONTRÔLE. LES FOURNISSEURS TIERS OU AUTRE TIERS SONT ENTIÈREMENT RESPONSABLES DE LA SÉLECTION, LA PROVISION, LA QUALITÉ, LA TAILLE DES IMAGES ET LA DISPONIBILITÉ D'UN TEL CONTENU ET/OU DE TELS LOGICIELS. VOUS ACCEPTEZ DE VOUS CONFORMER À TOUTES LES CONDITIONS ET MODALITÉS QUI PEUVENT ÊTRE ÉTABLIES PAR LES FOURNISSEURS TIERS POUR LEURS SERVICES, LEUR CONTENU ET/OU LEURS LOGICIELS. VOUS COMPRENEZ, RECONNAISSEZ ET ACCEPTEZ DE PLUS QUE L'ACCÈS, LA NAVIGATION ET L'UTILISATION DES SERVICES NÉCESSITENT UN SERVICE INTERNET FOURNI PAR VOUS ET POUR LEQUEL VOUS ÊTES ENTIÈREMENT RESPONSABLE, Y COMPRIS SANS EN EXCLURE D'AUTRES, LE PAIEMENT DE TOUTS LES FRAIS À DES TIERS (COMME LE FOURNISSEUR DE SERVICE INTERNET OU LES FRAIS D'UTILISATION DU RÉSEAU) POUR UN TEL ACCÈS ET POUR AFFICHER OU FOURNIR LES ANNONCES COMPRISES AVEC LES SERVICES. LE FONCTIONNEMENT DE LA FONCTION SONY ENTERTAINMENT NETWORK ET DES SERVICES PEUT ÊTRE LIMITÉ OU RESTREINT SELON LES CAPACITÉS, LA LARGEUR DE BANDE OU LES LIMITES TECHNIQUES DE VOTRE SERVICE INTERNET. SONY, SES SOCIÉTÉS AFFILIÉES ET SES FOURNISSEURS TIERS NE SERONT AUCUNEMENT RESPONSABLES DE L'OPPORTUNITÉ, LA SUPPRESSION, LA MAUVAISE LIVRAISON OU LA DÉFAILLANCE À SAUVEGARDER LES COMMUNICATIONS AVEC L'UTILISATEUR OU LES RÉGLAGES PERSONNELS.

LES LOGICIELS SONY ET LA DOCUMENTATION CONNEXE, LES SERVICES ET LE CONTENU VOUS SONT FOURNIS « TELS QUELS » ET NE COMPORTENT AUCUNE GARANTIE OU CONDITION, STATUTAIRE OU AUTRE, DE TOUTE SORTE. SONY, SES SOCIÉTÉS AFFILIÉES, SES TIERS DONNEURS DE LICENCE ET SES FOURNISSEURS TIERS RENONCENT EXPRESSÉMENT À TOUTES LES GARANTIES ET CONDITIONS, EXPRESSES OU IMPLICITES, Y COMPRIS SANS EN EXCLURE D'AUTRES, LES GARANTIES IMPLICITES D'ABSENCE DE CONTREFAÇON, DE TITRE, DE VALEUR MARCHANDE ET D'ADAPTATION À UN USAGE PARTICULIER. SONY, SES SOCIÉTÉS AFFILIÉES, SES TIERS DONNEURS DE LICENCE ET SES FOURNISSEURS TIERS NE GARANTISSENT PAS QUE LES LOGICIELS SONY OU LA DOCUMENTATION CONNEXE, LES SERVICES OU LE CONTENU RÉPONDENT À VOS EXIGENCES OU QUE LE FONCTIONNEMENT DES LOGICIELS SONY, DES SERVICES OU DU CONTENU SERA ININTERROMPU OU LIBRE D'ERREURS. DE PLUS, SONY, SES SOCIÉTÉS AFFILIÉES, SES TIERS DONNEURS DE LICENCE ET SES FOURNISSEURS TIERS NE GARANTISSENT PAS ET N'EFFECTUENT AUCUNE REPRÉSENTATION OU CONDITION CONCERNANT L'UTILISATION OU LES RÉSULTATS DE L'UTILISATION DES LOGICIELS SONY, DES SERVICES OU DU CONTENU RELATIVEMENT À SON BIEN-FONDÉ, SON EXACTITUDE, SA FIABILITÉ OU AUTRE. LES RENSEIGNEMENTS OU CONSEILS ORAUX OU ÉCRITS OFFERTS PAR SONY, SES SOCIÉTÉS AFFILIÉES OU UN REPRÉSENTANT AUTORISÉ DE SONY NE REPRÉSENTERONT PAS UNE GARANTIE ET NE MODIFIERONT PAS DANS AUCUN CAS CETTE EXCLUSION DE GARANTIE ET CONDITION. SI LE MÉDIA SUR LEQUEL LES LOGICIELS SONT FOURNIS, LA DOCUMENTATION, LES SERVICES OU LE CONTENU S'AVÉRAIENT DÉFECTUEUX, VOUS (ET NON PAS SONY OU UN REPRÉSENTANT AUTORISÉ DE SONY) ASSUMEZ TOUS LES FRAIS REQUIS POUR L'ENTRETIEN, LA RÉPARATION OU LA CORRECTION.

LIMITATION DE RESPONSABILITÉ

SONY, SES SOCIÉTÉS AFFILIÉES, SES TIERS DONNEURS DE LICENCE OU SES FOURNISSEURS TIERS NE SERONT DANS AUCUN CAS (Y COMPRIS, SANS EN EXCLURE D'AUTRES, LES PROBLÈMES DE NÉGLIGENCE RELATIFS AUX TIERS DONNEURS DE LICENCE OU FOURNISSEURS TIERS) RESPONSABLES ENVERS VOUS POUR LES DOMMAGES SPÉCIAUX, INDIRECTS, CONSÉCUTIFS, EXEMPLAIRES OU CORRÉLATIFS DE TOUTE SORTE, Y COMPRIS SANS EN EXCLURE D'AUTRES, LA COMPENSATION, LE REMBOURSEMENT OU LES DOMMAGES CONCERNANT, DÉCOULANT OU RELATIFS À CE CLU CONCERNANT LA PERTE D'UTILISATION DU PRODUIT SONY, LA DOCUMENTATION, LES SERVICES, LE CONTENU, LE TEMPS D'IMMOBILISATION ET VOTRE TEMPS, LA PERTE DE PROFITS ACTUELS OU ÉVENTUELS, LA PERTE DE DONNÉES, DE RENSEIGNEMENTS DE TOUTE SORTE, DE PROFITS COMMERCIAUX OU AUTRES PERTES COMMERCIALES OU POUR TOUTE AUTRE RAISON QUI SOIT, MÊME SI SONY, SES SOCIÉTÉS AFFILIÉES, SES TIERS DONNEURS DE LICENCE OU SES

FOURNISSEURS TIERS ONT ÉTÉ AVISÉS DE LA POSSIBILITÉ DE TELS DOMMAGES. LES LOGICIELS SONY ET LA DOCUMENTATION CONNEXE, LES SERVICES ET LE CONTENU VOUS SONT FOURNIS POUR UTILISATION À VOS PROPRES RISQUES. SONY, SES SOCIÉTÉS AFFILIÉES, SES TIERS DONNEURS DE LICENCE ET SES FOURNISSEURS TIERS NE SERONT PAS RESPONSABLES DES DOMMAGES POUR VIOLATION DE TOUTE GARANTIE OU CONDITION EXPRESSE OU IMPLICITE, VIOLATION DE CONTRAT, NÉGLIGENCE, RESPONSABILITÉ ABSOLUE OU TOUTE AUTRE THÉORIE LÉGALE RELATIVE AUX LOGICIELS SONY, AUX SERVICES, AU CONTENU OU À CE CLU.

Certaines juridictions ne permettent pas les exclusions ou les limites aux dommages consécutifs ou indirects, les exclusions ou les limites sur les garanties ou conditions implicites ou permettent les limites sur la durée d'une garantie implicite, et par conséquent, les limites ou les exclusions précédentes peuvent ne pas s'appliquer à votre cas.

GARANTIE LIMITÉE SUR LES MÉDIAS

Dans les cas où les Logiciels Sony ou toute partie de ces derniers sont fournis sur médias, Sony garantit que pendant une période de quatre-vingt-dix (90) jours à compter de la date où ils vous sont remis, les médias sur lesquels les Logiciels Sony vous sont fournis seront exempts de défauts de matériaux et de fabrication sous une utilisation normale. Cette garantie limitée ne s'applique qu'à vous le licencié original. L'entière responsabilité de Sony et votre seul remède seront le remplacement des médias ne répondant pas à la garantie limitée de Sony. TOUTES LES GARANTIES IMPLICITES OU CONDITIONS SUR LES MÉDIAS, Y COMPRIS LES GARANTIES ET LES CONDITIONS IMPLICITES DE VALEUR MARCHANDE, D'ABSENCE DE CONTREFAÇON ET/OU D'ADAPTATION À UN USAGE PARTICULIER, SE LIMITENT EN TEMPS À QUATRE-VINGT-DIX (90) JOURS À COMPTER DE LA DATE DE LIVRAISON. CERTAINES JURIDICTIONS NE PERMETTENT PAS LES LIMITES SUR LA DURÉE D'UNE GARANTIE OU CONDITION IMPLICITES, ET PAR CONSÉQUENT, CES LIMITES PEUVENT NE PAS S'APPLIQUER À VOTRE CAS. CETTE GARANTIE VOUS DONNE DES DROITS LÉGAUX PRÉCIS ET VOUS POUVEZ AUSSI AVOIR D'AUTRES DROITS QUI VARIENT D'UNE JURIDICTION À L'AUTRE.

FRAIS

Sony et ses Fournisseurs tiers se réservent le droit en tout temps d'exiger des frais pour l'accès à un nouveau Contenu ou à de nouveaux Services ou à des parties du Contenu et des Services existants ou aux Services dans leur totalité. De plus, les Fournisseurs tiers peuvent imposer des frais pour accéder à leur Contenu. Vous ne devez jamais payer des frais pour accéder au Contenu et/ou aux Services, en tout ou en partie, à moins que Sony et/ou un Fournisseur tiers n'aient obtenu votre accord préalable pour payer de tels frais. Cependant, si vous ne consentez pas à de tels frais, vous ne pourrez pas accéder au Contenu ou aux Services auxquels ces frais s'appliquent.

PROPRIÉTÉ INTELLECTUELLE / AVIS DE REVENDECTIONS POUR LES VIOLATIONS AUX DROITS DE PROPRIÉTÉ INTELLECTUELLE ET AGENT POUR L'AVIS

Sony respecte la propriété intellectuelle des autres et nous vous demandons de faire de même. Sony a comme politique, à sa discrétion selon le cas, de (a) terminer et/ou désactiver le Contenu de Fournisseurs tiers ou les comptes des utilisateurs des Services qui peuvent porter atteinte ou porter atteinte à maintes reprises aux droits d'auteur ou à la propriété intellectuelle de Sony, de ses Fournisseurs tiers ou d'autres; et/ou (b) faire parvenir les rapports de violations des droits d'auteur aux Fournisseurs tiers et autres pour révision et action conformément aux conditions établies dans les procédures d'un tel Fournisseur tiers relativement à la protection des droits de propriété intellectuelle. Les Logiciels Sony et le Contenu sont protégés par les lois sur les droits d'auteur et des traités internationaux sur les droits d'auteur, ainsi que par d'autres lois et traités sur la propriété intellectuelle. Il peut y avoir des logos exclusifs, des marques de service, des marques de commerce, des ressemblances et des noms de commerce dans les Logiciels Sony, le Contenu ou sur les Services. En rendant les Logiciels Sony et le Contenu disponibles sur les Services, Sony et les Fournisseurs tiers ne vous accordent pas le droit d'utiliser ces logos exclusifs, ces marques de service, ces marques de commerce, ces ressemblances ou ces noms de commerce. Toute utilisation non autorisée des Logiciels Sony, des Services ou du Contenu peut violer les lois sur les droits d'auteur, les lois sur les marques de commerce, les lois sur la vie privée et la publicité, ainsi que des statuts criminels et civils. Tous les droits, titres et intérêts dans et envers les Logiciels Sony et le Contenu et tous les exemplaires ou parties de ces derniers, appartiennent à Sony, ses donneurs de licence, aux Tiers donneurs de licence et/ou aux Fournisseurs tiers. Tous les droits non spécifiquement accordés en vertu de ce CLU sont réservés à Sony, ses donneurs de licence, aux Tiers donneurs de licence, aux fournisseurs et/ou aux Tiers fournisseurs.

Vous êtes responsable de toutes vos activités relatives aux présentes, y compris toute responsabilité légale encourue relative à l'accès, à la navigation ou à l'utilisation des Services par vous ou par d'autres qui utilisent les Services par l'entremise de votre produit Sony ou de votre Compte (tels qu'ils sont définis dans la section Compte d'utilisateur). Vous pouvez utiliser les Logiciels Sony, les Services et le Contenu à des fins légales seulement. Vous ne pouvez pas distribuer, échanger, modifier, vendre ou transmettre quoi que ce soit que vous pouvez copier des Logiciels Sony, des Services ou du Contenu, y compris sans en exclure d'autres, des données, des textes, des logiciels, des ressemblances, des photographies, des images, des graphiques, du son, de la musique, de l'audio, de la vidéo, des messages et des étiquettes pour tout besoin d'affaire, commercial

ou public. Tant que vous vous conformez aux conditions de ce CLU, Sony vous accorde un droit limité non exclusif, non transférables à utiliser la fonction Sony Entertainment Network pour accéder aux Services et au Contenu comme il est établi dans ce CLU. Vous acceptez de plus de ne pas interrompre/perturber ou tenter d'interrompre/perturber l'exploitation des Logiciels Sony, des Services ou du Contenu de toute façon qui soit.

Si vous croyez que votre travail a été copié de toute façon qui constitue une violation à un droit d'auteur ou que vos droits de propriété intellectuelle n'ont pas été respectés, veuillez d'abord communiquer avec le Fournisseur tiers pour ce Service en particulier. Si vous ne pouvez pas communiquer avec un tel Fournisseur tiers ou si le contenu en question appartient à Sony, vous pouvez communiquer avec l'agent de propriété intellectuelle de Sony (indiqué ci-dessous) en incluant les renseignements suivants dans un avis écrit : (a) une signature électronique ou physique de la personne autorisée à agir au nom du propriétaire du droit d'auteur ou de la propriété intellectuelle; (b) une description du travail protégé par un droit d'auteur ou de la propriété intellectuelle que vous alléguiez a été violée; (c) une description du Service en particulier et l'endroit où le document que vous alléguiez a été violé se trouve sur un tel Service avec suffisamment de détails afin que nous puissions trouver le document; (d) votre adresse, numéro de téléphone et adresse électronique; (e) une déclaration par vous que vous croyez de bonne foi que l'utilisation contestée n'est pas autorisée par le propriétaire du droit d'auteur ou de la propriété intellectuelle, son agent ou la loi; et (f) une déclaration par vous, effectuée sous peine de parjure, que les renseignements indiqués dans votre avis sont exacts et que vous êtes le propriétaire du droit d'auteur ou de la propriété intellectuelle ou autorisé à agir au nom du propriétaire du droit d'auteur ou de la propriété intellectuelle. L'agent de Sony concernant les revendications de violation de droit d'auteur ou de propriété intellectuelle est le suivant : Intellectual Property Agent, c/o Sony Electronics Inc., 16530 Via Esprillo, San Diego, CA 92127 É.-U.; télécopieur (858) 942-1111; Courriel : IPagent@am.sony.com.

INDEMNISATION

Vous acceptez d'indemniser, de défendre et de garantir Sony et tous ses agents, directeurs, dirigeants, employés, fournisseurs de renseignements et parents directs et indirects (collectivement, les « Parties indemnisées ») contre toutes les responsabilités et tous les frais (y compris, sans en exclure d'autres, les frais et honoraires d'avocat) encourus par les Parties indemnisées relativement à toute revendication survenant de (i) toute violation ou présumée violation par vous à ce CLU quel qu'en soit le moyen, (ii) tout renseignement que vous soumettez à Sony en vertu des présentes, (iii) toute violation ou présumée violation par vous des droits d'un tiers, (iv) tout dommage causé ou présumé ayant été causé par vous aux Logiciels Sony, aux Services ou au Contenu. L'avocat que vous choisirez

pour défendre ou régler une revendication doit être approuvé par Sony et/ou la(les) Partie(s) indemnisée(s) avant que cette personne soit retenue pour vous représenter et Sony et/ou la(les) Partie(s) indemnisée(s). Vous et votre avocat collaborerez aussi raisonnablement qu'il est requis par la(les) Partie(s) indemnisée(s) pour défendre ou régler toute revendication. Sony et/ou la(les) Partie(s) indemnisée(s) se réservent le droit, à leurs propres frais, d'assumer la défense ou le règlement exclusifs et le contrôle de tout litige assujéti à une indemnisation de votre part. Vous ne devez dans aucun cas consentir à un jugement, règlement, saisie ou privilège ou à tout autre acte défavorable aux intérêts de Sony ou de la Partie indemnisée sans le consentement préalable écrit de Sony et/ou de la(les) Partie(s) indemnisée(s).

FONCTION DE MISE À NIVEAU AUTOMATIQUE / MODIFICATION DU CLU RELATIVEMENT AUX SERVICES

De temps à autre, Sony ou des tiers peuvent automatiquement mettre à jour ou autrement modifier les Logiciels Sony, par exemple, sans en exclure d'autres, dans le but de corriger des erreurs, d'améliorer des caractéristiques ou de rehausser les fonctions de sécurité. De telles mises à jour ou modifications peuvent changer ou effacer la nature de caractéristiques ou d'autres aspects des Logiciels Sony, y compris des caractéristiques sur lesquelles vous pouvez compter. Vous acceptez par les présentes que de telles activités puissent se produire à l'entière discrétion de Sony et que Sony peut conditionner l'utilisation continue des Logiciels Sony sur votre installation complète ou accord à de telles mises à jour ou modifications. Sony peut ajouter, modifier ou retirer toute partie, modalité ou condition du CLU qui s'applique aux Logiciels Sony, aux Services et/ou au Contenu en tout temps sans vous donner de préavis. De telles additions, modifications ou suppressions ou de telles modalités affichées dans la fonction Sony Entertainment Network s'appliqueront dès qu'elles seront affichées. En continuant à accéder aux Services, aux Services de contenu Sony, au Contenu et/ou au Contenu Sony après leur affichage, vous indiquez que vous les acceptez. **SONY PEUT AJOUTER, MODIFIER, SUPPRIMER, RETIRER OU SUSPENDRE L'UN OU L'AUTRE DES SERVICES OU DES SERVICES DE CONTENU SONY, DE FAÇON TEMPORAIRE OU PERMANENTE, À TOUT MOMENT, SANS VOUS AVISER PRÉALABLEMENT ET SANS RESPONSABILITÉ. SANS PORTER ATTEINTE AUX AUTRES DROITS, SONY PEUT SUSPENDRE OU METTRE FIN À CE CLU CONCERNANT LES SERVICES, LES SERVICES DE CONTENU SONY, LE CONTENU ET/OU LE CONTENU SONY IMMÉDIATEMENT APRÈS VOUS AVOIR AVISÉ SI VOUS NE VOUS CONFORMEZ PAS AUX CONDITIONS DE CE CLU.** Sony peut engager tout remède légal et technique pour empêcher la violation et/ou pour faire respecter ce CLU, y compris, sans en exclure d'autres, la terminaison immédiate de votre accès aux Services si Sony croit, à sa discrétion, que vous violez ce CLU.

ACTIVITÉS À RISQUÉ ÉLEVÉ

Les Logiciels Sony ne sont pas insensibles aux défaillances et n'ont pas été conçus, fabriqués ou ne sont pas destinés à une utilisation ou à la revente à titre d'équipement de contrôle en ligne dans des environnements dangereux nécessitant un rendement à sécurité intégrée comme pour le fonctionnement d'installations nucléaires, de navigation aérienne ou de systèmes de communication, du contrôle de la circulation aérienne, d'appareils de survie ou de systèmes d'arme dans lesquels la défaillance des Logiciels Sony pourrait entraîner un décès, une blessure ou des dommages physiques ou environnementaux graves (« Activités à risque élevé »). **SONY, CHACUN DES TIERS DONNEURS DE LICENCE ET CHACUNE DE LEUR SOCIÉTÉ AFFILIÉE RENONCENT SPÉCIFIQUEMENT À TOUTE GARANTIE EXPRESSE OU IMPLICITE OU CONDITION D'ADAPTATION AUX ACTIVITÉS À RISQUÉ ÉLEVÉ.**

RESTRICTIONS SUR L'EXPORTATION DE LA TECHNOLOGIE DE CHIFFREMENT

Les Logiciels Sony et le Contenu peuvent comprendre de la technologie de chiffrement. Vous reconnaissez que toute exportation des Logiciels Sony ou du Contenu comprenant de la technologie de chiffrement des États-Unis ou toute réexportation subséquente de tels logiciels par une personne située à l'extérieur des États-Unis nécessite une licence ou autre autorisation de la part du Bureau de l'industrie et de la sécurité du Département du commerce des É.-U. Vous reconnaissez de plus que les Logiciels Sony ou le Contenu comprenant de la technologie de chiffrement et obtenus de Sony ne sont pas destinés à être utilisés par un utilisateur d'un gouvernement étranger. En acceptant ce contrat de licence, vous acceptez de respecter toutes les lois et tous les règlements applicables sur l'exportation relativement à l'achat et l'utilisation du produit Sony étant acquis, y compris sans en exclure d'autres, les règlements concernant le contrôle d'exportation d'articles cryptographiques et de ne pas transférer ou autoriser le transfert des Logiciels Sony ou du Contenu vers un pays interdit ou autrement en violation de telles restrictions ou règles.

DROITS LIMITÉS DU GOUVERNEMENT DES É.-U.

Les Logiciels Sony sont fournis avec des DROITS LIMITÉS. L'utilisation, la duplication ou la divulgation par le gouvernement des États-Unis sont soumises aux restrictions établies dans les sous-paragraphes (c)(1) et (c)(2) de la disposition des logiciels commerciaux à FAR 52.227 19, et le sous-paragraphe (c)(i)(ii) des droits dans la disposition des logiciels informatiques et données techniques à DOD FAR 252.227-7013 et toute loi ou tout règlement comparable fédéral, provincial ou local. Le fabricant est Sony Electronics Inc., 16530 Via Esprillo, San Diego, CA 92127 É.-U.

RENONCIATION À UN PROCÈS DEVANT JURY

LES PARTIES AUX PRÉSENTES RENONCENT AU PROCÈS PAR JURY EN CE QUI CONCERNE TOUT CONFLIT ISSU OU CONCERNANT CE CLU. Toute cause d'action que vous pouvez avoir relativement à votre utilisation des Services doit être entamée dans un délai d'un (1) an après la survenance de la revendication ou de la cause d'action.

CONTRAT INTÉGRAL, AVIS, RENONCIATION, DIVISIBILITÉ

Ce CLU, la garantie limitée accompagnant le produit Sony, la politique de confidentialité de Sony en vigueur à ce moment et toutes les conditions et modalités affichées sur les Services, ensemble représentent le contrat intégral entre vous et Sony en ce qui concerne le produit Sony, les Logiciels Sony, les Services et le Contenu. Tout avis de Sony relatif aux présentes peut être effectué par lettre, courriel ou affichage sur les Services. Toute défaillance de Sony à exercer ou à faire observer un droit ou une disposition de ce CLU ne représente pas une renonciation à un tel droit ou une telle disposition. Si une partie de ce CLU est reconnu invalide, illégale ou inexécutable, cette disposition sera observée dans la plus grande mesure permise en vue de respecter l'intention de ce CLU et les autres parties demeureront en vigueur.

BÉNÉFICIAIRE TIERS

Chaque Tiers donneur de licence et chaque Fournisseur tiers sont des bénéficiaires tiers expressly envisagés et auront le droit de faire observer chaque disposition de ce CLU relativement aux logiciels, services et contenu, le cas échéant, d'une telle partie.

DURÉE

Ce CLU est en vigueur jusqu'à ce qu'il soit résilié. Sony peut résilier ce CLU immédiatement si vous ne vous conformez pas à ses conditions en vous remettant un avis. Dans un tel cas, vous devez détruire les Logiciels Sony et la documentation connexe et toutes les copies que vous en avez faites. De plus, dès la résiliation, vous n'aurez aucun recours contre Sony, ses sociétés affiliées, ses Tiers donneurs de licence ou ses Fournisseurs tiers pour votre incapacité à utiliser les Logiciels Sony ou la documentation connexe, les Services ou le Contenu.

ANNULATION DE L'ENREGISTREMENT DE VOTRE APPAREIL

Si vous retournez votre produit Sony au vendeur, envoyez votre produit Sony conformément à ce CLU, ou si ce CLU est terminé, vous acceptez : (i) d'annuler l'enregistrement du produit Sony en supprimant tous les comptes que vous avez créé ou auxquels vous avez accédé avec le produit Sony ; et (ii) de réinitialiser le produit Sony aux paramètres d'usine. VOUS ÊTES ENTièrement RESPONSABLE DE RESPECTER LA CONFIDENTIALITÉ DES COMPTES QUE VOUS AVEZ AVEC DES TIERS ET DE TOUT NOM D'UTILISATEUR ET MOT DE PASSE ASSOCIÉ À VOTRE UTILISATION DU PRODUIT SONY.

RÉSOLUDRE DES CONFLITS ; ARBITRAGE ; COUR DES PETITES CRÉANCES

Ce CLU ne sera en aucun cas gouverné ni interprété en référence à une loi basée sur la Loi américaine sur l'uniformisation des transactions informatiques (UCITA) ou toute autre loi dérivée ou reliée à l'UCITA. De plus, la Convention des Nations-unies sur les contrats pour la Vente internationale de marchandises ne s'applique pas à ce CLU.

En cas de conflit, vous acceptez de nous en informer au préalable en contactant Sony Electronics Inc. à 16530 Via Esprillo, San Diego, California 92127, Attn : Legal Department, et d'engager en toute bonne foi des négociations afin d'essayer de résoudre tout conflit pendant au moins 14 jours. Cependant, vous ou Sony (ou l'une de ses filiales) pouvez passer cette procédure de négociation informelle en cas de conflit concernant l'application, la protection ou la validité de vos droits de propriété intellectuelle. « Conflit » est défini comme un désaccord, un grief, une réclamation, une controverse ou une procédure entre vous et toute entité de Sony concernant ou survenant des produits Sony, des logiciels Sony, du Contenu et des Services Sony ou de ce CLU. Conflit doit être entendu dans sa plus large signification.

TOUT CONFLIT NON RÉSOLU PAR LE PROCESSUS DE NÉGOCIATION INFORMEL DÉCRIT CI-DESSUS DOIT ÊTRE RÉSOLU EXCLUSIVEMENT PAR UN ARBITRAGE EXÉCUTOIRE.

Pour commencer un arbitrage, vous ou Sony devez en faire une demande écrite à l'autre partie. L'arbitrage sera réalisé devant un seul arbitre. Il sera administré selon les Procédures expéditives des Règles d'arbitrage commercial, et les Procédures supplémentaires pour les conflits de consommateur si applicable (« Règles ») de l'Association américaine d'arbitrage (« AAA ») ayant effet lorsque la réclamation est déposée. Vous pouvez obtenir une copie des Règles AAA en contactant l'AAA au (800) 778-7879 ou en consultant le site www.adr.org. Les droits de dépôt pour lancer et poursuivre l'arbitrage seront partagés entre vous et nous, mais vos frais ne devront en aucun cas excéder le montant allouable par les règles spéciales pour les Conflits de consommateurs fournies par l'AAA, et Sony couvrira alors tous les frais et dépenses administratives supplémentaires. Cela n'interdit pas l'arbitre d'incomber à la partie gagnante les frais et dépenses d'arbitrage si approprié selon les Règles. Sauf si vous et nous nous accordons différemment, l'arbitrage aura lieu dans le comté et l'état de votre résidence, et les lois fédérales ou d'état applicables gouverneront le fond de tout conflit. La Loi américaine d'arbitrage fédéral, 9 U.S.C. § 1, et suiv., gouvernera l'arbitrage en lui-même et non une loi d'état sur l'arbitrage. La décision de l'arbitre sera exécutoire et finale, sauf en cas de droit limité d'appel selon la Loi américaine d'arbitrage fédéral. L'arbitre peut remettre une décision déclaratoire ou une injonction uniquement en faveur de la partie en

ayant fait la demande, et uniquement dans la mesure nécessaire pour obtenir réparation garantie par cette réclamation individuelle. Tout tribunal compétent au regard des parties peut renforcer la décision de l'arbitre.

Malgré les mentions ci-dessus, vous avez le droit d'intenter une action en justice pour tout conflit auprès de la cour des petites créances ou autre cour similaire à juridiction limitée aux États-Unis, dans la mesure où le montant final ne dépasse pas 15 000 \$, et tant que cette cour dispose des compétences nécessaires et que toutes les autres exigences (y compris le montant de controverse) sont respectées.

Sauf mention expresse dans ce CLU, vous pouvez refuser les changements faits à la prévision d'arbitrage exécutoire si : (1) vous avez déjà commencé à utiliser le produit Sony autorisé au moment où le changement a été fait ; et (2) vous envoyez une notification écrite à l'adresse indiquée au paragraphe précédent dans les 30 jours suivant le changement. Dans ce cas, vous serez toujours lié aux procédures de conflit que vous avez préalablement acceptées et existantes avant que le changement que vous rejetez soit effectué.

Tout conflit déterminé comme non soumis à l'arbitrage et non intenté en cour des petites créances sera poursuivi en justice par l'une des parties dans un tribunal compétente, soit au Tribunal supérieur du Comté de San Diego, soit au Tribunal du district des États-Unis pour le District sud de Californie.

Sauf mention contraire pour les faits précités, chaque partie peut entamer un contentieux immédiatement concernant tout sujet survenant ou lié au présent Contrat pour lequel des mesures de redressement en Équité (ou type équivalent de recours juridique d'urgence) sont recherchées. Vous acceptez que toute violation ou non-conformité avec les termes de ce CLU constitueront une pratique commerciale illégale et déloyale, et causera des dommages irréparables à Sony, ses filiales ou donneurs de licence tiers, pour lesquels des dommages monétaires seraient inadapés, et vous consentez à ce que Sony obtienne les mesures de redressement en Équité ou injonctions que Sony estime nécessaires ou appropriées dans ces circonstances. Ces recours s'ajoutent à d'autres recours disponibles pour Sony sous contrat, en justice ou en équité.

COMMENTAIRES

Si vous avez des questions concernant ce CLU, vous pouvez contacter Sony en écrivant à Sony Technical Response Center, 12451 Gateway Boulevard, Fort Myers, Florida 33913, États-Unis.

© 2014 Sony Electronics Inc. Tous droits réservés.

Pour les clients dans les pays européens

AVIS ET LICENCES DES LOGICIELS UTILISÉS DANS CE PRODUIT

Consultez :

Des traductions non officielles de ce document sont disponibles sur le site Web suivant : <http://support.sony-europe.com>

Les traductions non officielles étrangères de la licence publique généralisée et de la licence publique généralisée amoindrie sont accessibles à partir du lien hypertexte : <http://www.gnu.org/licenses/translations.html>

Warnung

Um Feuer- oder Stromschlaggefahr zu reduzieren, darf dieses Gerät weder Regen noch Feuchtigkeit ausgesetzt werden.

Um die Brand- oder Stromschlaggefahr zu reduzieren, setzen Sie dieses Gerät keinem Tropf- oder Spritzwasser aus, und stellen Sie keine mit Flüssigkeiten gefüllten Gegenstände, wie z. B. Vasen, auf das Gerät.

Um die Brandgefahr zu reduzieren, decken Sie die Ventilationsöffnung des Gerätes nicht mit Zeitungen, Tischdecken, Vorhängen usw. ab. Setzen Sie das Gerät keinen offenen Flammen (z. B. brennende Kerzen) aus.



Öffnen Sie das Gehäuse nicht, da andernfalls die Gefahr eines Stromschlags besteht. Lassen Sie Wartungsarbeiten nur von qualifiziertem Fachpersonal ausführen.

ACHTUNG

Bei nicht ordnungsgemäßem Austausch der Batterie besteht Explosionsgefahr.

Der Austausch darf nur mit demselben oder einem baugleichen Typ erfolgen.

Setzen Sie die Batterien und das Gerät mit eingelegeten Batterien nicht übermäßiger Hitze aus, wie zum Beispiel Sonneneinstrahlung oder einem Feuer.



Dieses Symbol warnt den Benutzer vor nicht isolierter „gefährlicher Spannung“ im Gehäuse des Produkts, die so stark sein kann, dass sie einen Stromschlag bei Personen verursachen kann.



Dieses Symbol weist den Benutzer auf wichtige Anweisungen zur Bedienung und Wartung (Instandhaltung) in der Begleitdokumentation des Geräts hin.

Diese grafischen Symbole befinden sich auf dem Netzteil.

Hinweis für Kunden in Großbritannien und in der Republik Irland

Dieses Gerät ist zu Ihrer Sicherheit und Bequemlichkeit mit einem Spritzgussstecker gemäß BS1363 ausgestattet.

Falls ein Austausch der Sicherung im mitgelieferten Stecker erforderlich ist, muss eine baugleiche Sicherung mit der Nennkapazität der Originalsicherung verwendet werden, die von ASTA oder BSI für BS1362 genehmigt wurde (sie muss also entsprechend gekennzeichnet sein).

Wenn der mit diesem Gerät ausgelieferte Stecker über eine abnehmbare Sicherungsabdeckung verfügt, muss diese nach dem Wechsel der Sicherung wieder angebracht werden. Verwenden Sie den Stecker niemals ohne Sicherungsabdeckung. Falls die Sicherungsabdeckung verloren gegangen ist, wenden Sie sich an eine Wartungsstelle von Sony in Ihrer Nähe.



Entsorgung von gebrauchten Batterien und Akkus und gebrauchten elektrischen und elektronischen Geräten (anzuwenden in den Ländern der Europäischen

Union und anderen europäischen Ländern mit einem separaten Sammelsystem für diese Produkte)

Das Symbol auf der Batterie/dem Akku, dem Produkt oder der Verpackung weist darauf hin, dass das Produkt oder die Batterie/der Akku nicht als normaler Haushaltsabfall zu behandeln sind. Ein zusätzliches chemisches Symbol Pb (Blei) oder Hg (Quecksilber) unter der durchgestrichenen Mülltonne bedeutet, dass die Batterie/der Akku einen Anteil von mehr als 0,0005% Quecksilber oder 0,004% Blei enthält. Durch Ihren Beitrag zum korrekten Entsorgen des Produktes und der Batterie schützen Sie die Umwelt und die Gesundheit Ihrer Mitmenschen. Umwelt und Gesundheit werden durch falsches Entsorgen gefährdet. Materialrecycling hilft, den Verbrauch von Rohstoffen zu verringern.

Bei Produkten, die auf Grund ihrer Sicherheit, der Funktionalität oder als Sicherung vor Datenverlust eine ständige Verbindung zur eingebauten Batterie benötigen, sollte die Batterie nur durch qualifiziertes Servicepersonal ausgetauscht werden. Um sicherzustellen, dass das Produkt und die Batterie korrekt entsorgt werden, geben Sie das Produkt zwecks Entsorgung an einer Annahmestelle für das Recycling von elektrischen und elektronischen Geräten ab. Für alle anderen Batterien entnehmen Sie die Batterie bitte entsprechend dem Kapitel über die sichere Entfernung der Batterie. Geben Sie die Batterie an einer Annahmestelle für das Recycling von

Batterien/Akkus ab. Weitere Informationen über das Recycling dieses Produkts oder der Batterie erhalten Sie von Ihrer Gemeinde, den kommunalen Entsorgungsbetrieben oder dem Geschäft, in dem Sie das Produkt gekauft haben.

Hinweis für Lithiumbatterien: Bitte geben Sie nur entladene Batterien an den Sammelstellen ab. Wegen Kurzschlussgefahr überkleben Sie bitte die Pole der Batterie mit Klebestreifen. Sie erkennen Lithiumbatterien an den Abkürzungen Li oder CR.

Für Kunden in Kanada, Mexiko und Brasilien

Das obige Symbol gilt in der Europäischen Union und in anderen europäischen Ländern mit Getrenntsammlensystemen.

Hinweis für Kunden:

Die folgenden Informationen beziehen sich nur auf Geräte, die in Ländern mit geltenden EU-Richtlinien vertrieben werden.

Dieses Produkt wurde von oder für Sony Corporation, 1-7-1 Konan Minato-ku Tokio, 108-0075 Japan hergestellt. Bei Fragen zur Produktkonformität auf Grundlage der Gesetzgebung der Europäischen Union kontaktieren Sie bitte den Bevollmächtigten Sony Deutschland GmbH, Hedelfinger Strasse 61, 70327 Stuttgart, Deutschland.

Für Kundendienst oder Garantieangelegenheiten wenden Sie sich bitte an die in den Kundendienst- oder Garantiedokumenten genannten Adressen.

Die Gültigkeit der CE-Kennzeichnung ist ausschließlich auf Länder beschränkt, in denen sie gesetzlich verankert ist vorwiegend in Ländern des Europäischen Wirtschaftsraums (EEA, European Economic Area).

WARNUNG **VERSCHLUCKEN SIE KEINESFALLS DIE BATTERIE – ES BESTEHT VERÄTZUNGSGEFAHR DURCH CHEMISCHE SUBSTANZEN**

Die mit diesem Produkt ausgelieferte Fernbedienung enthält eine Knopfzellenbatterie. Wird diese verschluckt, kann sie in nur 2 Stunden zu schweren inneren Verätzungen und schließlich zum Tod führen.

Bewahren Sie neue und verbrauchte Batterien nicht in der Reichweite von Kindern auf. Falls sich das Batteriefach nicht ordnungsgemäß schließen lässt, stellen Sie die Verwendung des Produkts ein und halten Sie das Produkt von Kindern fern.

Wenn Sie vermuten, dass Batterien verschluckt wurden oder in eine Körperöffnung gelangt sind, suchen Sie umgehend einen Arzt auf.

Dieses Gerät wurde geprüft und erfüllt die Auflagen der EMV-Direktive für den Gebrauch von Verbindungskabeln, die kürzer als 3 m sind.

Sicherheitshinweise

- Solange der Player in die Netzsteckdose eingesteckt ist, wird er nach wie vor mit Netzstrom versorgt; dies gilt selbst dann, wenn der Player ausgeschaltet wurde.
- Stellen Sie dieses Gerät so auf, dass das Netzkabel im Fall eines Problems sofort aus der Netzsteckdose gezogen werden kann.
- Das Typenschild befindet sich auf der Unterseite des Players.

Aufstellen

Stellen Sie diesen Player nicht in einen engen Raum, z. B. in ein Bücherregal oder Ähnliches.

Für Kunden in Kanada

Kundenunterstützung von Sony

<http://esupport.sony.com/CA/>

1-877-899-SONY


Bitte wenden Sie sich an uns, bevor Sie das Produkt in das Fachgeschäft zurückbringen

Mitgelieferte Netzkabel


Ihr Medien-Player wird mit Netzkabeln ausgeliefert, die vier verschiedene Steckertypen aufweisen.

Verwenden Sie zu Ihrer eigenen Sicherheit nur das Kabel, das für den Gebrauch in Ihrem Land bzw. in Ihrer Region vorgesehen ist. Verwenden Sie niemals andere Kabeltypen.


Netzkabel (A): für Kunden in Kanada und Mexiko





Netzkabel (B): für Kunden in Großbritannien und in der Republik Irland



Netzkabel (C): für Kunden in Brasilien



Netzkabel (D): für Kunden in sonstigen europäischen Ländern



Sicherheitshinweise

Aufstellungsort

- Stellen Sie den Player an einen gut belüfteten Ort, damit sich im Player kein Hitzestau bildet.
- Stellen Sie den Player nicht auf eine weiche Oberfläche (z. B. auf eine Decke), die die Belüftungsöffnungen blockieren kann.
- Stellen Sie den Player nicht in die Nähe von Wärmequellen oder an einen Ort, der direktem Sonnenlicht, übermäßiger Staubbelastung oder mechanischen Erschütterungen ausgesetzt ist.
- Bringen Sie den Player nicht in den Außenbereich, in Fahrzeuge, auf Schiffe oder sonstige Wasserfahrzeuge.
- Wenn der Player unmittelbar von einem kalten an einen warmen Ort oder in einen sehr feuchten Raum gebracht wird, kann sich auf der Außenfläche und im Inneren des Players Feuchtigkeit bilden. Dies kann die ordnungsgemäße Funktionsweise des Players beeinträchtigen. Lassen Sie in diesem Fall den Player eingeschaltet etwa eine halbe Stunde stehen, bis sich die Feuchtigkeit verflüchtigt hat.
- Stellen Sie den Player nicht auf eine schräge Oberfläche. Er darf nur in einer waagrechten Position verwendet werden.
- Stellen Sie keine schweren oder instabilen Gegenstände auf den Player.
- Ziehen Sie das Netzkabel und alle sonstigen Kabel vom Player ab, wenn Sie den Player transportieren.
- Halten Sie den Player von Geräten mit starken Magnetfeldern wie beispielsweise Mikrowellenherden oder großen Lautsprechern fern.

Stromquellen

- Halten Sie sich beim Abziehen des Netzkabels an die unten beschriebene Vorgehensweise.
 - ① Ziehen Sie das LAN-Kabel ab oder halten Sie den Download über die 4K-Anwendungseinstellung in den Optionen unter „Anwendung“ im Startmenü des Players an.
 - ② Warten Sie nach dem Ausschalten des Players etwa fünf Minuten.
 - ③ Vergewissern Sie sich, dass das Festplattenlaufwerk gerade nicht in Betrieb ist (die Stromanzeige und die HDD-Anzeige müssen ausgeschaltet sein).
 - ④ Ziehen Sie das Netzkabel ab.

- Trennen Sie den Player von der Netzsteckdose, wenn Sie ihn längere Zeit nicht verwenden. Halten Sie beim Abziehen des Netzkabels stets den Stecker fest und ziehen Sie nicht am Kabel.
- Beachten Sie die folgenden Punkte, um eine Beschädigung des Netzkabels zu vermeiden. Ein beschädigtes Netzkabel darf keinesfalls verwendet werden, da es eine Stromschlag- oder Brandgefahr darstellt.
 - Klemmen Sie das Netzkabel nicht zwischen dem Player und der Wand, einem Regal oder Ähnlichem ein.
 - Stellen Sie keine schweren Gegenstände auf das Netzkabel und ziehen Sie nicht am Netzkabel selbst.

Netzteil

- Verwenden Sie ausschließlich das mitgelieferte Netzkabel für diesen Player, da andere Netzteile zu Fehlfunktionen führen können.
- Zerlegen Sie das Netzteil nicht und nehmen Sie keine baulichen Änderungen daran vor.
- Legen Sie das Netzteil nicht in einen geschlossenen Raum wie beispielsweise in ein Bücherregal oder in einen AV-Schrank.
- Schließen Sie das Netzteil nicht an einen elektrischen Reisetransformator an, der zu Hitzebildung und einer Fehlfunktion führen kann.
- Lassen Sie das Netzteil nicht fallen und setzen Sie es keinen Erschütterungen aus.

Einstellung der Lautstärke

Stellen Sie die Lautstärke nicht ein, wenn Sie gerade einen Abschnitt mit einem sehr niedrigen Eingangspegel oder keinen Audiosignalen hören. Andernfalls können Ihr Gehör und die Lautsprecher geschädigt werden, sobald ein Abschnitt mit einem sehr hohen Pegel abgespielt wird.

Reinigung

Reinigen Sie das Gehäuse, Anzeigefeld und die Bedienelemente mit einem weichen Tuch. Verwenden Sie keinesfalls Scheuertücher, Scheuermittel oder Lösungsmittel wie Alkohol oder Benzin.

Austausch der Teile

Im Fall einer Reparatur dieses Players können ausgetauschte Teile zur Wiederverwendung oder Wiederverwertung gesammelt werden.

Anschluss an HDMI-Buchse



Beachten Sie unbedingt die folgenden Hinweise, da die HDMI-Buchse und der Stecker durch eine unsachgemäße Handhabung beschädigt werden können.

- Richten Sie die HDMI-Buchse auf der Rückseite des Players und den HDMI-Stecker sorgfältig aneinander aus, indem Sie die jeweilige Formgebung genau prüfen. Achten Sie darauf, dass der Stecker richtig herum und nicht schräg eingesetzt wird.

HDMI-Buchse



HDMI-Buchse



- Ziehen Sie das HDMI-Kabel beim Transportieren des Players unbedingt ab.



- Halten Sie den HDMI-Stecker gerade, wenn Sie das HDMI-Kabel ein- oder ausstecken. Stecken Sie den HDMI-Stecker nicht verdreht oder mit Gewalt in die HDMI-Buchse.

WICHTIGER HINWEIS

Achtung: Dieser Player kann unendlich lange ein Videostandbild oder eine Bildschirmanzeige auf Ihrem Fernseh Bildschirm abbilden. Falls das Videostandbild oder die Bildschirmanzeige über einen längeren Zeitraum an Ihrem Fernsehgerät abgebildet wird, riskieren Sie eine dauerhafte Beschädigung Ihres Fernsehbildschirms. Insbesondere Fernsehgeräte mit Plasma-Bildschirm und Projektionsfernsehgeräte sind hierfür anfällig.

Falls Sie Fragen oder Probleme bezüglich Ihres Players haben, wenden Sie sich an einen Sony-Fachhändler in Ihrer Nähe.

Hinweis zu MPEG-4 AVC


DIESES PRODUKT WIRD UNTER DER AVC PATENT PORTFOLIO LICENSE FÜR DEN PRIVATEN GEBRAUCH DURCH DEN BENUTZER ODER ANDERWEITIGEN GEBRAUCH OHNE VERGÜTUNG LIZENZIERT, UND ZWAR ZUM (i) CODIEREN VON VIDEODATEN IN ÜBEREINSTIMMUNG MIT DEM AVC-STANDARD („AVC-VIDEO“) UND/ODER (ii) DECODIEREN VON AVC-VIDEODATEN, DIE VON EINEM BENUTZER IM PRIVATEN RAHMEN CODIERT WURDEN UND/ODER VON EINEM VIDEO-ANBIETER STAMMEN, DER ÜBER EINE LIZENZ ZUM ANBIETEN VON AVC-VIDEOS VERFÜGT.

FÜR EINEN ANDEREN ZWECK WIRD KEINE LIZENZ ERTEILT ODER IMPLIZIT GEWÄHRT. WEITERE INFORMATIONEN SIND BEI MPEG LA, L.L.C., ERHÄLTlich. SIEHE [HTTP://WWW.MPEGLA.COM](http://www.mpeg-la.com)

Austauschen der Batterie in der Fernbedienung

Führen Sie die unten genannten Schritte aus, um eine verbrauchte Batterie in der Fernbedienung durch eine neue Batterie zu ersetzen.


- 1 Ziehen Sie das Batteriefach heraus, indem Sie die Taste mit einem schmalen, spitzen Gegenstand (z. B. mit der Spitze eines Stiftes) drücken.**



- 2 Ersetzen Sie die alte Batterie durch eine neue Batterie.**

Beim Einlegen der neuen Batterie muss die Seite ⊕ nach oben zeigen.

CR2032-Batterie, hergestellt von Sony



- 3 Schließen Sie das Batteriefach.**

Informationen zu Warenzeichen

- Die Begriffe HDMI™ und HDMI High-Definition Multimedia Interface sowie das HDMI-Logo sind Warenzeichen oder eingetragene Warenzeichen von HDMI Licensing LLC in den USA und anderen Ländern.
- In Lizenz von Dolby Laboratories gefertigt. Dolby und das Doppel-D-Symbol sind Warenzeichen von Dolby Laboratories.
- TUXERA ist ein eingetragenes Warenzeichen von Tuxera Inc. in den USA und anderen Ländern.
- Sonstige System- und Produktnamen sind in der Regel Warenzeichen oder eingetragene Warenzeichen der jeweiligen Hersteller. In diesem Dokument sind Warenzeichen und eingetragene Warenzeichen nicht ausdrücklich durch die Symbole ™ und ® gekennzeichnet.



LEADING FILE SYSTEM INTEROPERABILITY

Technische Daten

Ein-/Ausgangsbuchsen	
HDMI OUT 1 (für AUDIO VIDEO)	19-poliger HDMI-Standardstecker Video: 3840 × 2160 Bildfrequenz: 24p, 25p, 30p, 50p, 60p Audio: Linear PCM, Dolby Digital, Dolby Digital Plus
HDMI OUT 2 (für AUDIO)	19-poliger HDMI-Standardstecker Linear PCM, Dolby Digital, Dolby Digital Plus
LAN (100)	100 BASE-TX-Terminal
EXTRA HDD	Hinterer USB-Anschluss: Für den Anschluss eines externen Festplattenlaufwerks*1 *2
USB	Vorderer USB-Anschluss: Für den Anschluss einer USB-Speichereinheit*2
Stromversorgung und Sonstiges	
Betriebsspannung	Eingang: 19,5 V Gleichstrom, 1,6 A
Stromaufnahme	In Betrieb: 35 W Standby: 0,5 W*3
Netzteil	Eingang: 100 V - 240 V Wechselstrom, 50/60 Hz, 1,0 A Ausgang: 19,5 V Gleichstrom, 4,35 A
Umgebungstemperatur bei Betrieb	5 °C bis 35 °C
Luftfeuchtigkeit bei Betrieb	25% bis 80%
Abmessungen (Näherungswerte)	250 mm × 250 mm × 50 mm (Breite/Tiefe/Höhe) ohne vorstehende Teile
Gewicht (Näherungswert)	1,8 kg
Zubehör	
Mitgeliefertes Zubehör	Netzkabel (4)/Netzteil (1)/Fernbedienung RMT-D304 mit CR2032-Batterie (1)/Einführungsanleitung, Referenzanleitung und Garantiekarte

*1 Diese Funktion ist nicht in allen Ländern/Regionen verfügbar.

*2 Sie finden ausführliche Informationen zu den USB-Geräten, die an den Player angeschlossen werden können, in der „Hilfe“ (http://rd1.sony.net/help/hv/fmpx5/h_zz).

*3 Der Wert steht für die ungefähre Stromaufnahme bei normalem Betrieb. Die Standby-Stromaufnahme kann sich unmittelbar nach dem Ausschalten der Stromzufuhr oder während einer Aktualisierung der Software erhöhen.

Änderungen der technischen Daten und des Designs vorbehalten.

HINWEISE UND LIZENZEN FÜR IN DIESEM PRODUKT VERWENDETE SOFTWARE

Weitere Informationen:

Inoffizielle Übersetzungen dieses Dokuments
finden Sie auf der folgenden Website:
<http://support.sony-europe.com>

Eine inoffizielle Übersetzung der General Public
Licence und der Lesser General Public Licence steht
auf der folgenden Website zur Verfügung:
<http://www.gnu.org/licenses/translations.html>



* 1 - 4 5 4 1 6 0 7 1 1 / *

Printed using VOC (Volatile Organic
Compound)-free vegetable oil based ink.

<http://www.sony.net/>

©2014 Sony Corporation Printed in Japan