




acer
explore beyond limits™

Acer Projection Screen




User's Manual




Acer Projection Screen User Guide

1. Gently and smoothly pull the screen down. When the screen is extended sufficiently, release the handle to lock the screen in place (#illustration A).




2. To store the screen, pull down sharply on the handle to release the lock (#illustration B). Guide the screen up gently (#illustration C) until it is fully stowed.




Note: Be careful not to damage the screen when pulling it down to release the lock.

Acer 投影幕使用指南

1. 輕緩將布幕向下拉伸展開至適當位置時鬆手，裝置便將布幕鎖定(示意 A)。



2. 當再次將布幕向下一拉(示意 B)，該裝置便解除鎖定，鬆手後布幕立即均速捲回保護殼內(示意 C)。



注意事項: 當將布幕向下拉伸做解除鎖定時，動作請輕緩，以免裝置故障。