

Symbol for Separate Collection in European Countries

This symbol indicates that this product is to be collected separately.

The following apply only to users in European countries:



- This product is designated for separate collection at an appropriate collection point. Do not dispose of as household waste.
- For more information, contact the retailer or the local authorities in charge of waste management.

Important Notice

The Digital Photo Frame has been thoroughly tested to be certain it meets our own **exacting quality control standards**. Please take a few moments to review the following **important information** before using it.

For your safety

CAUTION

- **TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER OR BACK. THERE ARE NO USER-SERVICEABLE PARTS INSIDE.**
- **TO DEDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS UNIT TO WATER OR MOISTURE.**



The lightning flash with arrow-head symbol within an equilateral triangle is intended to alert the user to the presence of insinuated “dangerous voltage” within the unit’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the unit.

IMPORTANT SAFETY INSTRUCTIONS

All the safety and operating instructions should be read, adhered to and followed before the unit is operated.

DANGER

To reduce the risk of electric shock, burns, fire or injury:

1. Always unplug the unit from the electrical outlet immediately after using.
2. Do not use while bathing or in a shower.
3. Do not place or store unit where it can cal fall or be pulled into a tub or sink.
4. Do not place in or drop into water or other liquid.
5. Do not reach for unit that has fallen into water.
6. Care should be taken so that objects do not fall and liquids are not spilled onto the unit.


Package contents

(1)	DPF-700	(3)	Power adapter
(2)	Multi-language user’s manual	(4)	Stand

## Product Overview



- **Front & Top Side:**

- (1) Power Switch
- (2) SD/MMC/MS
- (3) 7" TFT LCD panel



- **Back & Left Side :**

- (1) Navigation buttons
- (2) Enter button
- (3) ESC button
- (4) Wall mount hole
- (5) Stand hole
- (6) USB to PC connection
- (7) USB Host for pen drive
- (8) DC power



## Install the stand

- Follow the illustration to fix the stand to the main unit.
- You can put the stand to landscape or portrait position.

