

WARRANTY CARD

All dreamGEAR/i.Sound products come with a limited warranty and have been subjected to a thorough series of tests to ensure the highest level of dependability and compatibility. It is unlikely that you will experience any problem, but if a defect should become apparent during the use of this product, dreamGEAR warrants to the original consumer purchaser that this product will be free from defects in material and workmanship for a period of 120 days from the date of your original purchase. If a defect covered by this warranty occurs, dreamGEAR, at its option, will repair or replace the product purchased at no charge. If a replacement is necessary and your product is no longer available, a comparable product may be substituted at the sole discretion of dreamGEAR.

This warranty does not cover normal wear and tear, abusive use or misuse, modification, tampering or by any other cause not related to either materials or workmanship. This warranty does not apply to products used for any industrial, professional or commercial purposes.

For service on any defective product under the 120-day warranty policy, please contact Consumer Support to obtain a Return Authorization Number.

NOTE: dreamGEAR will not process any defective claims without a Return Authorization Number.

Consumer Support Hotline:

877-999-DREAM (3732) (U.S. and Canada only) or
310-222-1045 (International)

Consumer Support Email: support@dreamgear.net

Websites:

www.dreamgear.net
www.isound.net



User's Guide

**Package Contents:**

- Comfort Grip
- User's Guide / Warranty Card
- Registration Card

**Contenido del Paquete:**




- Comfort Grip
- Manual del Usuario / Tarjeta de Garantía
- Tarjeta de Registro

**Contenu de l'Emballage:**

- Comfort Grip
- Guide d'Utilisation / Carte de Garantie
- Carte d'Enregistrement

How to Install the Comfort Grip:

Cómo Instalar el Comfort Grip:
Installation du Comfort Grip:

**How to Remove the Comfort Grip:**

Cómo Quitar la Comfort Grip:
Comment Faire pour Supprimer le Comfort Grip: