


- F** p. 2 + 5 Service consommateurs & commande accessoires  
tél. 0 810 77 47 74 - www.tefal.fr
- NL** p. 2 + 9 + 31 318 58 24 24 - www.tefal.nl
- D** p. 2 + 13 + 49 212 387 400 - www.tefal.de
- I** p. 2 + 17 + 39 199 20 73 54 - www.tefal.it
- GB** p. 2 + 21 Consumer Service & Accessories ordering  
tel. 44 845 725 85 88 - www.tefal.co.uk
- GR** p. 2 + 25 + 30 801 11 97 101 - www.tefal.com  
210 -6371251
- TR** p. 2 + 29

# Tefal

## MIXEUR CUISEUR steamer blender



- F
- NL
- D
- I
- GB
- GR
- TR

Tefal

www.tefal.com

\* COMPAGNIE 360 EURO RSCG - 200892 - 0308 - R.C.S. TEFAL amey B 301 501 920 - Réf. 2000942821

www.tefal.com




fig. 1




fig. 2




fig. 3




fig. 4




fig. 5




fig. 6




fig. 7




fig. 8