



### Addendum

- UK -** To fully recharge the batteries via the power adapter, the decoder must be in the **ON** position (3 blue LEDs lit up). Charging of the batteries is not complete until the charge indicator stays lit up in green for a period of longer than 30 seconds (without flashing). This procedure may have to be carried out as of the first use.  
Note: The decoder's batteries can also be recharged using an external charger.
- F -** Pour une recharge complète des batteries via l'adaptateur secteur, le décodeur doit être en position **ON** (3 diodes bleues allumées). La charge des batteries n'est complète que lorsque le témoin de charge reste allumé vert pendant une période supérieure à 30 secondes (sans clignoter). Cette opération peut être effectuée dès la première utilisation.  
Remarque : Les batteries du décodeur peuvent également être rechargées sur un chargeur externe..
- D -** To fully recharge the batteries via the power adapter, the decoder must be in the **ON** position (3 blue LEDs lit up). Charging of the batteries is not complete until the charge indicator stays lit up in green for a period of longer than 30 seconds (without flashing). This procedure may have to be carried out as of the first use.  
Note: The decoder's batteries can also be recharged using an external charger.
- NL -** Om de batterijen volledig op te laden met de voedingsadapter moet de decoder in de stand **ON** staan (er branden drie blauwe LED's). De batterijen zijn pas volledig opgeladen wanneer de LED zonder knipperen langer dan 30 seconden groen blijft branden. Deze procedure moet mogelijk bij een eerste gebruik worden uitgevoerd.  
Opmerking: de batterijen van de decoder kunnen ook worden opgeladen met behulp van een externe oplader.
- I -** To fully recharge the batteries via the power adapter, the decoder must be in the **ON** position (3 blue LEDs lit up). Charging of the batteries is not complete until the charge indicator stays lit up in green for a period of longer than 30 seconds (without flashing). This procedure may have to be carried out as of the first use.  
Note: The decoder's batteries can also be recharged using an external charger.
- E -** To fully recharge the batteries via the power adapter, the decoder must be in the **ON** position (3 blue LEDs lit up). Charging of the batteries is not complete until the charge indicator stays lit up in green for a period of longer than 30 seconds (without flashing). This procedure may have to be carried out as of the first use.  
Note: The decoder's batteries can also be recharged using an external charger.
- P -** To fully recharge the batteries via the power adapter, the decoder must be in the **ON** position (3 blue LEDs lit up). Charging of the batteries is not complete until the charge indicator stays lit up in green for a period of longer than 30 seconds (without flashing). This procedure may have to be carried out as of the first use.  
Note: The decoder's batteries can also be recharged using an external charger.