

**SONY** 1-800-829-8888 1-800-829-8888

Our product warranty is limited only to the USB flash drive itself, when used normally in accordance with these operating instructions and with the accessories that were included with this unit in the specified or recommended system environment. Services provided by the Company, such as user support, are also subject to these restrictions.

The Company cannot be held responsible for any damage or loss resulting from the use of this unit, or for any claim from a third party.

The Company cannot accept any liability for problems with your computer or other hardware arising from the use of this product. The suitability of this product for specific hardware, software, or peripherals; operating conflicts with other installed software; data loss; or accidental or unavoidable damages.

The Company cannot accept any liability for financial damages, lost profits, claims from third parties, or anything from the use of the software provided with this unit.

The software specifications may be subject to change without notice.

Français

## AVERTISSEMENT

Tenir hors de portée des enfants. En cas d'ingestion, consulter immédiatement un médecin.

Afin de réduire les risques d'incendie ou de choc électrique, n'exposez pas cet appareil à la pluie ni à l'humidité. Pour éviter toute électrocution, ne pas ouvrir le boîtier. Conservez l'unité dans un lieu sec et protégé des intempéries.

Informations client

La référence du modèle et le numéro de série sont indiqués à l'arrière du produit. Notez les numéros de série dans un endroit sûr. Afin de réduire les risques d'incendie ou de choc électrique, n'exposez pas cet appareil à la pluie ni à l'humidité. Pour éviter toute électrocution, ne pas ouvrir le boîtier. Conservez l'unité dans un lieu sec et protégé des intempéries.

Referéncia do modelo e número de série

Para los utilizadores en Canadá Cet appareil numérique de la classe II est conforme à la norme NMB-003 du Canada. Pour les clients en Europe Ce produit est conforme aux normes européennes suivantes : 89/330/CEE, 92/11/CEE (directive CEM) 93/68/CEE (directive de marquage CE) Le produit est conforme aux normes de classification EN 50522 Class B et EN 50424 pour une utilisation dans les environnements suivants : zones résidentielles, commerciales ou industrielles.

Para los clientes en Europa Este producto cumple con las siguientes normas europeas : 89/330/CEE, 92/11/CEE (directiva EMC) 93/68/CEE (directiva de marcado CE) El producto es conforme con las normas de clasificación EN 50522 Clase B y EN 50424 para su utilización en los siguientes entornos : zonas residenciales, comerciales o industriales.

For Customers in the U.S.A. If you have any questions about this product, you may call: Sony Customer Information Center 1-800-242-SONY6699. The number below is for the FCC related matters only.

Regulatory Information

Declaration of Conformity

Trade Name : SONY
Model No. : USM256H, USM512H, USM1GH, USM2GH
Responsible Party : Sony Electronics Inc.
Address : 1650 Via Eppirito, San Diego, CA 92127 U.S.A.
Telephone Number : 858-942-2298

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.
The shielded interface cable and connectors must be used in order to comply with the limits for the digital device pursuant to part B of 15 of FCC Rules.

For Customers in CANADA This Class B digital product complies with Canadian ICES-003.

For Customers in Europe This product conforms to the following European Directives, 89/330/EEC, 92/11/EEC (EMC Directive), 93/68/EEC (CE Marking Directive). This product is also certified to EN50522 Class B and EN50424 for use in the following areas: residential, commercial, and light industrial.

Disposal of Old Electrical & Electronic Equipment (Applicable in the European Union and other European countries with separate collection systems)

This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise result from inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources. For more information on the correct handling of recycling of this product, please contact your local Civic Offices, your household waste disposal service or the shop where you purchased the product.

For Customers in Asia Pacific Region
**FOR MICRO VAULT™ USB Flash Drive only**
**Limited warranty for Customer in Asia Pacific region.**

If this product proves defective in workmanship or materials when used in accordance with the guidelines and conditions provided in the instruction manual, Sony will repair or replace this product with an equivalent product free of charge within 1 year after purchase date. This warranty is subject to the conditions and limitations herein. Sony shall not be liable for loss or damage to data stored in the product irrespective cause.

**NOTE: “FOR YOUR PROTECTION”**
Please retain your original sales receipt to receive warranty coverage. For more information on Sony Authorized Service Centers, please access the ‘Support Network’ section in the following web page.

http://www.csa.sony.com/

When Using USB Flash Drive for the First Time (Installing the Device Driver)

Initially, the device is not installed automatically when you connect the Micro Vault™ Tiny. However, with some USB 2.0 cards or boards, you may need to initiate installation manually.

Follow the instructions displayed on the screen to search for a suitable driver. Windows 98 and Windows 98SE are not supported.

### Basic Operation

Note:
• Please remove the Micro Vault Tiny properly following the procedure described in this manual. Otherwise, data may not be recovered correctly.
• This compression software is not easily accessible; you can use a USB hub to attach the Micro Vault Tiny to the USB port connector of your computer.


Setup
Connect Micro Vault Tiny to a USB port directly on the computer.
When running Windows XP, Windows 2000 or Windows Me
This device appears (The drive name varies, depending on your computer system). You can now copy and save data on the Micro Vault Tiny by dragging files and folders on the drive icon, just as you would when copying data to a hard disk or to a floppy disk.


When running Mac OS 9.0 and higher
When running Windows 2000 or Windows Me
This device appears (The drive icon for Windows 2000 or Windows Me).

You can now copy and save data on the Micro Vault Tiny by dragging files and folders on the drive icon, just as you would when copying data to a hard disk or to a floppy disk.

Meanings of the Indicator Light
When the Micro Vault Tiny is in use, the indicator light indicates its status as follows.

Indicator Light Status	Meaning
Off	Standby
On	Data transfer in progress (Do not remove the Micro Vault Tiny while the indicator light is flashing).

Disconnection
**When running Windows XP**
Double-click  (Safely Remove Hardware) in the task tray in the lower right portion of the screen. In the window that appears, select the name of the device that is to be removed, then click the Stop button. When the Stop a Hardware Device screen appears, make sure that the correct information is displayed, and then click the OK button. When the “Safe to Remove Hardware” dialog box appears, click the Stop button.

**When running Windows 2000 or Windows Me**
Double-click  (Unplug or Eject Hardware) in the task tray in the lower right portion of the screen, select the name of the device that is to be removed, then click the Stop button. When the Stop a Hardware Device screen appears, make sure that the correct information is displayed and then click the OK button. When a message appears indicating that the device can be safely removed, disconnect the Micro Vault Tiny.

About Micro Vault Virtual Expander software
This software is pre-installed in the Micro Vault Tiny.
This is compression software specifically designed for the Micro Vault Tiny. For more details on its use, see the README file stored in the Micro Vault Tiny.

The compression ratio will differ depending on the file.
• Files that have already been compressed and files of 2 KB or less are saved unchanged, without being compressed.
• If the software becomes unstable during use, visit the following URL to download the latest version. Only products with Micro Vault Virtual Expander installed at the time of purchase can download from the Web site.

http://www.sony.net/Products/Media/MicroVault/

• Supported OS: Windows XP (SP1 and higher), Windows 2000 (SP3 and higher)

Notes on Use
• When formatting the device, use the format software which you can download from the Web site. To avoid any changes of the specifications, do not format the device in any other way.
• The Micro Vault Tiny may not function correctly if it is connected to the computer when the computer is in a sleep mode. To avoid this problem, do not use the Micro Vault Tiny from the computer before performing any of these operations.

• Do not place the unit in locations that are:
• extremely hot or cold
• extremely humid
• exposed to direct sunlight

• Clean the unit with a soft, dry cloth or a soft cloth lightly moistened with a mild detergent solution.
Do not use any type of solvent, such as alcohol or benzene, which may damage the finish.

• If the unit does not operate when connected to a USB port, try again after verifying that the front and rear of the unit are oriented correctly.
• Do not touch the connectors with your fingers, metal objects, etc.
• Do not drop or bend the unit or subject it to severe shocks.

This is strongly recommended that you periodically back up data written on the unit. Sony Corporation assumes no liability for any damage or loss of data that may occur.

Precautions for Transfer and Duplication
If data stored on the Micro Vault Tiny is deleted or reformatted using the standard methods, the data only appears to be removed on a superficial level, and it may be possible for someone to retrieve and reuse the data from bits of special software.

To avoid information leaks and other problems of this sort, it is recommended that you use commercially available software designed to completely remove all data from the Micro Vault Tiny.

Notes on Use
• Micro Vault Tiny is a trademark of Sony Corporation.
• Microsoft and Windows are registered trademarks of Microsoft Corporation in the United States and other countries.
• Mac and Macintosh are trademarks of Apple Computer, Inc., registered in the U.S. and other countries.

• Other system names and product names that appear in this manual are registered trademarks or trademarks of their respective owners. Note that the ™ and ® symbols are not used in this manual.

Our product warranty is limited only to the USB flash drive itself, when used normally in accordance with these operating instructions and with the accessories that were included with this unit in the specified or recommended system environment. Services provided by the Company, such as user support, are also subject to these restrictions.

The Company cannot be held responsible for any damage or loss resulting from the use of this unit, or for any claim from a third party.

The Company cannot accept any liability for problems with your computer or other hardware arising from the use of this product. The suitability of this product for specific hardware, software, or peripherals; operating conflicts with other installed software; data loss; or accidental or unavoidable damages.

The Company cannot accept any liability for financial damages, lost profits, claims from third parties, or anything from the use of the software provided with this unit.

The software specifications may be subject to change without notice.

Français

## AVERTISSEMENT

Tenir hors de portée des enfants. En cas d'ingestion, consulter immédiatement un médecin.

Afin de réduire les risques d'incendie ou de choc électrique, n'exposez pas cet appareil à la pluie ni à l'humidité. Pour éviter toute électrocution, ne pas ouvrir le boîtier. Conservez l'unité dans un lieu sec et protégé des intempéries.

Informations client

La référence du modèle et le numéro de série sont indiqués à l'arrière du produit. Notez les numéros de série dans un endroit sûr. Afin de réduire les risques d'incendie ou de choc électrique, n'exposez pas cet appareil à la pluie ni à l'humidité. Pour éviter toute électrocution, ne pas ouvrir le boîtier. Conservez l'unité dans un lieu sec et protégé des intempéries.

Referéncia do modelo e número de série

Para los utilizadores en Canadá Cet appareil numérique de la classe II est conforme à la norme NMB-003 du Canada. Pour les clients en Europe Ce produit est conforme aux normes européennes suivantes : 89/330/CEE, 92/11/CEE (directive CEM) 93/68/CEE (directive de marquage CE) Le produit est conforme aux normes de classification EN 50522 Class B et EN 50424 pour une utilisation dans les environnements suivants : zones résidentielles, commerciales ou industrielles.

Para los clientes en Europa Este producto cumple con las siguientes normas europeas : 89/330/CEE, 92/11/CEE (directiva EMC) 93/68/CEE (directiva de marcado CE) El producto es conforme con las normas de clasificación EN 50522 Clase B y EN 50424 para su utilización en los siguientes entornos : zonas residenciales, comerciales o industriales.

For Customers in the U.S.A. If you have any questions about this product, you may call: Sony Customer Information Center 1-800-242-SONY6699. The number below is for the FCC related matters only.

Regulatory Information

Declaration of Conformity

Trade Name : SONY
Model No. : USM256H, USM512H, USM1GH, USM2GH
Responsible Party : Sony Electronics Inc.
Address : 1650 Via Eppirito, San Diego, CA 92127 U.S.A.
Telephone Number : 858-942-2298

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.
The shielded interface cable and connectors must be used in order to comply with the limits for the digital device pursuant to part B of 15 of FCC Rules.

For Customers in CANADA This Class B digital product complies with Canadian ICES-003.

For Customers in Europe This product conforms to the following European Directives, 89/330/EEC, 92/11/EEC (EMC Directive), 93/68/EEC (CE Marking Directive). This product is also certified to EN50522 Class B and EN50424 for use in the following areas: residential, commercial, and light industrial.

Disposal of Old Electrical & Electronic Equipment (Applicable in the European Union and other European countries with separate collection systems)

This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise result from inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources. For more information on the correct handling of recycling of this product, please contact your local Civic Offices, your household waste disposal service or the shop where you purchased the product.

For Customers in Asia Pacific Region
**FOR MICRO VAULT™ USB Flash Drive only**
**Limited warranty for Customer in Asia Pacific region.**

If this product proves defective in workmanship or materials when used in accordance with the guidelines and conditions provided in the instruction manual, Sony will repair or replace this product with an equivalent product free of charge within 1 year after purchase date. This warranty is subject to the conditions and limitations herein. Sony shall not be liable for loss or damage to data stored in the product irrespective cause.

**NOTE: “FOR YOUR PROTECTION”**
Please retain your original sales receipt to receive warranty coverage. For more information on Sony Authorized Service Centers, please access the ‘Support Network’ section in the following web page.

http://www.csa.sony.com/

When Using USB Flash Drive for the First Time (Installing the Device Driver)

Initially, the device is not installed automatically when you connect the Micro Vault™ Tiny. However, with some USB 2.0 cards or boards, you may need to initiate installation manually.

Follow the instructions displayed on the screen to search for a suitable driver. Windows 98 and Windows 98SE are not supported.

### Basic Operation

Note:
• Please remove the Micro Vault Tiny properly following the procedure described in this manual. Otherwise, data may not be recovered correctly.
• This compression software is not easily accessible; you can use a USB hub to attach the Micro Vault Tiny to the USB port connector of your computer.


Setup
Connect Micro Vault Tiny to a USB port directly on the computer.
When running Windows XP, Windows 2000 or Windows Me
This device appears (The drive name varies, depending on your computer system). You can now copy and save data on the Micro Vault Tiny by dragging files and folders on the drive icon, just as you would when copying data to a hard disk or to a floppy disk.

When running Mac OS 9.0 and higher
When running Windows 2000 or Windows Me
This device appears (The drive icon for Windows 2000 or Windows Me).

You can now copy and save data on the Micro Vault Tiny by dragging files and folders on the drive icon, just as you would when copying data to a hard disk or to a floppy disk.

Meanings of the Indicator Light
When the Micro Vault Tiny is in use, the indicator light indicates its status as follows.

Indicator Light Status	Meaning
Off	Standby
On	Data transfer in progress (Do not remove the Micro Vault Tiny while the indicator light is flashing).

Disconnection
**When running Windows XP**
Double-click  (Safely Remove Hardware) in the task tray in the lower right portion of the screen. In the window that appears, select the name of the device that is to be removed, then click the Stop button. When the Stop a Hardware Device screen appears, make sure that the correct information is displayed, and then click the OK button. When the “Safe to Remove Hardware” dialog box appears, click the Stop button.

**When running Windows 2000 or Windows Me**
Double-click  (Unplug or Eject Hardware) in the task tray in the lower right portion of the screen, select the name of the device that is to be removed, then click the Stop button. When the Stop a Hardware Device screen appears, make sure that the correct information is displayed and then click the OK button. When a message appears indicating that the device can be safely removed, disconnect the Micro Vault Tiny.

About Micro Vault Virtual Expander software
This software is pre-installed in the Micro Vault Tiny.
This is compression software specifically designed for the Micro Vault Tiny. For more details on its use, see the README file stored in the Micro Vault Tiny.

The compression ratio will differ depending on the file.
• Files that have already been compressed and files of 2 KB or less are saved unchanged, without being compressed.
• If the software becomes unstable during use, visit the following URL to download the latest version. Only products with Micro Vault Virtual Expander installed at the time of purchase can download from the Web site.

http://www.sony.net/Products/Media/MicroVault/

• Supported OS: Windows XP (SP1 and higher), Windows 2000 (SP3 and higher)

Notes on Use
• When formatting the device, use the format software which you can download from the Web site. To avoid any changes of the specifications, do not format the device in any other way.
• The Micro Vault Tiny may not function correctly if it is connected to the computer when the computer is in a sleep mode. To avoid this problem, do not use the Micro Vault Tiny from the computer before performing any of these operations.

• Do not place the unit in locations that are:
• extremely hot or cold
• extremely humid
• exposed to direct sunlight

• Clean the unit with a soft, dry cloth or a soft cloth lightly moistened with a mild detergent solution.
Do not use any type of solvent, such as alcohol or benzene, which may damage the finish.

• If the unit does not operate when connected to a USB port, try again after verifying that the front and rear of the unit are oriented correctly.
• Do not touch the connectors with your fingers, metal objects, etc.
• Do not drop or bend the unit or subject it to severe shocks.

This is strongly recommended that you periodically back up data written on the unit. Sony Corporation assumes no liability for any damage or loss of data that may occur.

Precautions for Transfer and Duplication
If data stored on the Micro Vault Tiny is deleted or reformatted using the standard methods, the data only appears to be removed on a superficial level, and it may be possible for someone to retrieve and reuse the data from bits of special software.

To avoid information leaks and other problems of this sort, it is recommended that you use commercially available software designed to completely remove all data from the Micro Vault Tiny.

Notes on Use
• Micro Vault Tiny is a trademark of Sony Corporation.
• Microsoft and Windows are registered trademarks of Microsoft Corporation in the United States and other countries.
• Mac and Macintosh are trademarks of Apple Computer, Inc., registered in the U.S. and other countries.

• Other system names and product names that appear in this manual are registered trademarks or trademarks of their respective owners. Note that the ™ and ® symbols are not used in this manual.

Entsorgung von gebrauchten elektrischen und elektronischen Geräten (anzuwenden in den Ländern der Europäischen Union und in den angrenzenden Ländern mit einem separaten Sammelsystem für diese Geräte)

Dieses Symbol auf dem Produkt oder seiner Verpackung weist darauf hin, dass dieses Produkt nicht als Hausmüll zu behandeln ist, sondern an einer Sammelstelle für das Recycling von elektrischen und elektronischen Geräten abgegeben werden muss.

Durch Ihren Beitrag zum Umweltschutz dieses Produkts schützen Sie die Umwelt und die Gesundheit Ihrer Mitmenschen. Umwelt und Gesundheit werden durch falsches Entsorgen gefährdet. Materialrecycling hilft, den Verbrauch von Rohstoffen zu verringern. Weitere Informationen zu diesem Thema sind unter dem Symbol erhältlich. (Detaillered description of hardware), comprehe que la información es correcta y haga clic en el botón [Aceptar]. Cuando aparece el mensaje "Atora se puede quitar con total seguridad el dispositivo", desconecte el Micro Vault Tiny.

Wenn Sie das USB-Speichermedium zum ersten Mal benutzen (Installieren des Gerätetreibers)

Normalerweise wird der Gerätetreiber automatisch installiert, wenn Sie den Micro Vault Tiny anschließen. Bei einigen USB 2.0-Karten oder -Plattinen müssen Sie die Installation jedoch manuell starten. Gehen Sie nach den Anweisungen auf dem Bildschirm vor, um einen geeigneten Treiber zu suchen.

Windows 98 und Windows 98SE werden nicht unterstützt.

### Grundfunktionen

Hinweis:
• Trennen Sie die Verbindung mit dem Micro Vault Tiny bitte ordnungsgemäß wie in diesem Handbuch beschrieben. Andernfalls werden Daten möglicherweise nicht korrekt gespeichert.
• Wenn der USB-Anschluss nicht zugänglich ist, können Sie den Micro Vault Tiny über einen USB-Hub an USB-Anschlüssen des Computers anbringen.

Anschließen
Schließen Sie den Micro Vault Tiny an einen USB-Anschluss direkt an der Computer- oder Unter-USB-Port. Wenn der Micro Vault Tiny an den Computer angeschlossen ist, wird das Laufwerkspiegel als Laufwerk Micro Vault Tiny-Gerät angezeigt. (Der Laufwerkname hängt von Ihrem Computersystem ab.)

Unter Windows XP, Windows 2000 oder Windows Me
Wenn Sie Micro Vault Tiny an den Computer angeschlossen ist, wird das Laufwerkspiegel als Laufwerk Micro Vault Tiny-Gerät angezeigt. (Der Laufwerkname hängt von Ihrem Computersystem ab.)

Unter Mac OS 9.0 und höher
Wenn Sie Micro Vault Tiny an den Computer angeschlossen ist, wird das Laufwerkspiegel als Laufwerk Micro Vault Tiny-Gerät angezeigt. (Der Laufwerkname hängt von Ihrem Computersystem ab.)

Unter Windows XP, Windows 2000 oder Windows Me
Wenn Sie Micro Vault Tiny an den Computer angeschlossen ist, wird das Laufwerkspiegel als Laufwerk Micro Vault Tiny-Gerät angezeigt. (Der Laufwerkname hängt von Ihrem Computersystem ab.)

Unter Mac OS 9.0 und höher
Wenn Sie Micro Vault Tiny an den Computer angeschlossen ist, wird das Laufwerkspiegel als Laufwerk Micro Vault Tiny-Gerät angezeigt. (Der Laufwerkname hängt von Ihrem Computersystem ab.)

Unter Windows XP, Windows 2000 oder Windows Me
Wenn Sie Micro Vault Tiny an den Computer angeschlossen ist, wird das Laufwerkspiegel als Laufwerk Micro Vault Tiny-Gerät angezeigt. (Der Laufwerkname hängt von Ihrem Computersystem ab.)

Unter Mac OS 9.0 und höher
Wenn Sie Micro Vault Tiny an den Computer angeschlossen ist, wird das Laufwerkspiegel als Laufwerk Micro Vault Tiny-Gerät angezeigt. (Der Laufwerkname hängt von Ihrem Computersystem ab.)

Unter Windows XP, Windows 2000 oder Windows Me
Wenn Sie Micro Vault Tiny an den Computer angeschlossen ist, wird das Laufwerkspiegel als Laufwerk Micro Vault Tiny-Gerät angezeigt. (Der Laufwerkname hängt von Ihrem Computersystem ab.)

Unter Mac OS 9.0 und höher
Wenn Sie Micro Vault Tiny an den Computer angeschlossen ist, wird das Laufwerkspiegel als Laufwerk Micro Vault Tiny-Gerät angezeigt. (Der Laufwerkname hängt von Ihrem Computersystem ab.)

Unter Windows XP, Windows 2000 oder Windows Me
Wenn Sie Micro Vault Tiny an den Computer angeschlossen ist, wird das Laufwerkspiegel als Laufwerk Micro Vault Tiny-Gerät angezeigt. (Der Laufwerkname hängt von Ihrem Computersystem ab.)

Unter Mac OS 9.0 und höher
Wenn Sie Micro Vault Tiny an den Computer angeschlossen ist, wird das Laufwerkspiegel als Laufwerk Micro Vault Tiny-Gerät angezeigt. (Der Laufwerkname hängt von Ihrem Computersystem ab.)

Unter Windows XP, Windows 2000 oder Windows Me
Wenn Sie Micro Vault Tiny an den Computer angeschlossen ist, wird das Laufwerkspiegel als Laufwerk Micro Vault Tiny-Gerät angezeigt. (Der Laufwerkname hängt von Ihrem Computersystem ab.)

Unter Mac OS 9.0 und höher
Wenn Sie Micro Vault Tiny an den Computer angeschlossen ist, wird das Laufwerkspiegel als Laufwerk Micro Vault Tiny-Gerät angezeigt. (Der Laufwerkname hängt von Ihrem Computersystem ab.)

Unter Windows XP, Windows 2000 oder Windows Me
Wenn Sie Micro Vault Tiny an den Computer angeschlossen ist, wird das Laufwerkspiegel als Laufwerk Micro Vault Tiny-Gerät angezeigt. (Der Laufwerkname hängt von Ihrem Computersystem ab.)

Unter Mac OS 9.0 und höher
Wenn Sie Micro Vault Tiny an den Computer angeschlossen ist, wird das Laufwerkspiegel als Laufwerk Micro Vault Tiny-Gerät angezeigt. (Der Laufwerkname hängt von Ihrem Computersystem ab.)

Unter Windows XP, Windows 2000 oder Windows Me
Wenn Sie Micro Vault Tiny an den Computer angeschlossen ist, wird das Laufwerkspiegel als Laufwerk Micro Vault Tiny-Gerät angezeigt. (Der Laufwerkname hängt von Ihrem Computersystem ab.)

Unter Mac OS 9.0 und höher
Wenn Sie Micro Vault Tiny an den Computer angeschlossen ist, wird das Laufwerkspiegel als Laufwerk Micro Vault Tiny-Gerät angezeigt. (Der Laufwerkname hängt von Ihrem Computersystem ab.)

Unter Windows XP, Windows 2000 oder Windows Me
Wenn Sie Micro Vault Tiny an den Computer angeschlossen ist, wird das Laufwerkspiegel als Laufwerk Micro Vault Tiny-Gerät angezeigt. (Der Laufwerkname hängt von Ihrem Computersystem ab.)

Unter Mac OS 9.0 und höher
Wenn Sie Micro Vault Tiny an den Computer angeschlossen ist, wird das Laufwerkspiegel als Laufwerk Micro Vault Tiny-Gerät angezeigt. (Der Laufwerkname hängt von Ihrem Computersystem ab.)

Unter Windows XP, Windows 2000 oder Windows Me
Wenn Sie Micro Vault Tiny an den Computer angeschlossen ist, wird das Laufwerkspiegel als Laufwerk Micro Vault Tiny-Gerät angezeigt. (Der Laufwerkname hängt von Ihrem Computersystem ab.)

Unter Mac OS 9.0 und höher
Wenn Sie Micro Vault Tiny an den Computer angeschlossen ist, wird das Laufwerkspiegel als Laufwerk Micro Vault Tiny-Gerät angezeigt. (Der Laufwerkname hängt von Ihrem Computersystem ab.)

Unter Windows XP, Windows 2000 oder Windows Me
Wenn Sie Micro Vault Tiny an den Computer angeschlossen ist, wird das Laufwerkspiegel als Laufwerk Micro Vault Tiny-Gerät angezeigt. (Der Laufwerkname hängt von Ihrem Computersystem ab.)

Unter Mac OS 9.0 und höher
Wenn Sie Micro Vault Tiny an den Computer angeschlossen ist, wird das Laufwerkspiegel als Laufwerk Micro Vault Tiny-Gerät angezeigt. (Der Laufwerkname hängt von Ihrem Computersystem ab.)

Unter Windows XP, Windows 2000 oder Windows Me
Wenn Sie Micro Vault Tiny an den Computer angeschlossen ist, wird das Laufwerkspiegel als Laufwerk Micro Vault Tiny-Gerät angezeigt. (Der Laufwerkname hängt von Ihrem Computersystem ab.)

Unter Mac OS 9.0 und höher
Wenn Sie Micro Vault Tiny an den Computer angeschlossen ist, wird das Laufwerkspiegel als Laufwerk Micro Vault Tiny-Gerät angezeigt. (Der Laufwerkname hängt von Ihrem Computersystem ab.)

Unter Windows XP, Windows 2000 oder Windows Me
Wenn Sie Micro Vault Tiny an den Computer angeschlossen ist, wird das Laufwerkspiegel als Laufwerk Micro Vault Tiny-Gerät angezeigt. (Der Laufwerkname hängt von Ihrem Computersystem ab.)

Unter Mac OS 9.0 und höher
Wenn Sie Micro Vault Tiny an den Computer angeschlossen ist, wird

